



Intro - Start Here

Where to start learning about FOME.

FOME Overview

What is FOME

Which FOME hardware to pick

Currently there are a few sweet options for hardware, all have the same brain, but with different baseboards.

Where to get firmware

FOME firmware releases are located here. You can download a release and install to the ECU with the console, or another way is to use TunerStudio (T...

Updating the firmware

Updating the firmware is easy to do, however it is important to do it correctly to prevent errors or board

Performing a safe first start

page to outline the best practice for doing a first start

How to first setup a board for use

Outputs, etc. Checking correct tune loaded

How to test inputs and outputs

Input tests

Tips and Tricks

Power cycle ECU

How to pick a fuel method

Use this to explain the pros and cons of each of the methods and which is more suitable for certain builds

Guide to Tuning the ETB and VVT PIDs

Let's discuss the ETB and VVT PID controls and some give techniques for tuning these loops.

Miata MX5 Quick Start Guide

So, you've just got yourself a shiny new BMM MX5 Miata ECU for your NA or NB, nice! If you're wondering how to install and get it running, you've co...

FOME Overview

What is FOME

Fome is an open-source project to create a whole vehicle open ecosystem that is able to work with modern vehicles with a view to safety, reliability, and sustainability. Fome is born out of existing open-source projects and intends to build upon those in a way to meets automotive standards and provides the best possible experience for users and contributors.


Which FOME hardware to pick

Currently there are a few sweet options for hardware, all have the same brain, but with different baseboards.

BRAIN

Polygonus

This is where the real action happens. Designed to be consistent across different base board applications to simplify design, ensure repeatability, and reduce cost. The Polygonus (said Puh-LIG-on-us) Brain is on all FOME ECUs.




BASEBOARDS

BMW

For the M50TU and M60 engines (and harnesses), this plug and play FOME ECU will allow you to use your turn signals (cringe jokes). No but really, E36 Chassis is hot right now. Street/Drag/Drift you name it. Everyone who had an S-Chassis now wants an E36. Hell you could use this in other

Miata

You love big hair, short shorts, and tops off 24/7 (and stereotypes too). Luckily FOME has you in mind with a wide arrangement of options for the Mazda Miata Platform. [BeerMoneyMotorsports](#) in sexy *billet* cases. NA,NB, 1.6, 1.8, VVT, turbo, ITBs, etc. You name, it, and its covered.



Harley

Whether you're cruising the highways, crushing that 1/4 mile, or just want more power, the Harley FOME ECU (designed for 2021+ bikes) is an excellent choice. [NMSTEC](#) has them available ready to go, also in a very

nice *billet* case.



Coming Soon

Universal

Sometimes you don't know what car your engine is going in, or you want to do a swap. Regardless, a universal option is always good to have. It uses the common and reliable VAG (not that VAG, but Volkswagen Audi Group) plugs with a nice 120 pins. This means 8 cylinders of sequential fueling (up to 12 batch), plenty of inputs and outputs. (20 lowside, 4 highside, CANBUS, SD Card) It should be able to handle 95% of projects

out there.

Honda

VTEC baby

Where to get firmware

FOME firmware releases are located [here](#). You can download a release and install to the ECU with the console, or another way is to use TunerStudio (TS).

Tuner Studio Setup

Make sure that you have downloaded the latest version of TunerStudio (TS) from [here](#). Although the base version of the software is free, it is strongly recommended to buy a license for the additional features including auto-tuning and the ability to customize the default dashboard.

Begin the setup by plugging the ECU into the laptop and opening TS. Create a new project and click *detect* under firmware. Select the COM port corresponding to the FOME ECU in the device list. If the COM port cannot be found or the firmware cannot be automatically detected, click *Other/ Browse* and load the .ini file for the ECU which can either be downloaded or found within the ZIP file on the USB device which appears when the ECU is plugged into the computer.

Note

As per the [FOME Statement](#), we want to make clear that FOME is currently a fork of rusEFI, and that present boards are BOTH rusEFI and FOME

compatible. As time goes on, and more changes are made, this compatibility may change.

Updating the firmware

Updating the firmware is easy to do, however it is important to do it correctly to prevent errors or board misconfiguration. A guide to downloading FOME firmware and setting up TunerStudio can be found [here](#).


Updating firmware involves a process sometimes called "flashing" or even "programming" the ECU. Generally, these all refer to the same thing: taking the compiled FOME firmware and loading it into the non-volatile flash memory on the ECU.

Updating the firmware with FOME console


After confirming the firmware to flash to the ECU, software to do so must be used. FOME provides a utility, the **FOME console**, which is capable of flashing firmware to supported ECUs and is the recommended way to update FOME firmware. The FOME console is included with each firmware release, and bundles can be downloaded from [the release page](#).

After extracting the bundle contents, navigate to the `console/` directory and run the FOME console program (e.g. `fome_console.exe` if using Windows). After first confirming **TunerStudio is not running**, connect the ECU to the computer. FOME console will automatically detect the

board and present similar to the display below.



Next, choose the *Update Firmware* button and leave the board connected until the console notifies that the update was successful with a green display. Only once the console has presented this success message, disconnected and re-connect the ECU to the computer to reboot it with the new firmware.




If the update completes successfully, congratulations; proceed to [the Setting up TunerStudio section](#). If the update does not complete successfully, the firmware may need to be loaded by first forcing the board into bootloader or Device Firmware Update (DFU) mode, documented in the next section.

Updating firmware via manual bootloader/DFU mode

In the event of a firmware update/flash failure, or some other firmware corruption issue, such that FOME console nor TunerStudio recognize the ECU when connected, the board needs to be first forced into bootloader mode before updating. In these situations, the FOME console cannot communicate with the firmware and so is unable to configure it into bootloader mode for updating.

To enter bootloader mode, on the ECU you will need to access buttons or pins on the main board to force the processor into this mode. Some boards use a momentary button, likely near to the reset button, to force this mode during power-up. Others might use a set of pins or pads that need shorted to force this mode during power-up. Press the button or short the pins with the ECU disconnected from the computer, then simultaneously connect the ECU into the computer. Once connected, the button can be released or the short removed.

When a board has been successfully booted into bootloader/DFU mode, the FOME console will recognize this and display the manual DFU update selection.




Next, choose the *Update Firmware* button and leave the board connected until the console notifies that the update was successful with a green display. Only once the console has presented this success message, disconnected and re-connect the ECU to the computer to reboot it with the new firmware.


Setting up TunerStudio

With the ECU connected, open TunerStudio with the associated project. TunerStudio will recognize that the project's ECU definition is out of date and display a prompt to update it. Choose the *Update ECU Definition* button, which will attempt to automatically update the definition from official sources. If an official definition cannot be found, manually load the `.ini` definition file associated with the firmware (i.e. from the

downloaded bundle).



Next, under the *Controller* tab, open the *Popular vehicles* menu and choose the top button (e.g. *Hellen NB1 36 wheel* as shown here) to load the preset for your vehicle (**not the button to *Reset firmware settings***).



Once the preset has been loaded, you can either start tuning or load your tune from the older firmware versions under *File > Load Tune (msq)*. After that, the update is complete!

Performing a safe first start

page to outline the best practice for doing a first start

How to first setup a board for use

Outputs, etc. Checking correct tune loaded

How to test inputs and outputs

Input tests

Output tests

Tips and Tricks

Power cycle ECU

Any change that you make to the tune or ecu should be followed by a power cycle of the ecu. The only exception to this is for tuning tables (VE Timing etc.)

Always have a main relay

The main relay is an essential component of the FOME ECU system. It is responsible for delivering power to the ECU when the key is turned on. Without the main relay, the ECU would not receive any power and would not be able to function properly.

Why use a main relay?

Using a main relay has several benefits. First, it helps to protect the ECU from power surges and voltage spikes that can occur when the engine is starting. Second, it allows for a more secure and stable connection between the ECU and the power source, which can help to prevent electrical interference and noise.

It's important to note that the wiring of the main relay may vary depending on the specific ECU and vehicle configuration. Always refer to the manufacturer's instructions and wiring diagrams when installing the main relay to ensure proper installation and operation.

Why do I have XYZ error?

Check error code and compare to this list (grab list out of firmware)

Table Axis

Make sure these are always numerically ascending (i.e. 1, 2 ,3 not 1, 1, 3, or 1, 3, 2.)

If you have these going from a large number to a small, stuff is not going to work.

How to pick a fuel method

Use this to explain the pros and cons of each of the methods and which is more suitable for certain builds

Guide to Tuning the ETB and VVT PIDs

Let's discuss the ETB and VVT PID controls and some give techniques for tuning these loops.

$$u(t) = K_p e(t) + K_i \int_0^t e(\tau) d\tau + K_d \frac{de(t)}{dt}$$

More Details

Wikipedia's PID Controller page's [operational description](#).

More details about ETB PID control are found in the Advanced Features section's page [ETB PID and Autotune](#).

More details about VVT PID control are found in the Advanced Features section's page [VVT PID Control](#).

Miata MX5 Quick Start Guide

So, you've just got yourself a shiny new BMM MX5 Miata ECU for your NA or NB, nice! If you're wondering how to install and get it running, you've come to the right place. This guide will cover how to install the ECU to the car with a Bosch LSU 4.9 wideband oxygen sensor and a mass air pressure (MAP) line. Installation of additional sensors or peripherals is covered in the advanced guides.

NOTE: Before commencing the ECU installation, it is recommended to jack up the car or drive it onto ramps in the case when the oxygen sensor location is under the vehicle.

Required Tools and Components

- BMM Miata ECU
- BMM wideband adapter harness
- BMM options port pigtail
- Genuine Bosch LSU 4.9 oxygen sensor
- 3 metres of silicone vacuum hose 5/32" or 4mm internal diameter
- 4mm straight barb joiner
- 22mm wrench or 22mm oxygen sensor socket
- Timing light
- USB cable (included with ECU)


- Windows, Mac or Linux laptop with an installed copy of [EFI Analytics TunerStudio](#)
- Spanner and socket set

Removing Original ECU

The stock ECU location for a Miata will be in one of three spots depending on the driving side and year:

Left Hand Drive NB

The ECU can be found above the pedals, next to the steering column.



90-93 Left Hand Drive NA and Right Hand Drive NA/NB

The ECU can be found under the carpet in the passenger side footwell. To access this, the carpet needs to be unhooked from the vertical trim piece on the edge closest to the passenger door. Removing this trim piece can also simplify access. The ECU kick plate will also need to be removed after

taking off the five 10mm nuts and bolts holding it in place.



94-97 Right Hand Drive NA

The ECU can be found behind the passenger's seat, under the carpet. Move the seat forwards all the way. Next, the passenger door sill needs to be removed with a philips head screwdriver so that the carpet towards the

back of the seat can be pulled back to reveal the ECU.

Once the ECU has been located on your Miata, disconnect the car battery then remove all electrical plugs to the ECU. Un-bolt any remaining ECU mounting brackets from the car with a 10mm socket and the ECU should now be free from the car. The last step is to use a philips head to remove the factory ECU mounting brackets from the stock ECU case for these will be needed to mount the BMM ECU.



Connecting Wideband Oxygen Sensor

NOTE: It is imperative that you use a genuine Bosch LSU 4.9 sensor rather than a cloned product. A fake LSU 4.9 will not provide accurate readings and can cause a lot of headaches down the track. The best way of avoiding a fake sensor is to buy directly from a reputable supplier of vehicle parts rather than generic large online re-sellers. Typical part numbers for this Bosch sensor include: 17025, 17212, 17123 and 17217. The notable difference between these part numbers is the cable length so it is recommended to measure what length you need ahead of time.

Find the factory oxygen sensor on the exhaust and unplug it from the wiring harness. In the case that the car has multiple oxygen sensors, the one to remove is the closest sensor to the engine block before any catalytic converters. Next, unscrew the sensor and replace it with a Bosch LSU 4.9 wide-band sensor. Connect the sensor to the BMM wideband adaptor harness. The trailing end of the harness will need to be fed through the firewall into the cabin. The easiest way of doing this, as shown in the image below, is to cut a hole in the nearest firewall bung to the stock ECU location, and feed the cable through that. Cable tie the wiring away from any hot areas of the engine bay. Inside the cabin, connect the wideband adaptor harness plug to the options port pigtail and plug it into the ECU.




Using an External Wideband Controller

In the case you wish to use an external wideband controller such as an *AEM X-Series Wideband UEGO AFR Sensor Controller Gauge*, the wideband sensor should be plugged into the wideband controller instead of directly into the ECU. The best way to wire in the controller is directly to the old narrow band oxygen sensor plug on the car based off the diagram below. In this diagram, pin 1 goes to the controller analogue output, pin 2 to the signal ground, pin 3 to the controller 12V input and pin 4 to the other controller ground (if applicable). Make sure to double check the voltages on the pins before connecting the controller to them. The external controller also requires additional setup in Tuner Studio which will be covered later.

MAZDA 4-WIRE

1

OE: Signal (Black)
Universal: Signal
Type B (Blue)



3

2

OE: Ground (Gray)
Universal: Ground
Type B (White)

OE: Heater (White)
Universal: Heater
Type B (Black)

4

OE: Heater (White)
Universal: Heater
Type B (Black)


Note: View From Front Of Connector

Connecting MAP Line

Look around the intake manifold for any spare vacuum ports that lie after the throttle body and connect the vacuum line. If there are no spare ports, pick one and attach the vacuum line to it using a tee piece. It is recommended but not required to cable tie the vacuum line to the tee. In the image below, there was a free vacuum port on the back of the intake manifold which has been tee'ed off into the MAP line and the blow off valve line (only applicable on turbo charged vehicles).



Like the oxygen sensor, feed the line through the bung in the firewall to the ECU. If you have a 4mm barb joiner, connect the vacuum line to the vacuum line protruding from the BMM ECU case. If you do not have a barb joiner, open up the BMM ECU case with a philips head and feed the vacuum line through the case. Mock up the position of the case in the car before cutting the vacuum line to length. Pull the vacuum line onto the MAP sensor on the ECU (the sensor with the nipple on it pictured below) and optionally fasten it with a small cable tie. The ECU can now be put back into its case.



Using the MAP line combined with an intake air temperature (IAT) sensor, the BMM ECU can run the car using what is known as speed-density air metering. This means that you can unplug the mass air flow (MAF) sensor or the air flow meter (AFM) for the NA 1.6L vehicles. Removing these sensors and replacing them with a pod filter directly to the intake can even result in a fractional power increase from the reduction in intake restriction.

Additional Steps for NA6 Vehicles

The NA6 1.6L vehicles which use an AFM instead of a MAF require a few additional modifications to run with a BMM ECU. A manual NA6 do not have a variable throttle position sensor (TPS) like the automatic NA6, later model NAs and all NBs. An NA6 also needs an external intake air temperature (IAT) sensor wired in as the AFM which has one inside is

typically removed. They also require a jumper for the ECU to control the fuel pump which was previously the job of the air flow meter.

The first step is to disconnect the factory TPS sensor. **This is very important or it will cause a short circuit later.** The TPS sensor location is shown in the image below.




The BMM ECUs for this vehicle include a KIA TPS and adapter. The KIA TPS will plug straight to the OEM TPS plug without any additional wiring. If using another variable TPS that requires re-wiring, the NA6 TPS connector pinout is as follows:

Function	Cable Colour
Signal	Green/White
Ground	Black/Green

Function	Cable Colour
5V Reference	Red

The next step is to wire up the IAT sensor and to add a jumper wire to the AFM connector as per the wiring diagram below. Any IAT sensor with two wires can be used although a GM IAT sensor is recommended as FOME already has a configuration for it. As the IAT is a resistance-based sensor, the orientation of the wires does not matter.




Connecting the ECU

Now that the MAP line and wideband are connected to the ECU, the remaining wiring harness plugs from the OEM wiring loom can be plugged into the ECU. Take the factory ECU mounts and attach them to the BMM ECU case. The ECU can now be re-installed into the factory location. The car battery can now be re-connected.

Tuner Studio Setup

Make sure that you have downloaded the latest version of TunerStudio (TS) from [here](#). Although the base version of the software is free, it is strongly recommended to buy a license for the additional features including auto-tuning and the ability to customize the default dashboard.

Begin the setup by plugging the ECU into the laptop and opening TS. Create a new project and click *detect* under firmware. Select the COM port corresponding to the FOME ECU in the device list. If the COM port cannot be found or the firmware cannot be automatically detected, click *Other/Browse* and load the .ini file for the ECU which can either be downloaded or found within the ZIP file on the USB device which appears when the ECU is plugged into the computer.



In the next dialog choose between lambda or air fuel ratio (AFR) as your display units. lambda is recommended as it is easier to comprehend and tune with. For example, the ideal or stoichiometric AFR for regular petrol is 14.7 (14.7 parts air to 1 part fuel) which corresponds with a lambda of 1. Lambda represents the percentage of air in the combustion chamber compared to the amount needed for ideal or stoichiometric combustion to

occur. If a car is running 10% lean, the AFR would be 16.17 and lambda would be 1.1. If the car is 10% rich, AFR would be 13.36 and lambda would be 0.9. Looking at lambda, it is instantly obvious what percentage rich or lean the engine is running but with AFR, it requires more effort.

The only time AFR should be selected here is if you are using an external wideband controller.

In the third dialog box, configure it as shown in the image below but select the com port which corresponds to your ECU. If unsure, go to the device manager on your computer and it should list the COM port number next to the name of the ECU. Click *Test Port* and if successful, move to the next dialog.

Create New Project X

New TunerStudio Project

Communication Settings

Driver: Standard Protocols Driver (Default) ▼

Connection Type

RS232 Serial Interface ▼

Connection Settings

Com Port: COM3 ▼ ?

Baud Rate: 115200 ▼ ?

Bluetooth Port ?


Not tested Test Port

< Back Next >

In the final dialog box, select the default gauge layout (you can change this later as you wish) and click *finish*. The last step before cranking the engine is to click the *Ignition* button to open the ignition settings and change the timing mode from *dynamic* to *fixed* and the fixed timing setting to 10 degrees. This will lock the engine to operate at 10 degrees of timing so that you can set the base timing.

Additional Tuner Studio Steps for an External Wideband Controller

To set up the external wideband controller there are several additional steps in Tuner Studio. First, your display units should be set to AFR for this as already stated. If you forgot to do this earlier, press *CTRL + P* to open the vehicle properties. Now, open the *Aux Sensors* dialog under *Sensors* and the *Full Pinout 3/3* dialog under *Controllers*. As per the diagram below, set the *AFR ADC Input* and *ADC Input* to the pin corresponding with *O2S* (pin 2C for the example). for the values in the *Aux Linear Sensor #1* box you need to reference the manual of your wideband controller for what voltages correspond to its AFR outputs. In the example below, 0V corresponds to an AFR of 10.0 and 4.99V corresponds to an AFR of 19.98. Once these are set, click *Burn*.




After completing all of the setup steps, you can go ahead and turn the car key two clicks to *ON* and listed for the fuel pump priming. Once the fuel pump has primed, go ahead and start the engine. Let it run for a few seconds and turn it off again. **Do not drive the vehicle yet, there are still several steps to complete before the car is ready for a drive.**


Set Base Timing

The car should start on the base map although once it is running, the base timing needs to be set up. This syncs the timing between the ECU and the car so that they are both reading the same values. Typically, the base timing will be a few degrees out from the base map as it varies slightly from car to car.


To set the base timing, connect the timing light power to a spare 12V battery and the inductive clamp onto the cylinder 1 spark plug lead (the closest spark plug to the front of the engine bay). Ensure that the arrow on the inductive clamp is pointing along the wire towards the spark plug, not towards the coil pack.




In TS, under *Ignition > Ignition Settings*, set the timing mode to *fixed* and *10* degrees then burn the configuration.



Now start the car and hold the timing gun trigger, shining the light onto the bottom harmonic damper pulley on the front of the engine. This pulley has two timing marks on it and a labelled cover above it. When the timing is spot on, these marks on the rotating pulley will line up with the *10* and *T* marks on the cover as shown below.



If your timing marks do not line up like in the image above, you will need to change the base timing. Count how many marks the timing is off by and turn the car engine off. In TS, go to *Base Engine > Trigger* and increase/decrease the *Trigger Advance Angle* by the amount of marks the timing was off by then burn the configuration. Repeat this process until the timing marks line up then change the timing mode back from *fixed* to *dynamic*.




First Drive and Tuning the VE Table


Everything is now ready to take your Miata for its first drive. You can't go and thrash it straight away though as the VE table which determines the fuelling needs to be tuned for your vehicle. Before you take the car for a drive, make sure your laptop is charged.

Start the car and plug the laptop in. Within 30 seconds, the lambda gauge should wake up and start displaying a value. For now, you want that value to be around 1 meaning that the exact amount of fuel is being supplied to the engine for perfect combustion to occur. To change the lambda value, you need to modify the VE Table under *Fuel > VE*. VE stands for volumetric efficiency which is the efficiency that the engine can move the fuel and air mix into and out of the cylinders. An example of a VE table is shown below (do not copy this table as it is off a highly modified vehicle). The table adjusts the VE percentage (represented by the numbers on the grid) based on the engine speed (represented as revolutions per minute - RPM) and engine load (represented as the MAP). With the engine running,


blip the throttle and see how the indicator moves around the different table cells as the engine state changes.




The general way to tune the VE table is to go through all the cells which the engine will operate within and to adjust the VE percentage until the lambda gauge matches the value in the *Target Lambda Table* shown below and in TS found under *Fuel > Target Lambda*. For example, if the lambda gauge shows 1.1 and the target lambda for that engine state is 1.0, the corresponding VE cell needs to be increased by 10%. The target lambda table supplied with the Miata base map should be sufficient to start with but you can modify it later to make the engine run richer or leaner under certain conditions such as boost or highway cruising respectively.



There are three ways of tuning the VE table. The first way is to drive the car around smoothly as a mate in the passenger seat goes through and changes the VE values until the lambda gauge matches the target lambda. The second and easier way is to use the TS autotuner which is only available in the full version of TS but absolutely worth it. To tune this way, you first need to disable some parameters. Under *Fuel*, open *Closed loop fuel correction* and *Deceleration fuel cut off (DFCO)*, set them both to false and click *burn* with the engine off. The third and easiest (yet most expensive option) is to take the car to a dyno for tuning where they will do either the first or second option themselves. The advantage of a dyno is that they can set it to bring the engine into any state they wish to perfectly configure the VE table.



Next, click the tab labelled *Tune Analyze Live! - Tune For You* to bring up the autotuner. Click to the *Advanced Settings* tab and configure it as shown in the image below. These configuration settings are deliberately quite loose so that TS can quickly tune the general shape of the VE table. On the left side of the *VE Table Control Panel*, you also need to check the box marked *Update Controller* which ensures that the VE table is updated on the ECU as the autotune corrects itself.



Now that the autotuner is set up, start the car and click *Start Auto Tune* on the autotuner. Let the car idle in park whilst it gets up to the minimum temperature. While this happens, you can attempt to change the idle cells in the VE table to get them to a lambda of 1. Once the car has warmed up, **smoothly** drive it around going through the gears and all the way through the rev range. A mix of flat, uphill and downhill driving in different gears is optimal to tune the majority of the engine's operating range. After you are sufficiently happy, click *Stop Auto Tune*, turn the engine off and click *Save on ECU*. You will want to repeat this process several more times, every time dropping the *Cell Change Resistance* and *Authority Limits* to slowly refine your VE table.

When you are satisfied with your VE table, turn closed loop fuel correction and *Deceleration fuel cut off (DFCO)* back to true. You don't actually need DFCO to be enabled although it will save fuel by turning the injectors off when the car is rolling in gear. Your Miata should now be relatively safe to drive but this is only the start of the tuning journey. As you read through the more advanced guides in this wiki, you will learn about all of the different ways the ECU can be configured to improve the drivability and squeeze every drop of performance out of your Miata.

Fundamentals of FOME tuning

The place to learn how to start tuning your FOME Hardware

Quick Start to fuel tuning

These instructions make some pretty serious assumptions:

Air Fuel Ratio

Air fuel ratio or AFR refers to the mass ratio of air to fuel involved in a combustion cycle. The AFR is important as the amount of fuel injected into the ...

Acceleration Compensation

What is acceleration compensation and why do I need it?

What is charge temperature estimation

Charge temp estimation is a method of predicting the temperature of air moving past the intake valve into the cylinder from less than perfect measu...

What is knock and why it matters

Knock is rapid, uncontrolled combustion which results in a correspondingly extremely fast increase in cylinder pressure. Knock is often accompanied ...

Multi-Dimensional Mapping, what is it and how to benefit from it

This page is under construction

Spark timing, MBT and combustion

What to put into this section

Use this folder for covering the overall topics of why things are needed, this is the place to talk about things like why an engine needs certain AFRs, ...

Quick Start to fuel tuning

These instructions make some pretty serious assumptions:

1. You have a setup that isn't going to grenade if you get things wrong for a few seconds
2. You know to lift off the throttle quickly if things are wrong
3. Your ignition maps are safe. THIS IS A BIG ASSUMPTION.
4. These instructions are oriented towards a naturally aspirated engine. Tuning a boosted engine this way is probably too risky, although it will work. Consider popping wastegate open with shop air, zip tie-ing bypass valve, popping a charge pipe (which has its own risks) or similar method to limit boost to minimal levels

DANGER

If you are not sure about your ignition maps, have a high-strung engine likely to blow up and hurt things, DO NOT DO THIS. These instructions assume a certain degree of forgiveness, which all engines are not necessarily going to give you.

Roughing in a fuel/VE map:

1. Estimate maximum VE value. For something like a 70s pushrod V8, this is probably 85-90%. For a modern overhead cam 4 valve head, this is probably more like 95%. For a very modern engine with VVT and high quality heads, this could be as high as 100%.

2. Set VE table to expected maximum value for loads 90kpa - 100kpa. set target AFR to something safe and THE SAME ACROSS THE BOARD i.e. 0.8 lambda everywhere
3. run engine hard, log AFR. We're talking Wide Open Throttle (WOT) operation
4. adjust injector size so that target AFR at peak torque (VE) is achieved. You will end up with lots of areas too rich and one narrow area in the middle of the powerband where AFR is just right
5. adjust VE at high load in order to achieve uniform AFR at WOT. This will mean decreasing VE as you move away from peak torque, where VE will be highest.
6. set entire table vertically (i.e. same RPM different load) as WOT VE
7. Pick a couple of part throttle load points. Adjust VE at part throttle load points to achieve target AFR. Apply same correction to all RPM points at chosen load.
8. Interpolate from chosen VE points vertically to WOT (or the next highest VE point you tuned)
9. extrapolate trends to lowest throttle loads
10. Set more reasonable target AFRs (i.e. 1.0 lambda at part throttle, 0.85 lambda at power desired)
11. adjust injector latency to achieve reasonable idle AFRs
12. revisit part throttle VE after latency changes with the expectation of small change in the opposite direction as latency changes. i.e. if you increased latency, expect to decrease VE but only a very small amount

Air Fuel Ratio

Air fuel ratio or AFR refers to the mass ratio of air to fuel involved in a combustion cycle. The AFR is important as the amount of fuel injected into the engine is one of the most significant combustion parameters that the ECU can control. The ECU takes the target AFR and determines the correct mass of fuel to inject based on the mass of air approximated using the temperature and pressure.

Why AFR Matters

An engine operates most efficiently and cleanly when the air-fuel ratio is at a specific value called the stoichiometric ratio. This ratio depends on the type of fuel being used, but for gasoline, it is approximately 14.7 parts air to 1 part fuel (14.7:1). When the air-fuel ratio is at the stoichiometric value, all of the fuel is burned, and there is no excess oxygen or unburned fuel left in the exhaust. This results in the least amount of emissions and the highest fuel efficiency. If the air-fuel ratio is too lean (excess air), there is not enough fuel to burn, and the engine may misfire or stall. If the air-fuel ratio is too rich (excess fuel), there is not enough oxygen to burn all the fuel, and the engine may emit more pollutants, have reduced fuel efficiency, and may even cause damage to the engine over time.

Therefore, maintaining the proper air-fuel ratio is essential for optimal engine performance, fuel efficiency, exhaust gas temperature, engine knock and emission control in a car engine.

What is Lambda and Why it is a Superior Metric


Lambda, is a dimensionless ratio of the actual air-fuel ratio to the stoichiometric air-fuel ratio. In other words, it is the ratio of the AFR to the stoichiometric AFR (or the measured AFR divided by the stoichiometric AFR). Lambda is a more universal measure of the air-fuel ratio, as it is not affected by the specific fuel being used. The stoichiometric lambda value for any fuel is always 1.0, regardless of the fuel type. For example, if the actual AFR in an engine is 14.7:1 (stoichiometric AFR), then the lambda value is 1.0. If the actual AFR is leaner than 14.7:1, then the lambda value is greater than 1.0, and if it is richer than 14.7:1, then the lambda value is less than 1.0.

Lambda is preferred in engine tuning because it allows for a more precise control of the air-fuel ratio across different fuels and is generally easier to comprehend. For example, if a gasoline car is running 10% lean, the AFR would be 16.17 and lambda would be 1.1. If the car is 10% rich, AFR would be 13.36 and lambda would be 0.9. Looking at lambda, it is instantly obvious what percentage rich or lean the engine is running but with AFR, it requires more effort.

AFR Targets - When to Run Rich, Lean and Stoich

The ideal AFR targets will vary for every engine however there are

guidelines for what the targets should be for each operating zone of the engine. These targets will be represented on an AFR target table or map, shown below, which characterizes the various engine operating conditions for their respective engine RPM and MAP. Generally speaking, running richer will decrease engine response at a gain of extra combustion chamber cooling and slightly higher power to a point. Inversely, running leaner will increase engine response at a loss running hotter and reducing power.



Idle and Cruising

For idle, a lambda of 1.0 is generally recommended to achieve a stable idle. When cruising, a lambda of 1.0 is also recommended however this can be raised up to about 1.05 to improve the fuel efficiency of the vehicle on the freeway or traveling a constant speed for long periods of

time.

Low and High Load Vacuum

In the low vacuum section of the map, the engine will only operate here when the engine is under minimum load such as rolling in gear with the throttle closed. To save fuel, the engine can be operated up to about 1.05 lambda here or Deceleration Fuel Cutoff (DFCO) can be enabled to disable to injectors entirely and let the vehicle engine brake. DFCO is found under the *Fuel* tab in Tuner Studio.

The high vacuum part of the map is typically only used in the short period between high RPM gear changes or throttle lifts. The engine is usually being driven hard if this part of the map is being used so a target lambda of 0.95 to help cool the cylinders is recommended although a value of 1.0 is also acceptable.

High Load Naturally Aspirated/Boost Transition Zone

For a naturally aspirated (NA) engine, this zone represents the peak operating load which the engine will be placed under. A lambda of about 0.9 is recommended to balance performance with cylinder cooling.

For a forced induction engine, this zone represents the engine's transition into boost. As the engine usually isn't under a lot of load here, a slightly higher lambda of 0.95 is recommended to balance the engine response with some degree cylinder cooling.

Medium and High Boost Zones

When the engine moves into boost, the engine load increases as does the temperature and pressure of the combustion. Hence, as the boost pressure increases, the AFR needs to get progressively richer. A good starting point for about 200kPa MAP or 14.5PSI of boost is a lambda of 0.78-0.82. For 300kPa MAP or 29PSI of boost, a 0.76-0.8 is generally a good starting range. Of course, every engine will differ so it is important here to research what others have successfully run on similar platforms to you.


Engine Start and Dead Zone

In both of these zones, their target AFRs do not matter a whole lot. The dead zone will never be operated in and the starting zone will never operate with closed loop fuelling as the lambda sensor will only activate after the car is running. The best configuration for these zones is to copy or transition them from the target AFR columns directly next to them for the sake of smoothness in the map.

Merging the zones

On the AFR target diagram, certain operating zones have missing values. To properly select targets for these zones, it's recommended to interpolate and smooth out the values between the defined sections of the map. It's important to create a smooth AFR target map that avoids abrupt changes, as the engine requires gradual variations in AFR to function optimally. To smooth the map in Tuner Studio there are four buttons in the map shown

below. From left to right, these buttons interpolate across the entire selected zone, interpolate horizontally only, interpolate vertically only, and smooths out changes between selected cells.



AFR For Different Fuels

Fundamentally, an oxygen sensor works in lambda. It measures the oxygen content in the exhaust relative to the open air and outputs a voltage which the ECU or wideband controller can directly convert to lambda. The ECU then converts this to AFR if required by multiplying the

lambda by the stoichiometric value of the fuel (typically 14.7 for unleaded). Regardless of the fuel, the oxygen sensor will read the same lambda for any fuel that is burning at its stoichiometric point. A table is shown below comparing the stoichiometric AFR values of common fuels.

Fuel Type	Stoichiometric AFR
Unleaded Gasoline	14.7
E85	9.76
E100	8.98
Diesel	14.5
Methanol	6.46

Acceleration Compensation

What is acceleration compensation and why do I need it?

What types of acceleration compensation are there?

What is charge temperature estimation

Charge temp estimation is a method of predicting the temperature of air moving past the intake valve into the cylinder from less than perfect measurements elsewhere. The temperature of the air entering the cylinder is what matters most for engine management but it is virtually impossible to measure because sensors can't be installed in the cylinder head and they take time to get a stable reading. Charge temp estimation seeks to make a better estimate than reading any one sensor present on the engine. Why not just read the temperature from an air temp sensor in a MAF or charge pipe? The air moving into the engine picks up heat from the engine bay, intake manifold, cylinder head before it actually enters the engine. This additional heat that the air soaks up isn't measured by the sensor. Charge temp estimation tries to mathematically model this extra heat soak to provide a better answer than the sensor alone can provide.

On a practical level, charge temp estimation works by taking an average of two sensors: air temperature (usually measuring the temperature of air entering the engine) and coolant temperature (measuring the temperature of the engine contributing to heat soak). Charge temp estimation is tuned by changing the bias, or how much each sensor contributes. At low load, less air is moving slowly into the engine. It has more opportunity to soak up heat from a hot engine and there are fewer

moles of air to spread the heat out between. At higher engine loads, air velocity is higher and there are more moles of air moving by. There is less time for air to soak up heat and there are more moles to divide up heat. Generally, at lower loads coolant temperature has a higher bias to reflect air soaking up more heat from the engine. Generally, at higher airflows, air temperature has a higher bias because it has less time to soak up temperature from a hot engine.

Tuning a charge air temp table properly is a hard problem without heavy instrumentation and an engine dyno. However, understanding the basics of how it operates can help poke it in one direction or another. Generally, when air temp changes produce odd or inconsistent air fuel ratio changes the charge estimation model can be a useful tool to make more consistent operation.

What is knock and why it matters

Knock is rapid, uncontrolled combustion which results in a correspondingly extremely fast increase in cylinder pressure. Knock is often accompanied by extremely high instantaneous combustion temperatures. Knock earned its name from the knocking or rattling noise that is audible from pressure waves smacking pieces of engine.

Knock matters because it breaks things. Peak cylinder pressures during knocking can be tens to hundreds of times higher than normal controlled combustion. The violent changes in pressure almost always exceed design parameters of the engine. Things break - headgaskets, pistons, connecting rods, crankshafts, rodbolts, headstuds, more. The intense heat associated with uncontrolled combustion can torch valves, melt holes in pistons and cylinder heads. Knocking at extremely light loads can sometimes be survived but it is a good idea to not operate engines while knocking.

Knock is typically detected by in-cylinder pressure transducers, ion sensing or acoustic sensors.

It is the job of engine management to take corrective action when knock is detected. This usually takes the form of retarding ignition timing.

Multi-Dimensional Mapping, what is it and how to benefit from it

This page is under construction

Multi-dimensional mapping is a new feature that has been recently introduced to FOME.

It is a method of overlaying multiple compensation maps over the simple Load vs RPM ignition and fuel table.

The term Multi-dimensional comes from the fact that each compensation table adds an extra dimension to the basic 3d map.

In FOME you are currently able to activate up to 4 additional compensation maps, each with its own configurable blend curve.

The purpose of these tables is to be able to configure an additional input that changes the fuelling or timing, for instance to compensate for things like Ethanol content, Different fuel octane rating or simple variable valve timing.

How it works

FOME allows the following inputs to be used as the input for each of the compensation maps:

TPS,

MAP,

CLT,

IAT,

Fuel Load,

Ignition Load,

Aux Temp 1,

Aux Temp 2,

Accelerator Pedal Position,

Battery Voltage,

VVT Position for bank 1 or 2 intake and exhaust,

Ethanol % sensed from the Flex Fuel,

Aux Linear Sensors 1 and 2,

GPPWM Outputs 1 to 4,

LUA outputs 1 and 2, RPM,

Detected Gear,

All of the above can be considered the additional dimensions the system is able to be mapped for once selected.

These are selectable in the four "blend config" tables.

Once one of these inputs is chosen in the Compensation table a blend table will become available.

This table is a 0 to 100% table that chooses how much of the adjustment in the compensation will be applied to the main table for each

combination of the dimension and RPM.

Spark timing, MBT and combustion

What to put into this section

Use this folder for covering the overall topics of why things are needed, this is the place to talk about things like why an engine needs certain AFRs, why timing needs to be reduced, what is knock, why do you need to add fuel on acceleration etc

Leave the details of how FOME works for each feature to the specific pages, when relevant we can link the firmware specific page and visavis, keep this and overview as a nuggets intro area

This can likely kill any dumb questions at source and prevent many user issues down the line

Sensors and gauges

Information on all sensor inputs and data outputs

General sensors

9 items

Temperature sensors

3 items

Pressure sensors

3 items

Fuel sensors

3 items



Driver controls and feedback

7 items

General sensors

General sensors

Analogue Input Settings

ADC V-Ref

AUX Sensor Inputs

Aux Speed Sensor

Camshaft position

Crankshaft Position

ETB Throttle Position

Mass Air Flow Meter

Throttle position

Throttle position sensors are used to tell the FOME ECU the angle of the throttle blade. Most are 3 wire:

Turbo Speed Sensors

Vehicle Speed Sensor

Notes on setting VSS

Analogue Input Settings

ADC V-Ref

Analogue Divider

Smoothing Factor

AUX Sensor Inputs

Aux Speed Sensor

Aux linear sensor

**Aux sensor serial comms
settings**

Camshaft position

Crankshaft Position

ETB Throttle Position

Mass Air Flow Meter

Throttle position

Throttle position sensors are used to tell the FOME ECU the angle of the throttle blade. Most are 3 wire:

1: Power (Provided from FOME ECU Power Output) 2: Ground (provided from FOME ECU Ground Output) 3: Signal (sent to FOME ECU Lowside input)

*ensuring power and ground come from the FOME ECU will make sure the signal is clean and consistent)

For vehicles with electric throttle bodies, throttle position sensors will need to always have two redundant signals (usually opposite ie 0-5v and 5-0v). This is to ensure safety of the operation of the vehicle.

Turbo Speed Sensors

Vehicle Speed Sensor

Notes on setting VSS

When setting VSS up calculate correct wheel rotations per km, use correct final drive ratio and then use the speed sensor gear ratio as a tuning factor to achieve correct speed reading.

Temperature sensors

Temperature sensors

 **Auxillary Temperature Inputs**

 **Coolant Temperature**

 **Intake Air Temperature**

Auxillary Temperature Inputs

Coolant Temperature

Intake Air Temperature

Pressure sensors

Pressure sensors



Barometric Pressure Sensing



Manifold Absolute Pressure

MAP sensors



Oil Pressure Sensors

Barometric Pressure Sensing

Manifold Absolute Pressure

MAP sensors

MAP settings

MAP sampling angle - See MAP sampling Angle page

Oil Pressure Sensors

Fuel sensors

Fuel sensors

Flex Fuel sensors

Flex fuel sensors measure the amount of ethanol content in the fuel passing through it. The flex fuel sensor has a pre calibrated signal that is sent fro...

Fuel Level Sensing

Fuel Pressure Sensors

Flex Fuel sensors

Flex fuel sensors measure the amount of ethanol content in the fuel passing through it. The flex fuel sensor has a pre calibrated signal that is sent from the sensor in a 0-5v voltage indicating which amount of ethanol is present. The FOME ECU has the ability to use this data. The signal circuit carries the ethanol percentage via the frequency signal.

The normal range of operating frequency is between 50-150Hz. The microprocessor inside the sensor is capable of a certain amount of self-diagnosis. An output frequency between 180Hz and 190Hz indicates that the fuel is contaminated.

In TunerStudio you select which input pin you have used for the signal from the flex fuel sensor. You can view % of content using a gauge in TunerStudio.

Fuel Level Sensing

Fuel Pressure Sensors

Driver controls and feedback

Driver controls and feedback

 **Accelerator pedal**

 **Battery Settings**

 **Brake position and pressure sensing**

 **BeerMoneyMotorsports KaN (CAN) Gauge**

Product description and purchase link: [BMM KaN Multi Fit CAN Gauge](#).

 **Clutch position sensing**

 **Rev Counter/Tachometer**

 **WBO2 Wideband Lambda Sensor**

Accelerator pedal

Battery Settings

Brake position and pressure sensing

BeerMoneyMotorsports KaN (CAN) Gauge

Product description and purchase link: [BMM KaN Multi Fit CAN Gauge](#).



The KaN gauge is a multi function, multi fit gauge designed exclusively for the Beer Money Motorsports line of ECUs. The gauge is designed to fit into multiple locations on a Miata including the oil pressure gauge hole, an air conditioning vent or into a standard 52mm gauge pod. Data is sent to the gauge via CAN bus communication wires coming from the ECU and the layout of the gauge can be configured wirelessly using its standalone WiFi network. This article will detail the installation and setup of a gauge into your Miata.

Wiring

Open your ECU casing and locate a 5/12V output, ground, CAN High, and CAN Low pins. Match each of these pins to one of the four corresponding wires on the gauge. For best signal over long distances, twist the pair of CAN lines.

WiFi Configuration

When powered, the gauge will start its own standalone wifi network. In the WiFi settings for your device, connect to this network with a phone or laptop and open your browser of choice. Next find the IP address of your gauge. It should be a number like "192.168.X.XXX" which was included with your gauge purchase. In the browser's web address bar, input this IP address of the device into the browser and go to the web page.

The web page should detail the gauge settings to allow for customization of the theme and displayed values.

Physical Installation

Several options are available to mount the gauge on a Miata depending on where you like your gauges, how much you like air conditioning, and how much you like removing your dashboard.

Oil Pressure Gauge Mounting

This is by far the most neat and integrated installation spot. If installing the

gauge here, it is recommended to also install an aftermarket oil pressure sensor to the ECU so that the gauge can display your oil pressure among other useful variables

Air Conditioning Vent Mounting

Another clean installation method is to replace an air conditioning eyeball vent on an NA/NB Miata with a 52mm gauge housing.

52mm Gauge Pod Mounting

With the 52mm housing option, the gauge can be mounted into any 52mm gauge pod housing which is the standard size for aftermarket automotive gauges. For Miatas specifically, there are a range of gauge pod mounts fitting to locations like the A pillar, in place of the radio console, on top of the gauge cluster, etc.

Bare PCB Mounting

Purchasing the gauge as a bare PCB allows you to design your own mounting solution. Mount the gauge anywhere from behind your steering wheel to inside a cup holder!

Clutch position sensing

Rev Counter/ Tachometer

WBO2 Wideband Lambda Sensor

Limits and Protections

Limiters, engine protections and safety features

Boost pressure limit

Coolant Based RPM limit

FOME Fuel and Ignition Cut Codes ("Clear Reason")

|Code|enum ClearReason|TunerStudio Text|Description|

FOME OBD fault codes and how to read them

The FOME ECU is providing a number of OBD fault codes, they are either standard OBD fault codes or FOME custom fault codes.

Fuel Pressure Compensation

Minimum oil pressure protection

Minimum oil pressure after start

Rev limiters

Hard cuts

Boost pressure limit

Coolant Based RPM limit

FOME Fuel and Ignition Cut Codes ("Clear Reason")

Code	enum ClearReason	TunerStudio Text	Description
0	None	None	no fuel/ignition cut
1	Fatal	Fatal Error	disabled due to fatal error
2	Settings	Setting Disabled	disabled by setting: <code>isInjectionEnabled/isIgnitionEnabled</code>
3	HardLimit	RPM Limit	disabled by hard (normal) RPM limit: <code>useCltBasedRpmLimit/cltRevLimitRpmBins/cltRevLimitRpm/rpmHardLimit/rpmHardLimitHyst</code>
4	FaultRevLimit	Fault RPM Limit	disabled by (fault) RPM limit -- ETB Problem: 1500, Fatal Error: 0
5	BoostCut	Boost Cut	disabled by boost cut pressure threshold: <code>boostCutPressure</code>
6	OilPressure	Oil Pressure	disabled due to low oil pressure after 5 seconds: <code>minOilPressureAfterStart</code>
7	StopRequested	Stop Requested	disabled due to engine stop
8	EtbProblem	ETB Problem	disabled due to detected ETB problem ("10 percent-seconds of integral error") -- currently not implemented
9	LaunchCut	Launch Control	disabled by launch control RPM retard condition: <code>launchRpm/launchFuelCutEnable/launchSparkCutEnable/launchControlEnable</code>
10	InjectorDutyCycle	Max Injector Duty	disabled due to injector duty cycle limits: <code>maxInjectorDutyInstant/maxInjectorDutySustained/maxInjectorDutySustainedTimeout</code> -- resets after falling below 20% duty
11	FloodClear	Flood Clear	disabled to allow flood clear mode: <code>isCylinderCleanupEnabled</code> -- TPS > 95% while cranking
12	EnginePhase	Engine Sync	disabled due to lacking engine-cam sync to avoid non-sync spark: <code>vvtMode[0]</code> -- ex: symmetrical crank (NB2, Nissan VQ/MR), uneven firing order (VTwin Harley)
13	KickStart	Kick Start	currently not implemented
14	IgnitionOff	Ignition Off	disabled because the ignition is off, exception: self-stimulation mode
15	Lua	Lua	fueling disabled by Lua script ignition cut request
16	ACR	ACR	disabled due to Harley Automatic Compression Release: <code>acrPin/acrRevolutions/acrDisablePhase</code> -- avoids spraying fuel everywhere

Code	enum ClearReason	TunerStudio Text	Description
17	LambdaProtection	Lambda Protection	disabled due to lambda protection: LambdaProtectionTimeout

FOME OBD fault codes and how to read them

The FOME ECU is providing a number of OBD fault codes, they are either standard OBD fault codes or FOME custom fault codes.

FOME specific custom codes are listed below

Meaning	Fault Code
CUSTOM_NAN_ENGINE_LOAD	6000
CUSTOM_WRONG_ALGORITHM	6001
CUSTOM_NAN_ENGINE_LOAD_2	6002
CUSTOM_INTEPOLATE_ERROR	6012
CUSTOM_INTEPOLATE_ERROR_2	6013
CUSTOM_INTEPOLATE_ERROR_3	6014

Meaning	Fault Code
CUSTOM_INTEPOLATE_ERROR_4	6015
CUSTOM_PARAM_RANGE	6016
CUSTOM_MAF_NEEDED	6017
CUSTOM_UNKNOWN_ALGORITHM	6018
CUSTOM_OBD_UNKNOWN_FIRING_ORDER	6023
CUSTOM_OBD_WRONG_FIRING_ORDER	6024
CUSTOM_OBD_IGNITION_MODE	6025
CUSTOM_UNEXPECTED_ENGINE_TYPE	6027
CUSTOM_INVALID_TPS_SETTING	6028
CUSTOM_OBD_NAN_INJECTION	6030
CUSTOM_OBD_NEG_INJECTION	6031
CUSTOM_ZERO_DWELL	6032
CUSTOM_DWELL_TOO_LONG	6033
CUSTOM_SKIPPING_STROKE	6034

Meaning	Fault Code
CUSTOM_OBD_ANALOG_INPUT_NOT_CONFIGURED	6038
CUSTOM_OBD_WRONG_ADC_MODE	6039
CUSTOM_OBD_KNOCK_PROCESSOR	6041
CUSTOM_OBD_LOCAL_FREEZE	6042
CUSTOM_LOGGING_BUFFER_OVERFLOW	6044
CUSTOM_OBD_PIN_CONFLICT	6048
CUSTOM_OBD_LOW_FREQUENCY	6049
CUSTOM_OBD_TS_PAGE_MISMATCH	6052
CUSTOM_OBD_TS_OUTPUT_MISMATCH	6053
CUSTOM_TOO_LONG_CRANKING_FUEL_INJECTION	6054
CUSTOM_INTERPOLATE_NAN	6055
ERROR_HISTO_NAME	6056
CUSTOM_OBD_HIGH_FREQUENCY	6058
CUSTOM_OBD_MMC_START1	6060

Meaning	Fault Code
CUSTOM_OBD_MMC_START2	6061
CUSTOM_PID_DTERM	6097
CUSTOM_DWELL	6098
CUSTOM_TS_OVERFLOW	6099
CUSTOM_ERR_OP_MODE	6100
CUSTOM_ERR_TRIGGER_ZERO	6101
CUSTOM_ERR_6102	6102
CUSTOM_ERR_2ND_WATCHDOG	6103
CUSTOM_ERR_INVALID_INJECTION_MODE	6104
CUSTOM_ERR_WAVE_1	6105
CUSTOM_ERR_WAVE_2	6106
CUSTOM_ERR_TEST_ERROR	6107
CUSTOM_ERR_IGNITION_MODE	6108
CUSTOM_ERR_CAN_CONFIGURATION	6109

Meaning	Fault Code
CUSTOM_ERR_INTERPOLATE	6110
CUSTOM_ERR_NOT_INITIALIZED_TRIGGER	6111
CUSTOM_ERR_MAP_TYPE	6112
CUSTOM_ERR_THERM	6113
CUSTOM_ERR_NATURAL_LOGARITHM_ERROR	6114
CUSTOM_ERR_LOOPED_QUEUE	6115
CUSTOM_ERR_PWM_1	6116
CUSTOM_ERR_PWM_2	6117
CUSTOM_ERR_DWELL_DURATION	6118
CUSTOM_ERR_NO_SHAPE	6119
CUSTOM_ERR_SGTP_ARGUMENT	6121
CUSTOM_ERR_INVALID_PIN	6130
CUSTOM_ERR_6131	6131
CUSTOM_ERR_UNKNOWN_PORT	6132

Meaning	Fault Code
CUSTOM_ERR_PIN_ALREADY_USED_1	6133
CUSTOM_ERR_PIN_ALREADY_USED_2	6134
CUSTOM_ERR_6135	6135
CUSTOM_ERR_TCHARGE_NOT_READY	6136
CUSTOM_ERR_TRIGGER_WAVEFORM_TOO_LONG	6137
CUSTOM_ERR_FUEL_TABLE_NOT_READY	6138
CUSTOM_ERR_TCHARGE_NOT_READY2	6139
CUSTOM_ERR_COMMAND_LOWER_CASE_EXPECTED	6140
CUSTOM_ERR_FLASH_CRC_FAILED	6141
CUSTOM_ERR_NOT_INPUT_PIN	6142
CUSTOM_ERR_SKIPPED_TOOTH_SHAPE	6143
CUSTOM_ERR_UNEXPECTED_SHAFT_EVENT	6144
CUSTOM_ERR_SD_MOUNT_FAILED	6145
CUSTOM_ERR_SD_SEEK_FAILED	6146

Meaning	Fault Code
CUSTOM_ERR_OUT_OF_ORDER	6147
CUSTOM_ERR_T2_CHARGE	6148
CUSTOM_ERR_ASSERT	6500
CUSTOM_ERR_ASSERT_VOID	6501
ERROR_FL_STACK_OVERFLOW	6502
CUSTOM_6503	6503
CUSTOM_FLSTACK	6504
CUSTOM_ERR_NAN_TCHARGE	6505
CUSTOM_EGO_TYPE	6506
CUSTOM_LIST_LOOP	6507
CUSTOM_ERR_LOCK_ISSUE	6508
CUSTOM_CONFIG_NOT_READY	6509
CUSTOM_ERR_TRG_ANGLE_ORDER	6510
CUSTOM_ERR_STATE_NULL	6511

Meaning	Fault Code
CUSTOM_ERR_SAME_ANGLE	6512
ERROR_TRIGGER_DRAMA	6513
CUSTOM_MAP_ANGLE_PARAM	6514
CUSTOM_ERR_DISPLAY_MODE	6515
CUSTOM_ERR_ADC_UNKNOWN_CHANNEL	6516
CUSTOM_ERR_ADC_USED	6517
CUSTOM_ERR_ADC_DEPTH_SLOW	6518
CUSTOM_ERR_ADC_DEPTH_FAST	6519
CUSTOM_ERR_6520	6520
CUSTOM_ERR_6521	6521
CUSTOM_ERR_6522	6522
CUSTOM_ERR_6523	6523
CUSTOM_ERR_UNEXPECTED_SPI	6524
CUSTOM_ERR_EXT_MODE	6525

Meaning	Fault Code
CUSTOM_ERR_TIMER_OVERFLOW	6526
CUSTOM_ERR_6527	6527
CUSTOM_ERR_SCHEDULING_ERROR	6528
CUSTOM_ERR_LOGGING_NOT_READY	6529
ERROR_NAN_FIND_INDEX	6530
ERROR_NULL_BUFFER	6531
CUSTOM_ERR_BUFF_INIT_ERROR	6532
CUSTOM_ERR_INTERPOLATE_PARAM	6533
ERROR_LOGGING_SIZE_CALC	6534
CUSTOM_ERR_ADC_CHANNEL	6535
CUSTOM_ERR_ANGLE	6536
CUSTOM_ERR_LOGGING_NULL	6537
CUSTOM_ERR_PARSING_ERROR	6538
CUSTOM_ERR_INJECTOR_LAG	6539

Meaning	Fault Code
CUSTOM_ERR_AXIS_ORDER	6540
CUSTOM_HW_TIMER	6541
CUSTOM_INJ_DURATION	6542
CUSTOM_ADD_BASE	6543
CUSTOM_ERR_6544	6544
CUSTOM_ERR_6545	6545
CUSTOM_UNEXPECTED_TDC_ANGLE	6546
CUSTOM_INVALID_GLOBAL_OFFSET	6547
CUSTOM_UNEXPECTED_MAP_VALUE	6548
CUSTOM_ERR_6549	6549
CUSTOM_ERR_6550	6550
CUSTOM_TRIGGER_SYNC_ANGLE	6551
CUSTOM_TRIGGER_SYNC_ANGLE2	6552
CUSTOM_ERR_6553	6553

Meaning	Fault Code
CUSTOM_ERR_6554	6554
CUSTOM_ERR_6555	6555
CUSTOM_ERR_6556	6556
CUSTOM_ERR_6557	6557
CUSTOM_ERR_6558	6558
CUSTOM_TRIGGER_SYNC_ANGLE_RANGE	6559
CUSTOM_ERR_TRIGGER_ANGLE_RANGE	6560
CUSTOM_ERR_6561	6561
CUSTOM_ERR_6562	6562
CUSTOM_ERR_6563	6563
CUSTOM_ERR_6564	6564
CUSTOM_ERR_6565	6565
CUSTOM_ERR_6566	6566
CUSTOM_ERR_6567	6567

Meaning	Fault Code
CUSTOM_ERR_6568	6568
CUSTOM_ERR_6569	6569
CUSTOM_ERR_6570	6570
CUSTOM_ERR_6571	6571
CUSTOM_ERR_ARRAY_REMOVE	6572
CUSTOM_ERR_6573	6573
CUSTOM_ERR_6574	6574
CUSTOM_ERR_6575	6575
CUSTOM_ERR_6576	6576
CUSTOM_ERR_6577	6577
CUSTOM_NULL_ENGINE_PTR	6578
CUSTOM_DUTY_TOO_LOW	6579
CUSTOM_ERR_6580	6580
CUSTOM_ERR_6581	6581

Meaning	Fault Code
CUSTOM_ERR_6582	6582
CUSTOM_ERR_6583	6583
CUSTOM_ERR_6584	6584
CUSTOM_ERR_6585	6585
CUSTOM_ERR_6586	6586
CUSTOM_ERR_6587	6587
CUSTOM_NULL_SHAPE	6588
CUSTOM_SPARK_ANGLE_1	6589
CUSTOM_ERR_6590	6590
CUSTOM_ERR_6591	6591
CUSTOM_ERR_6592	6592
CUSTOM_ERR_6593	6593
CUSTOM_SHAPE_LEN_ZERO	6594
CUSTOM_TRIGGER_CYCLE	6595

Meaning	Fault Code
CUSTOM_TRIGGER_CYCLE_NAN	6596
CUSTOM_OMODE_UNDEF	6597
CUSTOM_ERR_6598	6598
CUSTOM_ERR_6599	6599
CUSTOM_ERR_6600	6600
CUSTOM_CONSOLE_TOO_MANY	6601
CUSTOM_APPEND_NULL	6602
CUSTOM_ERR_6603	6603
CUSTOM_ERR_6604	6604
CUSTOM_ERR_6605	6605
CUSTOM_ERR_6606	6606
CUSTOM_APPEND_STACK	6607
CUSTOM_ERR_6608	6608
CUSTOM_ERR_6609	6609

Meaning	Fault Code
CUSTOM_ERR_6610	6610
CUSTOM_ERR_6611	6611
CUSTOM_ERR_6612	6612
CUSTOM_ERR_6613	6613
CUSTOM_ERR_6614	6614
CUSTOM_ERR_6615	6615
CUSTOM_ERR_6616	6616
CUSTOM_ERR_TIMER_STATE	6617
CUSTOM_ERR_6618	6618
CUSTOM_ERR_6619	6619
CUSTOM_APPLY_STACK	6620
CUSTOM_ERR_6621	6621
CUSTOM_ERR_6622	6622
CUSTOM_ERR_6623	6623

Meaning	Fault Code
CUSTOM_ERR_6624	6624
CUSTOM_ERR_6625	6625
CUSTOM_EVENT_6626	6626
CUSTOM_STACK_6627	6627
CUSTOM_ERR_6628	6628
CUSTOM_STACK_6629	6629
CUSTOM_ERR_6030	6630
CUSTOM_ERR_6631	6631
CUSTOM_ERR_6632	6632
CUSTOM_ANGLE_NAN	6633
CUSTOM_ERR_6634	6634
CUSTOM_ERR_6635	6635
CUSTOM_ERR_6636	6636
CUSTOM_CONF_NULL	6637

Meaning	Fault Code
CUSTOM_TRIGGER_EVENT_TYPE	6638
CUSTOM_ERR_6639	6639
CUSTOM_TRIGGER_UNEXPECTED	6640
CUSTOM_ERR_6641	6641
CUSTOM_TRIGGER_STACK	6642
CUSTOM_ERR_6643	6643
CUSTOM_IDLE_WAVE_CNT	6644
CUSTOM_ERR_6645	6645
CUSTOM_ERR_6646	6646
CUSTOM_ERR_6647	6647
CUSTOM_ERR_6648	6648
CUSTOM_ERR_6649	6649
CUSTOM_ERR_6650	6650
CUSTOM_ERR_6651	6651

Meaning	Fault Code
CUSTOM_ERR_6652	6652
CUSTOM_ERR_6653	6653
CUSTOM_ERR_6654	6654
CUSTOM_ERR_6655	6655
CUSTOM_ERR_6656	6656
CUSTOM_ERR_6657	6657
CUSTOM_ERR_6658	6658
CUSTOM_ERR_6659	6659
CUSTOM_ERR_6660	6660
CUSTOM_ERR_6661	6661
CUSTOM_ERR_6662	6662
CUSTOM_ERR_6663	6663
CUSTOM_ERR_6664	6664
CUSTOM_ERR_6665	6665

Meaning	Fault Code
CUSTOM_ERR_6666	6666
CUSTOM_ERR_ADCANCE_CALC_ANGLE	6667
CUSTOM_ERR_ETB_TARGET	6668
CUSTOM_ERR_6669	6669
CUSTOM_ERR_6670	6670
CUSTOM_STACK_ADC_6671	6671
CUSTOM_ERR_6672	6672
CUSTOM_ERR_6673	6673
CUSTOM_STACK_SPI	6674
CUSTOM_VVT_SYNC_POSITION	6675
CUSTOM_STACK_ADC	6676
CUSTOM_IH_STACK	6677
CUSTOM_ERR_6678	6678
CUSTOM_ERR6679	6679

Meaning	Fault Code
CUSTOM_ERR_ANGLE_CR	6680
CUSTOM_DELTA_NOT_POSITIVE	6681
CUSTOM_TIMER_WATCHDOG	6682
CUSTOM_SAME_TWICE	6683
CUSTOM_ERR_6684	6684
CUSTOM_ERR_6685	6685
CUSTOM_ERR_6686	6686
CUSTOM_FIRING_LENGTH	6687
CUSTOM_ADVANCE_SPARK	6688
CUSTOM_ERR_6689	6689
CUSTOM_ERR_MAP_START_ASSERT	6690
CUSTOM_ERR_MAP_AVG_OFFSET	6691
CUSTOM_ERR_MAP_CYL_OFFSET	6692
CUSTOM_ERR_PWM_DUTY_ASSERT	6693

Meaning	Fault Code
CUSTOM_ERR_ZERO_CRANKING_FUEL	6694
CUSTOM_NULL_EXECUTOR	6695
CUSTOM_SLOW_NOT_INVOKED	6696
CUSTOM_PWM_CYCLE_START	6697
CUSTOM_ERR_ARRAY_IS_FULL	6698
CUSTOM_ERR_ARRAY_REMOVE_ERROR	6699
CUSTOM_ERR_6700	6700
CUSTOM_CJ125_0	6700
CUSTOM_CJ125_1	6701
CUSTOM_CJ125_2	6702
CUSTOM_ERR_BENCH_PARAM	6703
CUSTOM_ERR_BOTH_FRONTS_REQUIRED	6704
CUSTOM_TLE8888	6705
CUSTOM_KNOCK_WINDOW	6706

Meaning	Fault Code
CUSTOM_ERR_TIMER_TEST_CALLBACK_NOT_HAPPENED	6707
CUSTOM_ERR_TIMER_TEST_CALLBACK_WRONG_TIME	6708
CUSTOM_ERR_6709	6709
CUSTOM_DUTY_INVALID	6710
CUSTOM_PWM_DUTY_TOO_HIGH	6711
CUSTOM_ERR_PWM_STATE_ASSERT	6712
CUSTOM_ERR_PWM_CALLBACK_ASSERT	6713
CUSTOM_ERR_PWM_SWITCH_ASSERT	6714
CUSTOM_ERR_ZERO_E0_MULT	6715
CUSTOM_ERR_ZERO_E85_MULT	6716
CUSTOM_INVALID_ADC	6720
CUSTOM_INVALID_MODE_SETTING	6721
CUSTOM_ERR_TASK_TIMER_OVERFLOW	6722
CUSTOM_NO_ETB_FOR_IDLE	6723

Meaning	Fault Code
CUSTOM_ERR_TLE8888_RESPONSE	6724
CUSTOM_ERR_CJ125_DIAG	6725
CUSTOM_6726	6726
CUSTOM_VVT_MODE_NOT_SELECTED	6727
CUSTOM_ERR_6728	6728
CUSTOM_ARTIFICIAL_MISFIRE	6729
CUSTOM_INSTANT_MAP_DECODING	6899
STACK_USAGE_COMMUNICATION	6900
STACK_USAGE_MIL	6901
CUSTOM_6902	6902
STACK_USAGE_STATUS	6903
STACK_USAGE_4	6904
CUSTOM_OBD_MMC_ERROR	8000
CUSTOM_ERR_CAN_COMMUNICATION	8900

Meaning	Fault Code
CUSTOM_8901	8901
CUSTOM_ERR_CUSTOM_GAPS_BAD	8999
CUSTOM_ERR_TRIGGER_SYNC	9000
CUSTOM_OBD_TRIGGER_WAVEFORM	9001
CUSTOM_PRIMARY_TOO_MANY_TEETH	9002
CUSTOM_PRIMARY_NOT_ENOUGH_TEETH	9003
CUSTOM_CAM_TOO_MANY_TEETH	9004
CUSTOM_CAM_NOT_ENOUGH_TEETH	9005
CUSTOM_PRIMARY_DOUBLED_EDGE	9006
CUSTOM_PRIMARY_BAD_TOOTH_TIMING	9007
CUSTOM_OBD_SKIPPED_SPARK	9009
CUSTOM_OBD_SKIPPED_FUEL	9010
CUSTOM_RE_ADDING_INTO_EXECUTION_QUEUE	9011
CUSTOM_OUT_OF_ORDER_COIL	9012

Meaning	Fault Code
CUSTOM_TOO_LONG_FUEL_INJECTION	9013

Standard OBD fault codes used by FOME

the meanings of standard OBD codes are available on <http://www.obd-codes.com/faq/obd2-codes-explained.php>

Meaning	Fault Code
OBD_Fuel_Pressure_Sensor_Missing	90
OBD_Mass_or_Volume_Air_Flow_Circuit_Malfunction	100
OBD_Manifold_Absolute_Pressure_Circuit_Malfunction	105
OBD_Map_Timeout	106
OBD_Map_Low	107
OBD_Map_High	108
OBD_ThermistorConfig	111

Meaning	Fault Code
OBD_Iat_Timeout	110
OBD_Iat_Low	112
OBD_Iat_High	113
OBD_Clt_Timeout	115
OBD_Clt_Low	117
OBD_Clt_High	118
OBD_TPS_Configuration	121
OBD_TPS1_Primary_Timeout	120
OBD_TPS1_Primary_Low	122
OBD_TPS1_Primary_High	123
OBD_FlexSensor_Timeout	176
OBD_FlexSensor_Low	178
OBD_FlexSensor_High	179

Meaning	Fault Code
OBD_Injector_Circuit_1	201
OBD_Injector_Circuit_2	202
OBD_Injector_Circuit_3	203
OBD_Injector_Circuit_4	204
OBD_Injector_Circuit_5	205
OBD_Injector_Circuit_6	206
OBD_Injector_Circuit_7	207
OBD_Injector_Circuit_8	208
OBD_Injector_Circuit_9	209
OBD_Injector_Circuit_10	210
OBD_Injector_Circuit_11	211
OBD_Injector_Circuit_12	212
OBD_TPS1_Secondary_Timeout	220

Meaning	Fault Code
OBD_TPS1_Secondary_Low	222
OBD_TPS1_Secondary_High	223
OBD_TPS2_Primary_Timeout	225
OBD_TPS2_Primary_Low	227
OBD_TPS2_Primary_High	228
OBD_Crankshaft_Position_Sensor_A_Circuit_Malfunction	335
OBD_Camshaft_Position_Sensor_Circuit_Range_Performance	341
OBD_Ignition_Circuit_1	351
OBD_Ignition_Circuit_2	352
OBD_Ignition_Circuit_3	353
OBD_Ignition_Circuit_4	354
OBD_Ignition_Circuit_5	355
OBD_Ignition_Circuit_6	356

Meaning	Fault Code
OBD_Ignition_Circuit_7	357
OBD_Ignition_Circuit_8	358
OBD_Ignition_Circuit_9	359
OBD_Ignition_Circuit_10	360
OBD_Ignition_Circuit_11	361
OBD_Ignition_Circuit_12	362
OBD_Oil_Pressure_Sensor_Malfunction	520
OBD_System_Voltage_Malfunction	560
OBD_PCM_Processor_Fault	606
OBD_Throttle_Actuator_Control_Range_Performance_Bank_1	638
OBD_TPS2_Secondary_Timeout	2120
OBD_TPS2_Secondary_Low	2122
OBD_TPS2_Secondary_High	2123

Meaning	Fault Code
OBD_PPS_Primary_Timeout	2125
OBD_PPS_Primary_Low	2127
OBD_PPS_Primary_High	2128
OBD_PPS_Secondary_Timeout	2130
OBD_PPS_Secondary_Low	2132
OBD_PPS_Secondary_High	2133
OBD_TPS1_Correlation	2135
OBD_TPS2_Correlation	2136
OBD_PPS_Correlation	2137
OBD_Vehicle_Speed_SensorB	2158
OBD_Barometric_Press_Circ	2226
OBD_Barometric_Press_Circ_Range_Perf	2227
OBD_WB_FW_Mismatch	2133, actually:

Meaning	Fault Code
	P2231 O2 Sensor Signal Circ Shorted to Heater Circ Bank1 Sensor 1
Wideband_1_Fault	2900
Wideband_2_Fault	2901

Standard OBD fault codes not used by FOME

Code and Meaning
P0001 Fuel Volume Regulator Control Circuit/Open

Code and Meaning

P0002 Fuel Volume Regulator Control Circuit Range/Performance

P0003 Fuel Volume Regulator Control Circuit Low

P0004 Fuel Volume Regulator Control Circuit High

P0005 Fuel Shutoff Valve "A" Control Circuit/Open

P0006 Fuel Shutoff Valve "A" Control Circuit Low

P0007 Fuel Shutoff Valve "A" Control Circuit High

P0008 Engine Positions System Performance Bank 1

P0009 Engine Position System Performance Bank 2

P0010 "A" Camshaft Position Actuator Circuit (Bank 1)

P0001 Fuel Volume Regulator Control Circuit/Open

P0002 Fuel Volume Regulator Control Circuit Range/Performance

P0003 Fuel Volume Regulator Control Circuit Low

P0004 Fuel Volume Regulator Control Circuit High

P0005 Fuel Shutoff Valve "A" Control Circuit/Open

Code and Meaning

P0006 Fuel Shutoff Valve "A" Control Circuit Low

P0007 Fuel Shutoff Valve "A" Control Circuit High

P0008 Engine Positions System Performance Bank 1

P0009 Engine Position System Performance Bank 2

P0010 "A" Camshaft Position Actuator Circuit (Bank 1)

P0011 "A" Camshaft Position - Timing Over-Advanced or System Performance (Bank 1)

P0012 "A" Camshaft Position - Timing Over-Retarded (Bank 1)

P0013 "B" Camshaft Position - Actuator Circuit (Bank 1)

P0014 "B" Camshaft Position - Timing Over-Advanced or System Performance (Bank 1)

P0015 "B" Camshaft Position -Timing Over-Retarded (Bank 1)

P0016 Crankshaft Position - Camshaft Position Correlation (Bank 1 Sensor A)

P0017 Crankshaft Position - Camshaft Position Correlation (Bank 1 Sensor B)

Code and Meaning

P0018 Crankshaft Position - Camshaft Position Correlation (Bank 2 Sensor A)

P0019 Crankshaft Position - Camshaft Position Correlation (Bank 2 Sensor B)

P0020 "A" Camshaft Position Actuator Circuit (Bank 2)

P0021 "A" Camshaft Position - Timing Over-Advanced or System Performance (Bank 2)

P0022 "A" Camshaft Position - Timing Over-Retarded (Bank 2)

P0023 "B" Camshaft Position - Actuator Circuit (Bank 2)

P0024 "B" Camshaft Position - Timing Over-Advanced or System Performance (Bank 2)

P0025 "B" Camshaft Position - Timing Over-Retarded (Bank 2)

P0026 Intake Valve Control Solenoid Circuit Range/Performance Bank 1

P0027 Exhaust Valve Control solenoid Circuit Range/Performance Bank 1

P0028 Intake valve Control Solenoid Circuit Range/Performance Bank 2

P0029 Exhaust Valve Control Solenoid Circuit Range/Performance Bank

Code and Meaning

2

P0030 HO2S Heater Control Circuit (Bank 1 Sensor 1)

P0031 HO2S Heater Control Circuit Low (Bank 1 Sensor 1)

P0032 HO2S Heater Control Circuit High (Bank 1 Sensor 1)

P0033 Turbo Charger Bypass Valve Control Circuit

P0034 Turbo Charger Bypass Valve Control Circuit Low

P0035 Turbo Charger Bypass Valve Control Circuit High

P0036 HO2S Heater Control Circuit (Bank 1 Sensor 2)

P0037 HO2S Heater Control Circuit Low (Bank 1 Sensor 2)

P0038 HO2S Heater Control Circuit High (Bank 1 Sensor 2)

P0039 Turbo/Super Charger Bypass Valve Control Circuit Range/
Performance

P0040 Upstream Oxygen Sensors Swapped From Bank To Bank

P0041 Downstream Oxygen Sensors Swapped From Bank To Bank

P0042 HO2S Heater Control Circuit (Bank 1 Sensor 3)

Code and Meaning

P0043 HO2S Heater Control Circuit Low (Bank 1 Sensor 3)

P0044 HO2S Heater Control Circuit High (Bank 1 Sensor 3)

P0050 HO2S Heater Control Circuit (Bank 2 Sensor 1)

P0051 HO2S Heater Control Circuit Low (Bank 2 Sensor 1)

P0052 HO2S Heater Control Circuit High (Bank 2 Sensor 1)

P0053 HO2S Heater Resistance (Bank 1, Sensor 1)

P0054 HO2S Heater Resistance (Bank 1, Sensor 2)

P0055 HO2S Heater Resistance (Bank 1, Sensor 3)

P0056 HO2S Heater Control Circuit (Bank 2 Sensor 2)

P0057 HO2S Heater Control Circuit Low (Bank 2 Sensor 2)

P0058 HO2S Heater Control Circuit High (Bank 2 Sensor 2)

P0059 HO2S Heater Resistance (Bank 2, Sensor 1)

P0060 HO2S Heater Resistance (Bank 2, Sensor 2)

P0061 HO2S Heater Resistance (Bank 2, Sensor 3)

Code and Meaning

P0062 HO2S Heater Control Circuit (Bank 2 Sensor 3)

P0063 HO2S Heater Control Circuit Low (Bank 2 Sensor 3)

P0064 HO2S Heater Control Circuit High (Bank 2 Sensor 3)

P0065 Air Assisted Injector Control Range/Performance

P0066 Air Assisted Injector Control Circuit or Circuit Low

P0067 Air Assisted Injector Control Circuit High

P0068 MAP/MAF - Throttle Position Correlation

P0069 Manifold Absolute Pressure - Barometric Pressure Correlation

P0070 Ambient Air Temperature Sensor Circuit

P0071 Ambient Air Temperature Sensor Range/Performance

P0072 Ambient Air Temperature Sensor Circuit Low Input

P0073 Ambient Air Temperature Sensor Circuit High Input

P0074 Ambient Air Temperature Sensor Circuit Intermittent

P0075 Intake Valve Control Solenoid Circuit (Bank 1)

Code and Meaning

P0076 Intake Valve Control Solenoid Circuit Low (Bank 1)

/P0077 Intake Valve Control Solenoid Circuit High (Bank 1)

P0078 Exhaust Valve Control Solenoid Circuit (Bank 1)

P0079 Exhaust Valve Control Solenoid Circuit Low (Bank 1)

/P0080 Exhaust Valve Control Solenoid Circuit High (Bank 1)

P0081 Intake valve Control Solenoid Circuit (Bank 2)

P0082 Intake Valve Control Solenoid Circuit Low (Bank 2)

P0083 Intake Valve Control Solenoid Circuit High (Bank 2)

P0084 Exhaust Valve Control Solenoid Circuit (Bank 2)

P0085 Exhaust Valve Control Solenoid Circuit Low (Bank 2)

P0086 Exhaust Valve Control Solenoid Circuit High (Bank 2)

P0087 Fuel Rail/System Pressure - Too Low

P0088 Fuel Rail/System Pressure - Too High

P0089 Fuel Pressure Regulator 1 Performance

Code and Meaning

P0091 Fuel Pressure Regulator 1 Control Circuit Low

P0092 Fuel Pressure Regulator 1 Control Circuit High

P0093 Fuel System Leak Detected - Large Leak

P0094 Fuel System Leak Detected - Small Leak

P0095 Intake Air Temperature Sensor 2 Circuit

P0096 Intake Air Temperature Sensor 2 Circuit Range/Performance

P0097 Intake Air Temperature Sensor 2 Circuit Low

P0098 Intake Air Temperature Sensor 2 Circuit High

P0099 Intake Air Temperature Sensor 2 Circuit Intermittent/Erratic

P0101 Mass or Volume Air Flow Circuit Range/Performance Problem

P0102 Mass or Volume Air Flow Circuit Low Input

P0103 Mass or Volume Air Flow Circuit High Input

P0104 Mass or Volume Air Flow Circuit Intermittent

P0106 Manifold Absolute Pressure/Barometric Pressure Circuit Range/
Performance Problem

Code and Meaning

P0107 Manifold Absolute Pressure/Barometric Pressure Circuit Low Input

P0108 Manifold Absolute Pressure/Barometric Pressure Circuit High Input

P0109 Manifold Absolute Pressure/Barometric Pressure Circuit Intermittent

P0111 Intake Air Temperature Circuit Range/Performance Problem

P0112 Intake Air Temperature Circuit Low Input

P0113 Intake Air Temperature Circuit High Input

P0114 Intake Air Temperature Circuit Intermittent

P0116 Engine Coolant Temperature Circuit Range/Performance Problem

P0117 Engine Coolant Temperature Circuit Low Input

P0118 Engine Coolant Temperature Circuit High Input

P0119 Engine Coolant Temperature Circuit Intermittent

P0122 Throttle Position Sensor/Switch A Circuit Low Input

P0123 Throttle Position Sensor/Switch A Circuit High Input

Code and Meaning

P0124 Throttle Position Sensor/Switch A Circuit Intermittent

P0125 Insufficient Coolant Temperature for Closed Loop Fuel Control

P0126 Insufficient Coolant Temperature for Stable Operation

P0128 Coolant Thermostat (Coolant Temperature Below Thermostat Regulating Temperature)

P0130 02 Sensor Circuit Malfunction (Bank I Sensor 1)

P0131 02 Sensor Circuit Low Voltage (Bank I Sensor I)

P0132 02 Sensor Circuit High Voltage (Bank I Sensor 1)

P0133 02 Sensor Circuit Slow Response (Bank 1 Sensor 1)

P0134 02 Sensor Circuit No Activity Detected (Bank I Sensor 1)

P0135 02 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)

P0136 02 Sensor Circuit Malfunction (Bank I Sensor 2)

P0137 02 Sensor Circuit Low Voltage (Bank I Sensor 2)

P0138 02 Sensor Circuit High Voltage (Bank I Sensor 2)

P0139 02 Sensor Circuit Slow Response (Bank 1 Sensor 2)

Code and Meaning

P0140 02 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)

P0141 02 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)

P0142 02 Sensor Circuit Malfunction (Bank I Sensor 3)

P0143 02 Sensor Circuit Low Voltage (Bank I Sensor 3)

P0144 02 Sensor Circuit High Voltage (Bank I Sensor 3)

P0145 02 Sensor Circuit Slow Response (Bank 1 Sensor 3)

P0146 02 Sensor Circuit No Activity Detected (Bank I Sensor 3)

P0147 02 Sensor Heater Circuit Malfunction (Bank I Sensor 3)

P0150 02 Sensor Circuit Malfunction (Bank 2 Sensor I)

P0151 02 Sensor Circuit Low Voltage (Bank 2 Sensor I)

P0152 02 Sensor Circuit High Voltage (Bank 2 Sensor 1)

P0153 02 Sensor Circuit Slow Response (Bank 2 Sensor 1)

P0154 02 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)

P0155 02 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)

Code and Meaning

P0156 02 Sensor Circuit Malfunction (Bank 2 Sensor 2)

P0157 02 Sensor Circuit Low Voltage (Bank 2 Sensor 2)

P0158 02 Sensor Circuit High Voltage (Bank 2 Sensor 2)

P0159 02 Sensor Circuit Slow Response (Bank 2 Sensor 2)

P0160 02 Sensor Circuit No Activity Detected (Bank 2 Sensor 2)

P0161 02 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)

P0162 02 Sensor Circuit Malfunction (Bank 2 Sensor 3)

P0163 02 Sensor Circuit Low Voltage (Bank 2 Sensor 3)

P0164 02 Sensor Circuit High Voltage (Bank 2 Sensor 3)

P0165 02 Sensor Circuit Slow Response (Bank 2 Sensor 3)

P0166 02 Sensor Circuit No Activity Detected (Bank 2 Sensor 3)

P0167 02 Sensor Heater Circuit Malfunction (Bank 2 Sensor 3)

P0170 Fuel Trim Malfunction (Bank 1)

P0171 System too Lean (Bank 1)

Code and Meaning

P0172 System too Rich (Bank 1)

P0173 Fuel Trim Malfunction (Bank 2)

P0174 System too Lean (Bank 2)

/P0175 System too Rich (Bank 2)

P0176 Fuel Composition Sensor Circuit Malfunction

P0177 Fuel Composition Sensor Circuit Range/Performance

P0178 Fuel Composition Sensor Circuit Low Input

P0179 Fuel Composition Sensor Circuit High Input

P0180 Fuel Temperature Sensor A Circuit Malfunction

P0181 Fuel Temperature Sensor A Circuit Range/Performance

P0182 Fuel Temperature Sensor A Circuit Low Input

P0183 Fuel Temperature Sensor A Circuit High Input

P0184 Fuel Temperature Sensor A Circuit Intermittent

P0185 Fuel Temperature Sensor B Circuit Malfunction

Code and Meaning

P0186 Fuel Temperature Sensor B Circuit Range/Performance

P0187 Fuel Temperature Sensor B Circuit Low Input

P0188 Fuel Temperature Sensor B Circuit High Input

P0189 Fuel Temperature Sensor B Circuit Intermittent

P0190 Fuel Rail Pressure Sensor Circuit Malfunction

P0191 Fuel Rail Pressure Sensor Circuit Range/Performance

P0192 Fuel Rail Pressure Sensor Circuit Low Input

P0193 Fuel Rail Pressure Sensor Circuit High Input

P0194 Fuel Rail Pressure Sensor Circuit Intermittent

P0195 Engine Oil Temperature Sensor Malfunction

P0196 Engine Oil Temperature Sensor Range/Performance

P0197 Engine Oil Temperature Sensor Low

P0198 Engine Oil Temperature Sensor High

P0199 Engine Oil Temperature Sensor Intermittent

Code and Meaning

P0200 Injector Circuit Malfunction

P0213 Cold Start Injector 1 Malfunction

P0214 Cold Start Injector 2 Malfunction

P0215 Engine Shutoff Solenoid Malfunction

P0216 Injection Timing Control Circuit Malfunction

P0217 Engine Overtemp Condition

P0218 Transmission Over Temperature Condition

P0219 Engine Overspeed Condition

P0220 Throttle/Petal Position Sensor/Switch B Circuit Malfunction

P0221 Throttle/Petal Position Sensor/Switch B Circuit Range/
Performance Problem

P0222 Throttle/Petal Position Sensor/Switch B Circuit Low Input

P0223 Throttle/Petal Position Sensor/Switch B Circuit High Input

P0224 Throttle/Petal Position Sensor/Switch B Circuit Intermittent

P0225 Throttle/Petal Position Sensor/Switch C Circuit Malfunction

Code and Meaning

P0226 Throttle/Petal Position Sensor/Switch C Circuit Range/
Performance Problem

P0227 Throttle/Petal Position Sensor/Switch C Circuit Low Input

P0228 Throttle/Petal Position Sensor/Switch C Circuit High Input

P0229 Throttle/Petal Position Sensor/Switch C Circuit Intermittent

P0230 Fuel Pump Primary Circuit Malfunction

P0231 Fuel Pump Secondary Circuit Low

P0232 Fuel Pump Secondary Circuit High

P0233 Fuel Pump Secondary Circuit Intermittent

P0234 Engine Turbocharger/Supercharger Overboost Condition

P0235 Turbocharger Boost Sensor A Circuit Malfunction

P0236 Turbocharger Boost Sensor A Circuit Range/Performance

P0237 Turbocharger Boost Sensor A Circuit Low

P0238 Turbocharger Boost Sensor A Circuit High

P0239 Turbocharger Boost Sensor B Malfunction

Code and Meaning

P0240 Turbocharger Boost Sensor B Circuit Range/Performance

P0241 Turbocharger Boost Sensor B Circuit Low

P0242 Turbocharger Boost Sensor B Circuit High

P0243 Turbocharger Wastegate Solenoid A Malfunction

P0244 Turbocharger Wastegate Solenoid A Range/Performance

P0245 Turbocharger Wastegate Solenoid A Low

P0246 Turbocharger Wastegate Solenoid A High

P0247 Turbocharger Wastegate Solenoid B Malfunction

P0248 Turbocharger Wastegate Solenoid B Range/Performance

P0249 Turbocharger Wastegate Solenoid B Low

P0250 Turbocharger Wastegate Solenoid B High

P0251 Injection Pump Fuel Metering Control "A" Malfunction (Cam/Rotor/Injector)

P0252 Injection Pump Fuel Metering Control "A" Range/Performance (Cam/Rotor/Injector)

Code and Meaning

P0253 Injection Pump Fuel Metering Control "A" Low (Cam/Rotor/Injector)

P0254 Injection Pump Fuel Metering Control "A" High (Cam/Rotor/Injector)

P0255 Injection Pump Fuel Metering Control "A" Intermittent (Cam/Rotor/Injector)

P0256 Injection Pump Fuel Metering Control "B" Malfunction (Cam/Rotor/Injector)

P0257 Injection Pump Fuel Metering Control "B" Range/Performance Injector)

P0258 Injection Pump Fuel Metering Control "B" Low (Cam/R

P0259 Injection Pump Fuel Metering Control "B" High (Cam/R

P0260 Injection Pump Fuel Metering Control "B" Intermittent Injector)

P0261 Cylinder I Injector Circuit Low

P0262 Cylinder I Injector Circuit High

P0263 Cylinder I Contribution/Balance Fault

P0264 Cylinder 2 Injector Circuit Low

Code and Meaning

P0265 Cylinder 2 Injector Circuit High

P0266 Cylinder 2 Contribution/Balance Fault

P0267 Cylinder 3 Injector Circuit Low

P0268 Cylinder 3 Injector Circuit High

P0269 Cylinder 3 Contribution/Balance Fault

P0270 Cylinder 4 Injector Circuit Low

P0271 Cylinder 4 Injector Circuit High

P0272 Cylinder 4 Contribution/Balance Fault

P0273 Cylinder 5 Injector Circuit Low

P0274 Cylinder 5 Injector Circuit High

P0275 Cylinder 5 Contribution/Balance Fault

P0276 Cylinder 6 Injector Circuit Low

P0277 Cylinder 6 Injector Circuit High

P0278 Cylinder 6 Contribution/Balance Fault

Code and Meaning

P0279 Cylinder 7 Injector Circuit Low

P0280 Cylinder 7 Injector Circuit High

P0281 Cylinder 7 Contribution/Balance Fault

P0282 Cylinder 8 Injector Circuit Low

P0283 Cylinder 8 Injector Circuit High

P0284 Cylinder 8 Contribution/Balance Fault

P0285 Cylinder 9 Injector Circuit Low

P0286 Cylinder 9 Injector Circuit High

P0287 Cylinder 9 Contribution/Balance Fault

P0288 Cylinder 10 Injector Circuit Low

P0289 Cylinder 10 Injector Circuit High

P0290 Cylinder 10 Contribution/Balance Fault

P0291 Cylinder 11 Injector Circuit Low

P0292 Cylinder 11 Injector Circuit High

Code and Meaning

P0293 Cylinder 11 Contribution/Balance Fault

P0294 Cylinder 12 Injector Circuit Low

P0295 Cylinder 12 Injector Circuit High

P0296 Cylinder 12 Contribution/Range Fault

P0297 Vehicle Overspeed Condition

P0298 Engine Oil Over Temperature Condition

P0299 Turbocharger/Supercharger "A" Underboost Condition

P0300 Random/Multiple Cylinder Misfire Detected

P0301 Cylinder 1 Misfire Detected

P0302 Cylinder 2 Misfire Detected

P0303 Cylinder 3 Misfire Detected

P0304 Cylinder 4 Misfire Detected

P0305 Cylinder 5 Misfire Detected

P0306 Cylinder 6 Misfire Detected

Code and Meaning

P0307 Cylinder 7 Misfire Detected

P0308 Cylinder 8 Misfire Detected

P0309 Cylinder 9 Misfire Detected

P0310 Cylinder 10 Misfire Detected

P0311 Cylinder 11 Misfire Detected

P0312 Cylinder 12 Misfire Detected

P0313 Misfire Detected with Low Fuel

P0314 Single Cylinder Misfire (Cylinder not Specified)

P0315 Crankshaft Position System Variation Not Learned

P0316 Misfire Detected On Startup (First 1000 Revolutions)

P0317 Rough Road Hardware Not Present

P0318 Rough Road Sensor A Signal Circuit

P0319 Rough Road Sensor B Signal Circuit

P0320 Ignition/Distributor Engine Speed Input Circuit Malfunction

Code and Meaning

P0321 Ignition/Distributor Engine Speed Input Circuit Range/Performance

P0322 Ignition/Distributor Engine Speed Input Circuit No Signal

P0323 Ignition/Distributor Engine Speed Input Circuit Intermittent

P0324 Knock Control System Error

P0325 Knock Sensor 1 Circuit Malfunction (Bank 1 or Single Sensor)

P0326 Knock Sensor 1 Circuit Range/Performance (Bank 1 or Single Sensor)

P0327 Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)

P0328 Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)

P0329 Knock Sensor 1 Circuit Intermittent (Bank 1 or Single Sensor)

P0330 Knock Sensor 2 Circuit Malfunction (Bank 2)

P0331 Knock Sensor 2 Circuit Range/Performance (Bank 2)

P0332 Knock Sensor 2 Circuit Low Input (Bank 2)

P0333 Knock Sensor 2 Circuit High Input (Bank 2)

Code and Meaning

P0334 Knock Sensor 2 Circuit Intermittent (Bank 2)

P0336 Crankshaft Position Sensor A Circuit Range/Performance

P0337 Crankshaft Position Sensor A Circuit Low Input

P0338 Crankshaft Position Sensor A Circuit High Input

P0339 Crankshaft Position Sensor A Circuit Intermittent

P0340 Camshaft Position Sensor Circuit Malfunction

P0342 Camshaft Position Sensor Circuit Low Input

P0343 Camshaft Position Sensor Circuit High Input

P0344 Camshaft Position Sensor Circuit Intermittent

P0345 Camshaft Position Sensor A Circuit Malfunction (Bank 2)

P0346 Camshaft Position Sensor A Circuit Range/Performance (Bank 2)

P0347 Camshaft Position Sensor A Circuit Low Input (Bank 2)

P0348 Camshaft Position Sensor A Circuit High Input (Bank 2)

P0349 Camshaft Position Sensor A Circuit Intermittent (Bank 2)

Code and Meaning

P0350 Ignition Coil Primary/Secondary Circuit Malfunction

P0363 Misfire Detected - Fueling Disabled

P0364 Reserved

P0365 Camshaft Position Sensor "B" Circuit (Bank 1)

P0366 Camshaft Position Sensor "B" Circuit Range/Performance (Bank 1)

P0367 Camshaft Position Sensor "B" Circuit Low (Bank 1)

P0368 Camshaft Position Sensor "B" Circuit High (Bank 1)

P0369 Camshaft Position Sensor "B" Circuit Intermittent (Bank 1)

P0370 Timing Reference High Resolution Signal A Malfunction

P0371 Timing Reference High Resolution Signal A Too Many Pulses

P0372 Timing Reference High Resolution Signal A Too Few Pulses

P0373 Timing Reference High Resolution Signal A Intermittent/Erratic Pulses

P0374 Timing Reference High Resolution Signal A No Pulses

Code and Meaning

P0375 Timing Reference High Resolution Signal B Malfunction

P0376 Timing Reference High Resolution Signal B Too Many Pulses

P0377 Timing Reference High Resolution Signal B Too Few Pulses

P0378 Timing Reference High Resolution Signal B Intermittent/Erratic Pulses

P0379 Timing Reference High Resolution Signal B No Pulses

P0380 Glow Plug/Heater Circuit "A" Malfunction

P0381 Glow Plug/Heater Indicator Circuit Malfunction

P0382 Exhaust Gas Recirculation Flow Malfunction

P0383 Glow Plug Control Module Control Circuit Low

P0384 Glow Plug Control Module Control Circuit High

P0385 Crankshaft Position Sensor B Circuit Malfunction

P0386 Crankshaft Position Sensor B Circuit Range/Performance

P0387 Crankshaft Position Sensor B Circuit Low Input

P0388 Crankshaft Position Sensor B Circuit High Input

Code and Meaning

P0389 Crankshaft Position Sensor B Circuit Intermittent

P0390 Camshaft Position Sensor "B" Circuit (Bank 2)

P0391 Camshaft Position Sensor "B" Circuit Range/Performance (Bank 2)

P0392 Camshaft Position Sensor "B" Circuit Low (Bank 2)

P0393 Camshaft Position Sensor "B" Circuit High (Bank 2)

P0394 Camshaft Position Sensor "B" Circuit Intermittent (Bank 2)

DTC Codes - P0400-P0499 - Auxiliary Emissions Controls

P0400 Exhaust Gas Recirculation Flow Malfunction

P0401 Exhaust Gas Recirculation Flow Insufficient Detected

P0402 Exhaust Gas Recirculation Flow Excessive Detected

P0403 Exhaust Gas Recirculation Circuit Malfunction

P0404 Exhaust Gas Recirculation Circuit Range/Performance

P0405 Exhaust Gas Recirculation Sensor A Circuit Low

P0406 Exhaust Gas Recirculation Sensor A Circuit High

Code and Meaning

P0407 Exhaust Gas Recirculation Sensor B Circuit Low

P0408 Exhaust Gas Recirculation Sensor B Circuit High

P0409 Exhaust Gas Recirculation Sensor "A" Circuit

P0410 Secondary Air Injection System Malfunction

P0411 Secondary Air Injection System Incorrect Flow Detected

P0412 Secondary Air Injection System Switching Valve A Circuit Malfunction

P0413 Secondary Air Injection System Switching Valve A Circuit Open

P0414 Secondary Air Injection System Switching Valve A Circuit Shorted

P0415 Secondary Air Injection System Switching Valve B Circuit Malfunction

P0416 Secondary Air Injection System Switching Valve B Circuit Open

P0417 Secondary Air Injection System Switching Valve B Circuit Shorted

P0418 Secondary Air Injection System Relay "A" Circuit Malfunction

Code and Meaning

P0419 Secondary Air Injection System Relay "B" Circuit Malfunction

P0420 Catalyst System Efficiency Below Threshold (Bank 1)

P0421 Warm Up Catalyst Efficiency Below Threshold (Bank 1)

P0422 Main Catalyst Efficiency Below Threshold (Bank 1)

P0423 Heated Catalyst Efficiency Below Threshold (Bank 1)

P0424 Heated Catalyst Temperature Below Threshold (Bank 1)

P0424 Heated Catalyst Temperature Below Threshold (Bank 1)

P0425 Catalyst Temperature Sensor (Bank 1)

P0426 Catalyst Temperature Sensor Range/Performance (Bank 1)

P0427 Catalyst Temperature Sensor Low (Bank 1)

P0428 Catalyst Temperature Sensor High (Bank 1)

P0429 Catalyst Heater Control Circuit

P0430 Catalyst System Efficiency Below Threshold (Bank 2)

P0431 Warm Up Catalyst Efficiency Below Threshold (Bank 2)

Code and Meaning

P0432 Main Catalyst Efficiency Below Threshold (Bank 2)

P0433 Heated Catalyst Efficiency Below Threshold (Bank 2)

P0434 Heated Catalyst Temperature Below Threshold (Bank 2)

P0435 Catalyst Temperature Sensor (Bank 2)

P0436 Catalyst Temperature Sensor Range/Performance (Bank 2)

P0437 Catalyst Temperature Sensor Low (Bank 2)

P0438 Catalyst Temperature Sensor High (Bank 2)

P0439 Catalyst Heater Control Circuit

P0440 Evaporative Emission Control System Malfunction

P0441 Evaporative Emission Control System Incorrect Purge Flow

P0442 Evaporative Emission Control System Leak Detected (small leak)

P0443 Evaporative Emission Control System Purge Control Valve Circuit

P0444 Evaporative Emission Control System Purge Control Valve Circuit Open

Code and Meaning

P0445 Evaporative Emission Control System Purge Control Valve Circuit Shorted

P0446 Evaporative Emission Control System Vent Control Circuit Malfunction

P0447 Evaporative Emission Control System Vent Control Circuit Open

P0448 Evaporative Emission Control System Vent Control Circuit Shorted

P0449 Evaporative Emission Control System Vent Valve/Solenoid Circuit Malfunction

P0450 Evaporative Emission Control System Pressure Sensor Malfunction

P0451 Evaporative Emission Control System Pressure Sensor Range/Performance

P0452 Evaporative Emission Control System Pressure Sensor Low Input

P0453 Evaporative Emission Control System Pressure Sensor High Input

P0454 Evaporative Emission Control System Pressure Sensor Intermittent

Code and Meaning

P0455 Evaporative Emission Control System Leak Detected (gross leak)

P0456 Evaporative Emissions System Small Leak Detected

P0457 Evaporative Emission Control System Leak Detected

P0458 Evaporative Emission System Purge Control Valve Circuit Low

P0459 Evaporative Emission System Purge Control Valve Circuit High

P0460 Fuel Level Sensor Circuit Malfunction

P0461 Fuel Level Sensor Circuit Range/Performance

P0462 Fuel Level Sensor Circuit Low Input

P0463 Fuel Level Sensor Circuit High Input

P0464 Fuel Level Sensor Circuit Intermittent

P0465 Purge Flow Sensor Circuit Malfunction

P0466 Purge Flow Sensor Circuit Range/Performance

P0467 Purge Flow Sensor Circuit Low Input

P0468 Purge Flow Sensor Circuit High Input

Code and Meaning

P0469 Purge Flow Sensor Circuit Intermittent

P0470 Exhaust Pressure Sensor Malfunction

P0471 Exhaust Pressure Sensor Range/Performance

P0472 Exhaust Pressure Sensor Low

P0473 Exhaust Pressure Sensor High

P0474 Exhaust Pressure Sensor Intermittent

P0475 Exhaust Pressure Control Valve Malfunction

P0476 Exhaust Pressure Control Valve Range/Performance

P0477 Exhaust Pressure Control Valve Low

P0478 Exhaust Pressure Control Valve High

P0479 Exhaust Pressure Control Valve Intermittent

P0480 Cooling Fan 1 Control Circuit Malfunction

P0481 Cooling Fan 2 Control Circuit Malfunction

P0482 Cooling Fan 3 Control Circuit Malfunction

Code and Meaning

P0483 Cooling Fan Rationality Check Malfunction

P0484 Cooling Fan Circuit Over Current

P0485 Cooling Fan Power/Ground Circuit Malfunction

P0486 Exhaust Gas Recirculation Sensor "B" Circuit

P0487 Exhaust Gas Recirculation Throttle Control Circuit "A" Open

P0488 Exhaust Gas Recirculation Throttle Control Circuit "A" Range/
Performance

P0489 Exhaust Gas Recirculation "A" Control Circuit Low

P0490 Exhaust Gas Recirculation "A" Control Circuit High

P0491 Secondary Air Injection System Insufficient Flow Bank 1

P0492 Secondary Air Injection System Insufficient Flow Bank 2

P0493 Fan Overspeed

P0494 Fan Speed Low

P0495 Fan Speed High

P0496 EVAP Flow During A Non-Purge Condition

Code and Meaning

P0497 Evaporative Emission System Low Purge Flow

P0498 Evaporative Emission System Vent Valve Control Circuit Low

P0499 Evaporative Emission System Vent Valve Control Circuit High

DTC Codes - P0500-P0599 - Vehicle Speed Controls and Idle Control System

P0500 Vehicle Speed Sensor Malfunction

P0501 Vehicle Speed Sensor Range/Performance

P0502 Vehicle Speed Sensor Low Input

P0503 Vehicle Speed Sensor Intermittent/Erratic/High

P0504 Brake Switch "A"/"B" Correlation

P0505 Idle Control System Malfunction

P0506 Idle Control System RPM Lower Than Expected

P0507 Idle Control System RPM Higher Than Expected

P0508 Idle Air Control System Circuit Low

P0509 Idle Air Control System Circuit High

Code and Meaning

P0510 Closed Throttle Position Switch Malfunction

P0511 Idle Air Control Circuit

P0512 Starter Request Circuit

P0513 Incorrect Immobilizer Key

P0514 Battery Temperature Sensor Circuit Range/Performance

P0515 Battery Temperature Sensor Circuit

P0516 Battery Temperature Sensor Circuit Low

P0517 Battery Temperature Sensor Circuit High

P0518 Idle Air Control Circuit Intermittent

P0519 Idle Air Control System Performance

P0520 Engine Oil Pressure Sensor/Switch Circuit Malfunction

P0521 Engine Oil Pressure Sensor/Switch Circuit Range/Performance

P0522 Engine Oil Pressure Sensor/Switch Circuit Low Voltage

P0523 Engine Oil Pressure Sensor/Switch Circuit High Voltage

Code and Meaning

P0524 Engine Oil Pressure Too Low

P0525 Cruise Control Servo Control Circuit Range/Performance

P0526 Fan Speed Sensor Circuit

P0527 Fan Speed Sensor Circuit Range/Performance

P0528 Fan Speed Sensor Circuit No Signal

P0529 Fan Speed Sensor Circuit Intermittent

P0530 A/C Refrigerant Pressure Sensor Circuit Malfunction

P0531 A/C Refrigerant Pressure Sensor Circuit Range/Performance

P0532 A/C Refrigerant Pressure Sensor Circuit Low Input

P0533 A/C Refrigerant Pressure Sensor Circuit High Input

P0534 Air Conditioner Refrigerant Charge Loss

P0535 A/C Evaporator Temperature Sensor Circuit

P0536 A/C Evaporator Temperature Sensor Circuit Range/Performance

P0537 A/C Evaporator Temperature Sensor Circuit Low

Code and Meaning

P0538 A/C Evaporator Temperature Sensor Circuit High

P0539 A/C Evaporator Temperature Sensor Circuit Intermittent

P0540 Intake Air Heater "A" Circuit

P0541 Intake Air Heater "A" Circuit Low

P0542 Intake Air Heater "A" Circuit High

P0543 Intake Air Heater "A" Circuit Open

P0544 Exhaust Gas Temperature Sensor Circuit

P0545 Exhaust Gas Temperature Sensor Circuit Low

P0546 Exhaust Gas Temperature Sensor Circuit High

P0547 Exhaust Gas Temperature Sensor Circuit

P0548 Exhaust Gas Temperature Sensor Circuit Low

P0549 Exhaust Gas Temperature Sensor Circuit High

P0550 Power Steering Pressure Sensor Circuit Malfunction

P0551 Power Steering Pressure Sensor Circuit Range/Performance

Code and Meaning

P0552 Power Steering Pressure Sensor Circuit Low Input

P0553 Power Steering Pressure Sensor Circuit High Input

P0554 Power Steering Pressure Sensor Circuit Intermittent

P0555 Brake Booster Pressure Sensor Circuit

P0556 Brake Booster Pressure Sensor Circuit Range/Performance

P0557 Brake Booster Pressure Sensor Circuit Low

P0558 Brake Booster Pressure Sensor Circuit High

P0559 Brake Booster Pressure Sensor Circuit Intermittent

P0561 System Voltage Unstable

P0562 System Voltage Low

P0563 System Voltage High

P0564 Cruise Control Multi-Function Input "A" Circuit

P0565 Cruise Control On Signal Malfunction

P0566 Cruise Control Off Signal Malfunction

Code and Meaning

P0567 Cruise Control Resume Signal Malfunction

P0568 Cruise Control Set Signal Malfunction

P0569 Cruise Control Coast Signal Malfunction

P0570 Cruise Control Accel Signal Malfunction

P0571 Cruise Control/Brake Switch A Circuit Malfunction

P0572 Cruise Control/Brake Switch A Circuit Low

P0573 Cruise Control/Brake Switch A Circuit High

P0574 Cruise Control System - Vehicle Speed Too High

P0575 Cruise Control Input Circuit

P0576 Cruise Control Input Circuit Low

P0577 Cruise Control Input Circuit High

P0578 Cruise Control Multi-Function Input "A" Circuit Stuck

P0579 Cruise Control Multi-Function Input "A" Circuit Range/
Performance

P0580 Cruise Control Multi-Function Input "A" Circuit Low

Code and Meaning

P0581 Cruise Control Multi-Function Input "A" Circuit High

P0582 Cruise Control Vacuum Control Circuit/Open

P0583 Cruise Control Vacuum Control Circuit Low

P0584 Cruise Control Vacuum Control Circuit High

P0585 Cruise Control Multi-Function Input "A"/"B" Correlation

P0586 Cruise Control Vent Control Circuit/Open

P0587 Cruise Control Vent Control Circuit Low

P0588 Cruise Control Vent Control Circuit High

P0589 Cruise Control Multi-Function Input "B" Circuit

P0590 Cruise Control Multi-Function Input "B" Circuit Stuck

P0591 Cruise Control Multi-Function Input "B" Circuit Range/
Performance

P0592 Cruise Control Multi-Function Input "B" Circuit Low

P0593 Cruise Control Multi-Function Input "B" Circuit High

P0594 Cruise Control Servo Control Circuit/Open

Code and Meaning

P0595 Cruise Control Servo Control Circuit Low

P0596 Cruise Control Servo Control Circuit High

P0597 Thermostat Heater Control Circuit/Open

P0598 Thermostat Heater Control Circuit Low

P0599 Thermostat Heater Control Circuit High

P0600 Serial Communication Link Malfunction

P0601 Internal Control Module Memory Check Sum Error

P0602 Control Module Programming Error

P0603 Internal Control Module Keep Alive Memory (KAM) Error

P0604 Internal Control Module Random Access Memory (RAM) Error

P0605 Internal Control Module Read Only Memory (ROM) Error

P0607 Control Module Performance

P0608 Control Module VSS Output "A" Malfunction

P0609 Control Module VSS Output "B" Malfunction

Code and Meaning

P0610 Control Module Vehicle Options Error

P0611 Fuel Injector Control Module Performance

P0612 Fuel Injector Control Module Relay Control

P0613 TCM Processor

P0614 ECM / TCM Incompatible

P0615 Starter Relay Circuit

P0616 Starter Relay Circuit Low

P0617 Starter Relay Circuit High

P0618 Alternative Fuel Control Module KAM Error

P0619 Alternative Fuel Control Module RAM/ROM Error

P0620 Generator Control Circuit Malfunction

P0621 Generator Lamp "L" Control Circuit Malfunction

P0622 Generator Field "F" Control Circuit Malfunction

P0623 Generator Lamp Control Circuit

Code and Meaning

P0624 Fuel Cap Lamp Control Circuit

P0625 Generator Field/F Terminal Circuit Low

P0626 Generator Field/F Terminal Circuit High

P0627 Fuel Pump "A" Control Circuit /Open

P0628 Fuel Pump "A" Control Circuit Low

P0629 Fuel Pump "A" Control Circuit High

P0630 VIN Not Programmed or Incompatible - ECM/PCM

P0631 VIN Not Programmed or Incompatible - TCM

P0632 Odometer Not Programmed - ECM/PCM

P0633 Immobilizer Key Not Programmed - ECM/PCM

P0634 PCM/ECM/TCM Internal Temperature Too High

P0635 Power Steering Control Circuit

P0636 Power Steering Control Circuit Low

P0637 Power Steering Control Circuit High

Code and Meaning

P0639 Throttle Actuator Control Range/Performance (Bank 2)

P0640 Intake Air Heater Control Circuit

P0641 Sensor Reference Voltage "A" Circuit/Open

P0642 Sensor Reference Voltage "A" Circuit Low

P0643 Sensor Reference Voltage "A" Circuit High

P0644 Driver Display Serial Communication Circuit

P0645 A/C Clutch Relay Control Circuit

P0646 A/C Clutch Relay Control Circuit Low

P0647 A/C Clutch Relay Control Circuit High

P0648 Immobilizer Lamp Control Circuit

P0649 Speed Control Lamp Control Circuit

P0650 Malfunction Indicator Lamp (MIL) Control Circuit Malfunction

P0651 Sensor Reference Voltage "B" Circuit/Open

P0652 Sensor Reference Voltage "B" Circuit Low

Code and Meaning

P0653 Sensor Reference Voltage "B" Circuit High

P0654 Engine RPM Output Circuit Malfunction

P0655 Engine Hot Lamp Output Control Circuit Malfunction

P0656 Fuel Level Output Circuit Malfunction

P0657 Actuator Supply Voltage "A" Circuit/Open

P0658 Actuator Supply Voltage "A" Circuit Low

P0659 Actuator Supply Voltage "A" Circuit High

P0660 Intake Manifold Tuning Valve Control Circuit/Open Bank 1

P0661 Intake Manifold Tuning Valve Control Circuit Low Bank 1

P0662 Intake Manifold Tuning Valve Control Circuit High Bank 1

P0663 Intake Manifold Tuning Valve Control Circuit/Open Bank 2

P0664 Intake Manifold Tuning Valve Control Circuit Low Bank 2

P0665 Intake Manifold Tuning Valve Control Circuit High Bank 2

P0666 PCM/ECM/TCM Internal Temperature Sensor Circuit

Code and Meaning

P0667 PCM/ECM/TCM Internal Temperature Sensor Range/Performance

P0668 PCM/ECM/TCM Internal Temperature Sensor Circuit Low

P0669 PCM/ECM/TCM Internal Temperature Sensor Circuit High

P0670 Glow Plug Module Control Circuit

P0671 Cylinder 1 Glow Plug Circuit

P0672 Cylinder 2 Glow Plug Circuit

P0673 Cylinder 3 Glow Plug Circuit

P0674 Cylinder 4 Glow Plug Circuit

P0675 Cylinder 5 Glow Plug Circuit

P0676 Cylinder 6 Glow Plug Circuit

P0677 Cylinder 7 Glow Plug Circuit

P0678 Cylinder 8 Glow Plug Circuit

P0679 Cylinder 9 Glow Plug Circuit

P0680 Cylinder 10 Glow Plug Circuit

Code and Meaning

P0681 Cylinder 11 Glow Plug Circuit

P0682 Cylinder 12 Glow Plug Circuit

P0683 Glow Plug Control Module to PCM Communication Circuit

P0684 Glow Plug Control Module to PCM Communication Circuit Range/
Performance

P0685 ECM/PCM Power Relay Control Circuit /Open

P0686 ECM/PCM Power Relay Control Circuit Low

P0687 ECM/PCM Power Relay Control Circuit High

P0688 ECM/PCM Power Relay Sense Circuit /Open

P0689 ECM/PCM Power Relay Sense Circuit Low

P0690 ECM/PCM Power Relay Sense Circuit High

P0691 Fan 1 Control Circuit Low P0692 Fan 1 Control Circuit High

P0693 Fan 2 Control Circuit Low

P0694 Fan 2 Control Circuit High

P0695 Fan 3 Control Circuit Low

Code and Meaning

P0696 Fan 3 Control Circuit High

P0697 Sensor Reference Voltage "C" Circuit/Open

P0698 Sensor Reference Voltage "C" Circuit Low

P0699 Sensor Reference Voltage "C" Circuit High

P0700 Transmission Control System Malfunction

P0701 Transmission Control System Range/Performance

P0702 Transmission Control System Electrical

P0703 Torque Converter/Brake Switch B Circuit Malfunction

P0704 Clutch Switch Input Circuit Malfunction

P0705 Transmission Range Sensor Circuit malfunction (PRNDL Input)

P0706 Transmission Range Sensor Circuit Range/Performance

P0707 Transmission Range Sensor Circuit Low Input

P0708 Transmission Range Sensor Circuit High Input

P0709 Transmission Range Sensor Circuit Intermittent

Code and Meaning

P0710 Transmission Fluid Temperature Sensor Circuit Malfunction

P0711 Transmission Fluid Temperature Sensor Circuit Range/
Performance

P0712 Transmission Fluid Temperature Sensor Circuit Low Input

P0713 Transmission Fluid Temperature Sensor Circuit High Input

P0714 Transmission Fluid Temperature Sensor Circuit Intermittent

P0715 Input/Turbine Speed Sensor Circuit Malfunction

P0716 Input/Turbine Speed Sensor Circuit Range/Performance

P0717 Input/Turbine Speed Sensor Circuit No Signal

P0718 Input/Turbine Speed Sensor Circuit Intermittent

P0719 Torque Converter/Brake Switch B Circuit Low

P0720 Output Speed Sensor Circuit Malfunction

P0721 Output Speed Sensor Range/Performance

P0722 Output Speed Sensor No Signal

P0723 Output Speed Sensor Intermittent

Code and Meaning

P0724 Torque Converter/Brake Switch B Circuit High

P0725 Engine Speed input Circuit Malfunction

P0726 Engine Speed Input Circuit Range/Performance

P0727 Engine Speed Input Circuit No Signal

P0728 Engine Speed Input Circuit Intermittent

P0729 Gear 6 Incorrect Ratio

P0730 Incorrect Gear Ratio

P0731 Gear 1 Incorrect ratio

P0732 Gear 2 Incorrect ratio

P0733 Gear 3 Incorrect ratio

P0734 Gear 4 Incorrect ratio

P0735 Gear 5 Incorrect ratio

P0736 Reverse incorrect gear ratio

P0737 TCM Engine Speed Output Circuit

Code and Meaning

P0738 TCM Engine Speed Output Circuit Low

P0739 TCM Engine Speed Output Circuit High

P0740 Torque Converter Clutch Circuit Malfunction

P0741 Torque Converter Clutch Circuit Performance or Stuck Off

P0742 Torque Converter Clutch Circuit Stock On

P0743 Torque Converter Clutch Circuit Electrical

P0744 Torque Converter Clutch Circuit Intermittent

P0745 Pressure Control Solenoid Malfunction

P0746 Pressure Control Solenoid Performance or Stuck Off

P0747 Pressure Control Solenoid Stuck On

P0748 Pressure Control Solenoid Electrical

P0749 Pressure Control Solenoid Intermittent

P0750 Shift Solenoid A Malfunction

P0751 Shift Solenoid A Performance or Stuck Off

Code and Meaning

P0752 Shift Solenoid A Stuck On

P0753 Shift Solenoid A Electrical

P0754 Shift Solenoid A Intermittent

P0755 Shift Solenoid B Malfunction

P0756 Shift Solenoid B Performance or Stock Off

P0757 Shift Solenoid B Stuck On

P0758 Shift Solenoid B Electrical

P0759 Shift Solenoid B Intermittent

P0760 Shift Solenoid C Malfunction

P0761 Shift Solenoid C Performance or Stuck Off

P0762 Shift Solenoid C Stuck On

P0763 Shift Solenoid C Electrical

P0764 Shift Solenoid C Intermittent

P0765 Shift Solenoid D Malfunction

Code and Meaning

P0766 Shift Solenoid D Performance or Stuck Off

P0767 Shift Solenoid D Stuck On

P0768 Shift Solenoid D Electrical

P0769 Shift Solenoid D Intermittent

P0770 Shift Solenoid E Malfunction

P0771 Shift Solenoid E Performance or Stuck Off

P0772 Shift Solenoid E Stuck On

P0773 Shift Solenoid E Electrical

P0774 Shift Solenoid E Intermittent

P0775 Pressure Control Solenoid "B"

P0776 Pressure Control Solenoid "B" Performance or Stuck off

P0777 Pressure Control Solenoid "B" Stuck On

P0778 Pressure Control Solenoid "B" Electrical

P0779 Pressure Control Solenoid "B" Intermittent

Code and Meaning

P0780 Shift Malfunction

P0781 1-2 Shift Malfunction

P0782 2-3 Shift Malfunction

P0783 3-4 Shift Malfunction

P0784 4-5 Shift Malfunction

P0785 Shift/Timing Solenoid Malfunction

P0786 Shift/Timing Solenoid Range/Performance

P0787 Shift/Timing Solenoid Low

P0788 Shift/Timing Solenoid High

P0789 Shift/Timing Solenoid Intermittent

P0790 Normal/Performance Switch Circuit Malfunction

P0791 Intermediate Shaft Speed Sensor "A" Circuit

P0792 Intermediate Shaft Speed Sensor "A" Circuit Range/Performance

P0793 Intermediate Shaft Speed Sensor "A" Circuit No Signal

Code and Meaning

P0794 Intermediate Shaft Speed Sensor "A" Circuit Intermittent

P0795 Pressure Control Solenoid "C"

P0796 Pressure Control Solenoid "C" Performance or Stuck off

P0797 Pressure Control Solenoid "C" Stuck On

P0798 Pressure Control Solenoid "C" Electrical

P0799 Pressure Control Solenoid "C" Intermittent

P0800 Transfer Case Control System (MIL Request)

P0801 Reverse Inhibit Control Circuit Malfunction

P0802 Transmission Control System MIL Request Circuit/Open

P0803 1-4 Upshift (Skip Shift) Solenoid Control Circuit Malfunction

P0804 1-4 Upshift (Skip Shift) Lamp Control Circuit Malfunction

P0805 Clutch Position Sensor Circuit

P0806 Clutch Position Sensor Circuit Range/Performance

P0807 Clutch Position Sensor Circuit Low

Code and Meaning

P0808 Clutch Position Sensor Circuit High

P0809 Clutch Position Sensor Circuit Intermittent

P0810 Clutch Position Control Error

P0811 Excessive Clutch Slippage

P0812 Reverse Input Circuit

P0813 Reverse Output Circuit

P0814 Transmission Range Display Circuit

P0815 Upshift Switch Circuit

P0816 Downshift Switch Circuit

P0817 Starter Disable Circuit

P0818 Driveline Disconnect Switch Input Circuit

P0819 Up and Down Shift Switch to Transmission Range Correlation

P0820 Gear Lever X-Y Position Sensor Circuit

P0821 Gear Lever X Position Circuit

Code and Meaning

P0822 Gear Lever Y Position Circuit

P0823 Gear Lever X Position Circuit Intermittent

P0824 Gear Lever Y Position Circuit Intermittent

P0825 Gear Lever Push-Pull Switch (Shift Anticipate

P0826 Up and Down Shift Switch Circuit

P0827 Up and Down Shift Switch Circuit Low

P0828 Up and Down Shift Switch Circuit High

P0829 5-6 Shift

P0830 Clutch Pedal Switch "A" Circuit

P0831 Clutch Pedal Switch "A" Circuit Low

P0832 Clutch Pedal Switch "A" Circuit High

P0833 Clutch Pedal Switch "B" Circuit

P0834 Clutch Pedal Switch "B" Circuit Low

P0835 Clutch Pedal Switch "B" Circuit High

Code and Meaning

P0836 Four Wheel Drive (4WD) Switch Circuit

P0837 Four Wheel Drive (4WD) Switch Circuit Range/Performance

P0838 Four Wheel Drive (4WD) Switch Circuit Low

P0839 Four Wheel Drive (4WD) Switch Circuit High P0840 Transmission Fluid Pressure Sensor/Switch "A" Circuit

P0840 Transmission Fluid Pressure Sensor/Switch "A" Circuit

P0841 Transmission Fluid Pressure Sensor/Switch "A" Circuit Range/Performance

P0842 Transmission Fluid Pressure Sensor/Switch "A" Circuit Low

P0843 Transmission Fluid Pressure Sensor/Switch "A" Circuit High

P0844 Transmission Fluid Pressure Sensor/Switch "A" Circuit Intermittent

P0845 Transmission Fluid Pressure Sensor/Switch "B" Circuit

P0846 Transmission Fluid Pressure Sensor/Switch "B" Circuit Range/Performance

P0847 Transmission Fluid Pressure Sensor/Switch "B" Circuit Low

Code and Meaning

P0848 Transmission Fluid Pressure Sensor/Switch "B" Circuit High

P0849 Transmission Fluid Pressure Sensor/Switch "B" Circuit Intermittent

P0850 Park/Neutral Switch Input Circuit

P0851 Park/Neutral Switch Input Circuit Low

P0852 Park/Neutral Switch Input Circuit High

P0853 Drive Switch Input Circuit

P0854 Drive Switch Input Circuit Low

P0855 Drive Switch Input Circuit High

P0856 Traction Control Input Signal

P0857 Traction Control Input Signal Range/Performance

P0858 Traction Control Input Signal Low

P0859 Traction Control Input Signal High

P0860 Gear Shift Module Communication Circuit

P0861 Gear Shift Module Communication Circuit Low

Code and Meaning

P0862 Gear Shift Module Communication Circuit High

P0863 TCM Communication Circuit

P0864 TCM Communication Circuit Range/Performance

P0865 TCM Communication Circuit Low

P0866 TCM Communication Circuit High

P0867 Transmission Fluid Pressure

P0868 Transmission Fluid Pressure Low P0869 Transmission Fluid Pressure High

P0869 Transmission Fluid Pressure High

P0870 Transmission Fluid Pressure Sensor/Switch "C" Circuit

P0871 Transmission Fluid Pressure Sensor/Switch "C" Circuit Range/Performance

P0872 Transmission Fluid Pressure Sensor/Switch "C" Circuit Low

P0873 Transmission Fluid Pressure Sensor/Switch "C" Circuit High

P0874 Transmission Fluid Pressure Sensor/Switch "C" Circuit Intermittent

Code and Meaning

P0875 Transmission Fluid Pressure Sensor/Switch "D" Circuit

P0876 Transmission Fluid Pressure Sensor/Switch "D" Circuit Range/
Performance

P0877 Transmission Fluid Pressure Sensor/Switch "D" Circuit Low

P0878 Transmission Fluid Pressure Sensor/Switch "D" Circuit High

P0879 Transmission Fluid Pressure Sensor/Switch "D" Circuit
Intermittent

P0880 TCM Power Input Signal

P0881 TCM Power Input Signal Range/Performance

P0882 TCM Power Input Signal Low

P0883 TCM Power Input Signal High

P0884 TCM Power Input Signal Intermittent

P0885 TCM Power Relay Control Circuit/Open

P0886 TCM Power Relay Control Circuit Low

P0887 TCM Power Relay Control Circuit High

Code and Meaning

P0888 TCM Power Relay Sense Circuit

P0889 TCM Power Relay Sense Circuit Range/Performance

P0890 TCM Power Relay Sense Circuit Low

P0891 TCM Power Relay Sense Circuit High

P0892 TCM Power Relay Sense Circuit Intermittent

P0893 Multiple Gears Engaged

P0894 Transmission Component Slipping

P0895 Shift Time Too Short

P0896 Shift Time Too Long

P0897 Transmission Fluid Deteriorated

P0898 Transmission Control System MIL Request Circuit Low

P0899 Transmission Control System MIL Request Circuit High

P2000 NOx Trap Efficiency Below Threshold Bank1

P2001 NOx Trap Efficiency Below Threshold Bank2

Code and Meaning

P2002 Particulate Trap Efficiency Below Threshold Bank1

P2003 Particulate Trap Efficiency Below Threshold Bank2

P2004 Intake Manifold Runner Ctrl Stuck Open Bank1

P2005 Intake Manifold Runner Ctrl Stuck Open Bank2

P2006 Intake Manifold Runner Ctrl Stuck Closed Bank1

P2007 Intake Manifold Runner Ctrl Stuck Closed Bank2

P2008 Intake Manifold Runner Ctrl Circ/Open Bank1

P2009 Intake Manifold Runner Ctrl Circ Low Bank1

P2010 Intake Manifold Runner Ctrl Circ High Bank1

P2011 Intake Manifold Runner Ctrl Circ/Open Bank2

P2012 Intake Manifold Runner Ctrl Circ Low Bank2

P2013 Intake Manifold Runner Ctrl Circ High Bank2

P2014 Intake Manifold Runner Pos Sensor/Switch Circ Bank1

P2015 Intake Manifold Runner Pos Sensor/Switch Circ Range/Perf Bank1

Code and Meaning

P2016 Intake Manifold Runner Pos Sensor/Switch Circ Low Bank1

P2017 Intake Manifold Runner Pos Sensor/Switch Circ High Bank1

P2018 Intake Manifold Runner Pos Sensor/Switch Circ Interm Bank1

P2019 Intake Manifold Runner Pos Sensor/Switch Circ Bank2

P2020 Intake Manifold Runner Pos Sensor/Switch Circ Range/Perf Bank2

P2021 Intake Manifold Runner Pos Sensor/Switch Circ Low Bank2

P2022 Intake Manifold Runner Pos Sensor/Switch Circ High Bank2

P2023 Intake Manifold Runner Pos Sensor/Switch Circ Interm Bank2

P2024 EVAP Fuel Vapor Temp Sensor Circ

P2025 EVAP Fuel Vapor Temp Sensor Perf

P2026 EVAP Fuel Vapor Temp Sensor Circ Low Voltage

P2027 EVAP Fuel Vapor Temp Sensor Circ High Voltage

P2028 EVAP Fuel Vapor Temp Sensor Circ Interm

P2029 Fuel Fired Heater Disabled

Code and Meaning

P2030 Fuel Fired Heater Perf

P2031 Exhaust Gas Temp Sensor Circ Bank1 Sensor 2

P2032 Exhaust Gas Temp Sensor Circ Low Bank1 Sensor 2

P2033 Exhaust Gas Temp Sensor Circ High Bank1 Sensor 2

P2034 Exhaust Gas Temp Sensor Circ Bank2 Sensor 2

P2035 Exhaust Gas Temp Sensor Circ Low Bank2 Sensor 2

P2036 Exhaust Gas Temp Sensor Circ High Bank2 Sensor 2

P2037 Reductant Inj Air Press Sensor Circ

P2038 Reductant Inj Air Press Sensor Circ Range/Perf

P2039 Reductant Inj Air Press Sensor Circ Low Input

P2040 Reductant Inj Air Press Sensor Circ High Input

P2041 Reductant Inj Air Press Sensor Circ Interm

P2042 Reductant Temp Sensor Circ

P2043 Reductant Temp Sensor Circ Range/Perf

Code and Meaning

P2044 Reductant Temp Sensor Circ Low Input

P2045 Reductant Temp Sensor Circ High Input

P2046 Reductant Temp Sensor Circ Interm

P2047 Reductant Injector Circ/Open Bank1 Unit 1

P2048 Reductant Injector Circ Low Bank1 Unit 1

P2049 Reductant Injector Circ High Bank1 Unit 1

P2050 Reductant Injector Circ/Open Bank2 Unit 1

P2051 Reductant Injector Circ Low Bank2 Unit 1

P2052 Reductant Injector Circ High Bank2 Unit 1

P2053 Reductant Injector Circ/Open Bank1 Unit 2

P2054 Reductant Injector Circ Low Bank1 Unit 2

P2055 Reductant Injector Circ High Bank1 Unit 2

P2056 Reductant Injector Circ/Open Bank2 Unit 2

P2057 Reductant Injector Circ Low Bank2 Unit 2

Code and Meaning

P2058 Reductant Injector Circ High Bank2 Unit 2

P2059 Reductant Inj Air Pump Ctrl Circ/Open

P2060 Reductant Inj Air Pump Ctrl Circ Low

P2061 Reductant Inj Air Pump Ctrl Circ High

P2062 Reductant Supply Ctrl Circ/Open

P2063 Reductant Supply Ctrl Circ Low

P2064 Reductant Supply Ctrl Circ High

P2065 Fuel Level SensorB Circ

P2066 Fuel Level SensorB Perf

P2067 Fuel Level SensorB Circ Low

P2068 Fuel Level SensorB Circ High

P2069 Fuel Level SensorB Circ Interm

P2070 Intake Manifold Tuning (IMT) Valve Stuck Open

P2071 IMT Valve Stuck Closed

Code and Meaning

P2072 Throttle Actuator Control System - Ice Blockage

P2073 Manifold Absolute Pressure/Mass Air Flow - Throttle Position Correlation at Idle

P2074 Manifold Absolute Pressure/Mass Air Flow - Throttle Position Correlation at Higher Load

P2075 IMT Valve Pos Sensor/Switch Circ

P2076 IMT Valve Pos Sensor/Switch Circ Range/Perf

P2077 IMT Valve Pos Sensor/Switch Circ Low

P2078 IMT Valve Pos Sensor/Switch Circ High

P2079 IMT Valve Pos Sensor/Switch Circ Interm

P2080 Exhaust Gas Temp Sensor Circ Range/Perf Bank1 Sensor 1

P2081 Exhaust Gas Temp Sensor Circ Interm Bank1 Sensor 1

P2082 Exhaust Gas Temp Sensor Circ Range/Perf Bank2 Sensor 1

P2083 Exhaust Gas Temp Sensor Circ Interm Bank2 Sensor 1

P2084 Exhaust Gas Temp Sensor Circ Range/Perf Bank1 Sensor 2

Code and Meaning

P2085 Exhaust Gas Temp Sensor Circ Interm Bank1 Sensor 2

P2086 Exhaust Gas Temp Sensor Circ Range/Perf Bank2 Sensor 2

P2087 Exhaust Gas Temp Sensor Circ Interm Bank2 Sensor 2

P2088 A Camshaft Pos Actuator Ctrl Circ Low Bank1

P2089 A Camshaft Pos Actuator Ctrl Circ High Bank1

P2090 B Camshaft Pos Actuator Ctrl Circ Low Bank1

P2091 B Camshaft Pos Actuator Ctrl Circ High Bank1

P2092 A Camshaft Pos Actuator Ctrl Circ Low Bank2

P2093 A Camshaft Pos Actuator Ctrl Circ High Bank2

P2094 B Camshaft Pos Actuator Ctrl Circ Low Bank2

P2095 B Camshaft Pos Actuator Ctrl Circ High Bank2

P2096 Post Catalyst Fuel Trim Sys Too Lean Bank1

P2097 Post Catalyst Fuel Trim Sys Too Rich Bank1

P2098 Post Catalyst Fuel Trim Sys Too Lean Bank2

Code and Meaning

P2099 Post Catalyst Fuel Trim Sys Too Rich Bank2

P2100 Throttle Actuator Ctrl Motor Circ/Open

P2101 Throttle Actuator Ctrl Motor Circ Range/Perf

P2102 Throttle Actuator Ctrl Motor Circ Low

P2103 Throttle Actuator Ctrl Motor Circ High

P2104 Throttle Actuator Ctrl Sys-Forced Idle

P2105 Throttle Actuator Ctrl Sys-Forced Engine Shutdown

P2106 Throttle Actuator Ctrl Sys-Forced Limited Power

P2107 Throttle Actuator Ctrl Mod Processor

P2108 Throttle Actuator Ctrl Mod Perf

P2109 Throttle/Pedal Pos SensorA Minimum Stop Perf

P2110 Throttle Actuator Ctrl Sys-Forced Limited RPM

P2111 Throttle Actuator Ctrl Sys-Stuck Open

P2112 Throttle Actuator Ctrl Sys-Stuck Closed

Code and Meaning

P2113 Throttle/Pedal Pos SensorB Minimum Stop Perf

P2114 Throttle/Pedal Pos Sensor C Minimum Stop Perf

P2115 Throttle/Pedal Pos Sensor D Minimum Stop Perf

P2116 Throttle/Pedal Pos Sensor E Minimum Stop Perf

P2117 Throttle/Pedal Pos Sensor F Minimum Stop Perf

P2118 Throttle Actuator Ctrl Motor Current Range/Perf

P2119 Throttle Actuator Ctrl Throttle Body Range/Perf

P2120 Throttle/Pedal Pos Sensor/Switch D Circ

P2121 Throttle/Pedal Pos Sensor/Switch D Circ Range/Perf

P2122 Throttle/Pedal Pos Sensor/Switch D Circ Low Input

P2123 Throttle/Pedal Pos Sensor/Switch D Circ High Input

P2124 Throttle/Pedal Pos Sensor/Switch D Circ Interm

P2125 Throttle/Pedal Pos Sensor/Switch E Circ

P2126 Throttle/Pedal Pos Sensor/Switch E Circ Range/Perf

Code and Meaning

P2127 Throttle/Pedal Pos Sensor/Switch E Circ Low Input

P2128 Throttle/Pedal Pos Sensor/Switch E Circ High Input

P2129 Throttle/Pedal Pos Sensor/Switch E Circ Interm

P2130 Throttle/Pedal Pos Sensor/Switch F Circ

P2131 Throttle/Pedal Pos Sensor/Switch F Circ Range Perf

P2132 Throttle/Pedal Pos Sensor/Switch F Circ Low Input

P2133 Throttle/Pedal Pos Sensor/Switch F Circ High Input

P2134 Throttle/Pedal Pos Sensor/Switch F Circ Interm

P2135 Throttle/Pedal Pos Sensor/Switch A / B Voltage Correlation

P2136 Throttle/Pedal Pos Sensor/Switch A / C Voltage Correlation

P2137 Throttle/Pedal Pos Sensor/Switch B / C Voltage Correlation

P2138 Throttle/Pedal Pos Sensor/Switch D / E Voltage Correlation

P2139 Throttle/Pedal Pos Sensor/Switch D / F Voltage Correlation

P2140 Throttle/Pedal Pos Sensor/Switch E / F Voltage Correlation

Code and Meaning

P2141 Exhaust Gas Recirculation Throttle Ctrl Circ Low

P2142 Exhaust Gas Recirculation Throttle Ctrl Circ High

P2143 Exhaust Gas Recirculation Vent Ctrl Circ/Open

P2144 Exhaust Gas Recirculation Vent Ctrl Circ Low

P2145 Exhaust Gas Recirculation Vent Ctrl Circ High

P2146 Fuel Injector Group A Supply Voltage Circ/Open

P2147 Fuel Injector Group A Supply Voltage Circ Low

P2148 Fuel Injector Group A Supply Voltage Circ High

P2149 Fuel Injector Group B Supply Voltage Circ/Open

P2150 Fuel Injector Group B Supply Voltage Circ Low

P2151 Fuel Injector Group B Supply Voltage Circ High

P2152 Fuel Injector Group C Supply Voltage Circ/Open

P2153 Fuel Injector Group C Supply Voltage Circ Low

P2154 Fuel Injector Group C Supply Voltage Circ High

Code and Meaning

P2155 Fuel Injector Group D Supply Voltage Circ/Open

P2156 Fuel Injector Group D Supply Voltage Circ Low

P2157 Fuel Injector Group D Supply Voltage Circ High

P2158 Vehicle Speed SensorB

P2159 Vehicle Speed SensorB Range/Perf

P2160 Vehicle Speed SensorB Circ Low

P2161 Vehicle Speed SensorB Interm/Erratic

P2162 Vehicle Speed SensorA / B Correlation

P2163 Throttle/Pedal Pos SensorA Maximum Stop Perf

P2164 Throttle/Pedal Pos SensorB Maximum Stop Perf

P2165 Throttle/Pedal Pos Sensor C Maximum Stop Perf

P2166 Throttle/Pedal Pos Sensor D Maximum Stop Perf

P2167 Throttle/Pedal Pos Sensor E Maximum Stop Perf

P2168 Throttle/Pedal Pos Sensor F Maximum Stop Perf

Code and Meaning

P2169 Exhaust Press Reg Vent Solenoid Ctrl Circ/Open

P2170 Exhaust Press Reg Vent Solenoid Ctrl Circ Low

P2171 Exhaust Press Reg Vent Solenoid Ctrl Circ High

P2172 Throttle Actuator Ctrl Sys-Sudden High Airflow Detected

P2173 Throttle Actuator Ctrl Sys-High Airflow Detected

P2174 Throttle Actuator Ctrl Sys-Sudden Low Airflow Detected

P2175 Throttle Actuator Ctrl Sys-Low Airflow Detected

P2176 Throttle Actuator Ctrl Sys-Idle Pos Not Learned

P2177 Sys Too Lean Off Idle Bank1

P2178 Sys Too Rich Off Idle Bank1

P2179 Sys Too Lean Off Idle Bank2

P2180 Sys Too Rich Off Idle Bank2

P2181 Cooling System Performance

P2182 Engine Coolant Temp Sensor 2 Circ

Code and Meaning

P2183 Engine Coolant Temp Sensor 2 Circ Range/Perf

P2184 Engine Coolant Temp Sensor 2 Circ Low

P2185 Engine Coolant Temp Sensor 2 Circ High

P2186 Engine Coolant Temp Sensor 2 Circ Interm/Erratic

P2187 Sys Too Lean at Idle Bank1

P2188 Sys Too Rich at Idle Bank1

P2189 Sys Too Lean at Idle Bank2

P2190 Sys Too Rich at Idle Bank2

P2191 Sys Too Lean at Higher Load Bank1

P2192 Sys Too Rich at Higher Load Bank1

P2193 Sys Too Lean at Higher Load Bank2

P2194 Sys Too Rich at Higher Load Bank2

P2195 O2 Sensor Signal Stuck Lean Bank1 Sensor 1

P2196 O2 Sensor Signal Stuck Rich Bank1 Sensor 1

Code and Meaning

P2197 O2 Sensor Signal Stuck Lean Bank2 Sensor 1

P2198 O2 Sensor Signal Stuck Rich Bank2 Sensor 1

P2199 Intake Air Temp Sensor 1 / 2 Correlation

P2200 NOx Sensor Circ Bank1

P2201 NOx Sensor Circ Range/Perf Bank1

P2202 NOx Sensor Circ Low Input Bank1

P2203 NOx Sensor Circ High Input Bank1

P2204 NOx Sensor Circ Interm Input Bank1

P2205 NOx Sensor Heater Ctrl Circ/Open Bank1

P2206 NOx Sensor Heater Ctrl Circ Low Bank1

P2207 NOx Sensor Heater Ctrl Circ High Bank1

P2208 NOx Sensor Heater Sense Circ Bank1

P2209 NOx Sensor Heater Sense Circ Range/Perf Bank1

P2210 NOx Sensor Heater Sense Circ Low Input Bank1

Code and Meaning

P2211 NOx Sensor Heater Sense Circ High Input Bank1

P2212 NOx Sensor Heater Sense Circ Interm Bank1

P2213 NOx Sensor Circ Bank2

P2214 NOx Sensor Circ Range/Perf Bank2

P2215 NOx Sensor Circ Low Input Bank2

P2216 NOx Sensor Circ High Input Bank2

P2217 NOx Sensor Circ Interm Input Bank2

P2218 NOx Sensor Heater Ctrl Circ/Open Bank2

P2219 NOx Sensor Heater Ctrl Circ Low Bank2

P2220 NOx Sensor Heater Ctrl Circ High Bank2

P2221 NOx Sensor Heater Sense Circ Bank2

P2222 NOx Sensor Heater Sense Circ Range/Perf Bank2

P2223 NOx Sensor Heater Sense Circ Low Bank2

P2224 NOx Sensor Heater Sense Circ High Bank2

Code and Meaning

P2225 NOx Sensor Heater Sense Circ Interm Bank2

P2228 Barometric Press Circ Low

P2229 Barometric Press Circ High

P2230 Barometric Press Circ Interm

P2232 O2 Sensor Signal Circ Shorted to Heater Circ Bank1 Sensor 2

P2233 O2 Sensor Signal Circ Shorted to Heater Circ Bank1 Sensor 3

P2234 O2 Sensor Signal Circ Shorted to Heater Circ Bank2 Sensor 1

P2235 O2 Sensor Signal Circ Shorted to Heater Circ Bank2 Sensor 2

P2236 O2 Sensor Signal Circ Shorted to Heater Circ Bank2 Sensor 3

P2237 O2 Sensor Positive Current Ctrl Circ/Open Bank1 Sensor 1

P2238 O2 Sensor Positive Current Ctrl Circ Low Bank1 Sensor 1

P2239 O2 Sensor Positive Current Ctrl Circ High Bank1 Sensor 1

P2240 O2 Sensor Positive Current Ctrl Circ/Open Bank2 Sensor 1

P2241 O2 Sensor Positive Current Ctrl Circ Low Bank2 Sensor 1

Code and Meaning

P2242 O2 Sensor Positive Current Ctrl Circ High Bank2 Sensor 1

P2243 O2 Sensor Ref Voltage Circ/Open Bank1 Sensor 1

P2244 O2 Sensor Ref Voltage Perf Bank1 Sensor 1

P2245 O2 Sensor Ref Voltage Circ Low Bank1 Sensor 1

P2246 O2 Sensor Ref Voltage Circ High Bank1 Sensor 1

P2247 O2 Sensor Ref Voltage Circ/Open Bank2 Sensor 1

P2248 O2 Sensor Ref Voltage Perf Bank2 Sensor 1

P2249 O2 Sensor Ref Voltage Circ Low Bank2 Sensor 1

P2250 O2 Sensor Ref Voltage Circ High Bank2 Sensor 1

P2251 O2 Sensor Negative Current Ctrl Circ/Open Bank1 Sensor 1

P2252 O2 Sensor Negative Current Ctrl Circ Low Bank1 Sensor 1

P2253 O2 Sensor Negative Current Ctrl Circ High Bank1 Sensor 1

P2254 O2 Sensor Negative Current Ctrl Circ/Open Bank2 Sensor 1

P2255 O2 Sensor Negative Current Ctrl Circ Low Bank2 Sensor 1

Code and Meaning

P2256 O2 Sensor Negative Current Ctrl Circ High Bank2 Sensor 1

P2257 Sec Air Inj Sys Ctrl A Circ Low

P2258 Sec Air Inj Sys Ctrl A Circ High

P2259 Sec Air Inj Sys Ctrl B Circ Low

P2260 Sec Air Inj Sys Ctrl B Circ High

P2261 T/S Charger Bypass Valve-Mechanical

P2262 Turbo Boost Press Not Detected-Mechanical

P2263 T/S Charger Boost Sys Perf

P2264 Water in Fuel Sensor Circ

P2265 Water in Fuel Sensor Circ Range/Perf

P2266 Water in Fuel Sensor Circ Low

P2267 Water in Fuel Sensor Circ High

P2268 Water in Fuel Sensor Circ Interm

P2269 Water in Fuel Condition

Code and Meaning

P2270 O2 Sensor Signal Stuck Lean Bank1 Sensor 2

P2271 O2 Sensor Signal Stuck Rich Bank1 Sensor 2

P2272 O2 Sensor Signal Stuck Lean Bank2 Sensor 2

P2273 O2 Sensor Signal Stuck Rich Bank2 Sensor 2

P2274 O2 Sensor Signal Stuck Lean Bank1 Sensor 3

P2275 O2 Sensor Signal Stuck Rich Bank1 Sensor 3

P2276 O2 Sensor Signal Stuck Lean Bank2 Sensor 3

P2277 O2 Sensor Signal Stuck Rich Bank2 Sensor 3

P2278 O2 Sensor Signals Swapped Bank1 Sensor 3 / Bank2 Sensor 3

P2279 Intake Air Sys Leak

P2280 Air Flow Restriction / Air Leak Between Air Filter and MAF

P2281 Air Leak Between MAF and Throttle Body

P2282 Air Leak Between Throttle Body and Intake Valves

P2283 Injector Ctrl Press Sensor Circ

Code and Meaning

P2284 Injector Ctrl Press Sensor Circ Range/Perf

P2285 Injector Ctrl Press Sensor Circ Low

P2286 Injector Ctrl Press Sensor Circ High

P2287 Injector Ctrl Press Sensor Circ Interm

P2288 Injector Ctrl Press Too High

P2289 Injector Ctrl Press Too High-Engine Off

P2290 Injector Ctrl Press Too Low

P2291 Injector Ctrl Press Too Low-Engine Cranking

P2292 Injector Ctrl Press Erratic

P2293 Fuel Press Reg 2 Perf

P2294 Fuel Press Reg 2 Ctrl Circ

P2295 Fuel Press Reg 2 Ctrl Circ Low

P2296 Fuel Press Reg 2 Ctrl Circ High

P2297 O2 Sensor Out of Range During Deceleration Bank1 Sensor 1

Code and Meaning

P2298 O2 Sensor Out of Range During Deceleration Bank2 Sensor 1

P2299 Brake Pedal Pos / Accelerator Pedal Pos Incompatible

P2300 Ignition Coil A Pri Ctrl Circ Low

P2301 Ignition Coil A Pri Ctrl Circ High

P2302 Ignition Coil A Sec Circ

P2303 Ignition Coil B Pri Ctrl Circ Low

P2304 Ignition Coil B Pri Ctrl Circ High

P2305 Ignition Coil B Sec Circ

P2306 Ignition Coil C Pri Ctrl Circ Low

P2307 Ignition Coil C Pri Ctrl Circ High

P2308 Ignition Coil C Sec Circ

P2309 Ignition Coil D Pri Ctrl Circ Low

P2310 Ignition Coil D Pri Ctrl Circ High

P2311 Ignition Coil D Sec Circ

Code and Meaning

P2312 Ignition Coil E Pri Ctrl Circ Low

P2313 Ignition Coil E Pri Ctrl Circ High

P2314 Ignition Coil E Sec Circ

P2315 Ignition Coil F Pri Ctrl Circ Low

P2316 Ignition Coil F Pri Ctrl Circ High

P2317 Ignition Coil F Sec Circ

P2318 Ignition Coil G Pri Ctrl Circ Low

P2319 Ignition Coil G Pri Ctrl Circ High

P2320 Ignition Coil G Sec Circ

P2321 Ignition Coil H Pri Ctrl Circ Low

P2322 Ignition Coil H Pri Ctrl Circ High

P2323 Ignition Coil H Sec Circ

P2324 Ignition Coil I Pri Ctrl Circ Low

P2325 Ignition Coil I Pri Ctrl Circ High

Code and Meaning

P2326 Ignition Coil I Sec Circ

P2327 Ignition Coil J Pri Ctrl Circ Low

P2328 Ignition Coil J Pri Ctrl Circ High

P2329 Ignition Coil J Sec Circ

P2330 Ignition Coil K Pri Ctrl Circ Low

P2331 Ignition Coil K Pri Ctrl Circ High

P2332 Ignition Coil K Sec Circ

P2333 Ignition Coil L Pri Ctrl Circ Low

P2334 Ignition Coil L Pri Ctrl Circ High

P2335 Ignition Coil L Sec Circ

P2336 Cylinder #1 Above Knock Threshold

P2337 Cylinder #2 Above Knock Threshold

P2338 Cylinder #3 Above Knock Threshold

P2339 Cylinder #4 Above Knock Threshold

Code and Meaning

P2340 Cylinder #5 Above Knock Threshold

P2341 Cylinder #6 Above Knock Threshold

P2342 Cylinder #7 Above Knock Threshold

P2343 Cylinder #8 Above Knock Threshold

P2344 Cylinder #9 Above Knock Threshold

P2345 Cylinder #10 Above Knock Threshold

P2346 Cylinder #11 Above Knock Threshold

P2347 Cylinder #12 Above Knock Threshold

P2400 EVAP Leak Detection Pump Ctrl Circ/Open

P2401 EVAP Leak Detection Pump Ctrl Circ Low

P2402 EVAP Leak Detection Pump Ctrl Circ High

P2403 EVAP Leak Detection Pump Sense Circ/Open

P2404 EVAP Leak Detection Pump Sense Circ Range/Perf

P2405 EVAP Leak Detection Pump Sense Circ Low

Code and Meaning

P2406 EVAP Leak Detection Pump Sense Circ High

P2407 EVAP Leak Detection Pump Sense Circ Interm/Erratic

P2408 Fuel Cap Sensor/Switch Circ

P2409 Fuel Cap Sensor/Switch Circ Range/Perf

P2410 Fuel Cap Sensor/Switch Circ Low

P2411 Fuel Cap Sensor/Switch Circ High

P2412 Fuel Cap Sensor/Switch Circ Interm/Erratic

P2413 Exhaust Gas Recirculation Sys Perf

P2414 O2 Sensor Exhaust Sample Error Bank1 Sensor 1

P2415 O2 Sensor Exhaust Sample Error Bank2 Sensor 1

P2416 O2 Sensor Signals Swapped Bank1 Sensor 2 / Bank1 Sensor 3

P2417 O2 Sensor Signals Swapped Bank2 Sensor 2 / Bank2 Sensor 3

P2418 EVAP Switching Valve Ctrl Circ /Open

P2419 EVAP Switching Valve Ctrl Circ Low

Code and Meaning

P2420 EVAP Switching Valve Ctrl Circ High

P2421 EVAP Vent Valve Stuck Open

P2422 EVAP Vent Valve Stuck Closed

P2423 HC Adsorption Catalyst Efficiency Below Threshold Bank1

P2424 HC Adsorption Catalyst Efficiency Below Threshold Bank2

P2425 Exhaust Gas Recirculation Cooling Valve Ctrl Circ/Open

P2426 Exhaust Gas Recirculation Cooling Valve Ctrl Circ Low

P2427 Exhaust Gas Recirculation Cooling Valve Ctrl Circ High

P2428 Exhaust Gas Temp Too High Bank1

P2429 Exhaust Gas Temp Too High Bank2

P2430 Sec Air Inj Sys Air Flow/Press Sensor Circ Bank1

P2431 Sec Air Inj Sys Air Flow/Press Sensor Circ Range/Perf Bank1

P2432 Sec Air Inj Sys Air Flow/Press Sensor Circ Low Bank1

P2433 Sec Air Inj Sys Air Flow/Press Sensor Circ High Bank1

Code and Meaning

P2434 Sec Air Inj Sys Air Flow/Press Sensor Circ Interm/Erratic Bank1

P2435 Sec Air Inj Sys Air Flow/Press Sensor Circ Bank2

P2436 Sec Air Inj Sys Air Flow/Press Sensor Circ Range/Perf Bank2

P2437 Sec Air Inj Sys Air Flow/Press Sensor Circ Low Bank2

P2438 Sec Air Inj Sys Air Flow/Press Sensor Circ High Bank2

P2439 Sec Air Inj Sys Air Flow/Press Sensor Circ Interm/Erratic Bank2

P2440 Sec Air Inj Sys Switching Valve Stuck Open Bank1

P2441 Sec Air Inj Sys Switching Valve Stuck Closed Bank1

P2442 Sec Air Inj Sys Switching Valve Stuck Open Bank2

P2443 Sec Air Inj Sys Switching Valve Stuck Closed Bank2

P2444 Sec Air Inj Sys Pump Stuck On Bank1

P2445 Sec Air Inj Sys Pump Stuck Off Bank1

P2446 Sec Air Inj Sys Pump Stuck On Bank2

P2447 Sec Air Inj Sys Pump Stuck Off Bank2

Code and Meaning

P2453 Particulate Matter Trap Differential Pressure Sensor Signal Performance

P2455 DPF Differential Pressure Sensor Short to Voltage

P2500 Generator Lamp/L-Terminal Circ Low

P2501 Generator Lamp/L-Terminal Circ High

P2502 Charging Sys Voltage

P2503 Charging Sys Voltage Low

P2504 Charging Sys Voltage High

P2505 ECM/PCM Power Input Signal

P2506 ECM/PCM Power Input Signal Range/Perf

P2507 ECM/PCM Power Input Signal Low

P2508 ECM/PCM Power Input Signal High

P2509 ECM/PCM Power Input Signal Interm

P2510 ECM/PCM Power Relay Sense Circ Range/Perf

P2511 ECM/PCM Power Relay Sense Circ Interm

Code and Meaning

P2512 Event Data Recorder Request Circ/ Open

P2513 Event Data Recorder Request Circ Low

P2514 Event Data Recorder Request Circ High

P2515 A/C Refrigerant Press SensorB Circ

P2516 A/C Refrigerant Press SensorB Circ Range/Perf

P2517 A/C Refrigerant Press SensorB Circ Low

P2518 A/C Refrigerant Press SensorB Circ High

P2519 A/C Request A Circ

P2520 A/C Request A Circ Low

P2521 A/C Request A Circ High

P2522 A/C Request B Circ

P2523 A/C Request B Circ Low

P2524 A/C Request B Circ High

P2525 Vacuum Reservoir Press Sensor Circ

Code and Meaning

P2526 Vacuum Reservoir Press Sensor Circ Range/Perf

P2527 Vacuum Reservoir Press Sensor Circ Low

P2528 Vacuum Reservoir Press Sensor Circ High

P2529 Vacuum Reservoir Press Sensor Circ Interm

P2530 Ignition Switch Run Pos Circ

P2531 Ignition Switch Run Pos Circ Low

P2532 Ignition Switch Run Pos Circ High

P2533 Ignition Switch Run/Start Pos Circ

P2534 Ignition Switch Run/Start Pos Circ Low

P2535 Ignition Switch Run/Start Pos Circ High

P2536 Ignition Switch Accessory Pos Circ

P2537 Ignition Switch Accessory Pos Circ Low

P2538 Ignition Switch Accessory Pos Circ High

P2539 Low Press Fuel Sys Sensor Circ

P2540 Low Press Fuel Sys Sensor Circ Range/Perf

Code and Meaning

P2541 Low Press Fuel Sys Sensor Circ Low

P2542 Low Press Fuel Sys Sensor Circ High

P2543 Low Press Fuel Sys Sensor Circ Interm

P2544 Torque Mgmt Request Input Signal A

P2545 Torque Mgmt Request Input Signal A Range/Perf

P2546 Torque Mgmt Request Input Signal A Low

P2547 Torque Mgmt Request Input Signal A High

P2548 Torque Mgmt Request Input Signal B

P2549 Torque Mgmt Request Input Signal B Range/Perf

P2550 Torque Mgmt Request Input Signal B Low

P2551 Torque Mgmt Request Input Signal B High

P2552 Throttle/Fuel Inhibit Circ

P2553 Throttle/Fuel Inhibit Circ Range/Perf

P2554 Throttle/Fuel Inhibit Circ Low

P2555 Throttle/Fuel Inhibit Circ High

Code and Meaning

P2556 Engine Coolant Level Sensor/Switch Circ

P2557 Engine Coolant Level Sensor/Switch Circ Range/Perf

P2558 Engine Coolant Level Sensor/Switch Circ Low

P2559 Engine Coolant Level Sensor/Switch Circ High

P2560 Engine Coolant Level Low

P2561 A/C Ctrl Mod Requested MIL Illumination

P2562 Turbocharger Boost Ctrl Pos Sensor Circ

P2563 Turbocharger Boost Ctrl Pos Sensor Circ Range/Perf

P2564 Turbocharger Boost Ctrl Pos Sensor Circ Low

P2565 Turbocharger Boost Ctrl Pos Sensor Circ High

P2566 Turbocharger Boost Ctrl Pos Sensor Circ Interm

P2567 Direct Ozone Reduction Catalyst Temp Sensor Circ

P2568 Direct Ozone Reduction Catalyst Temp Sensor Circ Range/Perf

P2569 Direct Ozone Reduction Catalyst Temp Sensor Circ Low

P2570 Direct Ozone Reduction Catalyst Temp Sensor Circ High

Code and Meaning

P2571 Direct Ozone Reduction Catalyst Temp Sensor Circ Interm/
Erratic4

P2572 Direct Ozone Reduction Catalyst Deterioration Sensor Circ4

P2573 Direct Ozone Reduction Catalyst Deterioration Sensor Circ
Range/Perf4

P2574 Direct Ozone Reduction Catalyst Deterioration Sensor Circ Low4

P2575 Direct Ozone Reduction Catalyst Deterioration Sensor Circ High4

P2576 Direct Ozone Reduction Catalyst Deterioration Sensor Circ
Interm/Erratic

P2577 Direct Ozone Reduction Catalyst Efficiency Below Threshold

P2600 Coolant Pump Ctrl Circ/Open

P2601 Coolant Pump Ctrl Circ Range/Perf

P2602 Coolant Pump Ctrl Circ Low

P2603 Coolant Pump Ctrl Circ High

P2604 Intake Air Heater A Circ Range/Perf

P2605 Intake Air Heater A Circ/Open

P2606 Intake Air Heater B Circ Range/Perf

Code and Meaning

P2607 Intake Air Heater B Circ Low

P2608 Intake Air Heater B Circ High

P2609 Intake Air Heater Sys Perf

P2610 ECM/PCM Internal Engine Off Timer Perf

P2611 A/C Refrigerant Distribution Valve Ctrl Circ/Open

P2612 A/C Refrigerant Distribution Valve Ctrl Circ Low

P2613 A/C Refrigerant Distribution Valve Ctrl Circ High

P2614 Camshaft Pos Signal Output Circ/Open

P2615 Camshaft Pos Signal Output Circ Low

P2616 Camshaft Pos Signal Output Circ High

P2617 Crank Pos Signal Output Circ/Open

P2618 Crank Pos Signal Output Circ Low

P2619 Crank Pos Signal Output Circ High

P2620 Throttle Pos Output Circ/Open

P2621 Throttle Pos Output Circ Low

Code and Meaning

P2622 Throttle Pos Output Circ High

P2623 Injector Ctrl Press Reg Circ/Open

P2624 Injector Ctrl Press Reg Circ Low

P2625 Injector Ctrl Press Reg Circ High

P2626 O2 Sensor Pumping Current Trim Circ/Open Bank1 Sensor 1

P2627 O2 Sensor Pumping Current Trim Circ Low Bank1 Sensor 1

P2628 O2 Sensor Pumping Current Trim Circ High Bank1 Sensor 1

P2629 O2 Sensor Pumping Current Trim Circ/Open Bank2 Sensor 1

P2630 O2 Sensor Pumping Current Trim Circ Low Bank2 Sensor 1

P2631 O2 Sensor Pumping Current Trim Circ High Bank2 Sensor 1

P2632 Fuel Pump B Ctrl Circ /Open

P2633 Fuel Pump B Ctrl Circ Low

P2634 Fuel Pump B Ctrl Circ High

P2635 Fuel Pump A Low Flow / Perf

P2636 Fuel Pump B Low Flow / Perf

Code and Meaning

P2637 Torque Mgmt Feedback Signal A

P2638 Torque Mgmt Feedback Signal A Range/Perf

P2639 Torque Mgmt Feedback Signal A Low

P2640 Torque Mgmt Feedback Signal A High

P2641 Torque Mgmt Feedback Signal B

P2642 Torque Mgmt Feedback Signal B Range/Perf

P2643 Torque Mgmt Feedback Signal B Low

P2644 Torque Mgmt Feedback Signal B High

P2645 A Rocker Arm Actuator Ctrl Circ/Open Bank1

P2646 A Rocker Arm Actuator Sys Perf or Stuck Off Bank1

P2647 A Rocker Arm Actuator Sys Stuck On Bank1

P2648 A Rocker Arm Actuator Ctrl Circ Low Bank1

P2649 A Rocker Arm Actuator Ctrl Circ High Bank1

P2650 B Rocker Arm Actuator Ctrl Circ/Open Bank1

P2651 B Rocker Arm Actuator Sys Perf or Stuck Off Bank1

Code and Meaning

P2652 B Rocker Arm Actuator Sys Stuck On Bank1

P2653 B Rocker Arm Actuator Ctrl Circ Low Bank1

P2654 B Rocker Arm Actuator Ctrl Circ High Bank1

P2655 A Rocker Arm Actuator Ctrl Circ/Open Bank2

P2656 A Rocker Arm Actuator Sys Perf or Stuck Off Bank2

P2657 A Rocker Arm Actuator Sys Stuck On Bank2

P2658 A Rocker Arm Actuator Ctrl Circ Low Bank2

P2659 A Rocker Arm Actuator Ctrl Circ High Bank2

P2660 B Rocker Arm Actuator Ctrl Circ/Open Bank2

P2661 B Rocker Arm Actuator Sys Perf or Stuck Off Bank2

P2662 B Rocker Arm Actuator Sys Stuck On Bank2

P2663 B Rocker Arm Actuator Ctrl Circ Low Bank2

P2664 B Rocker Arm Actuator Ctrl Circ High Bank2

P2665 Fuel Shutoff Valve B Ctrl Circ/Open

P2666 Fuel Shutoff Valve B Ctrl Circ Low

Code and Meaning

P2667 Fuel Shutoff Valve B Ctrl Circ High

P2668 Fuel Mode Indicator Lamp Ctrl Circ

P2669 Actuator Supply Voltage B Circ /Open

P2670 Actuator Supply Voltage B Circ Low

P2671 Actuator Supply Voltage B Circ High

P2700 Trans Friction Element A Apply Time Range/Perf

P2701 Trans Friction Element B Apply Time Range/Perf

P2702 Trans Friction Element C Apply Time Range/Perf

P2703 Trans Friction Element D Apply Time Range/Perf

P2704 Trans Friction Element E Apply Time Range/Perf

P2705 Trans Friction Element F Apply Time Range/Perf

P2706 Shift Solenoid F

P2707 Shift Solenoid F Perf or Stuck Off

P2708 Shift Solenoid F Stuck On

P2709 Shift Solenoid F Electrical

Code and Meaning

P2710 Shift Solenoid F Interm

P2711 Unexpected Mechanical Gear Disengagement

P2712 Hydraulic Power Unit Leakage

P2713 Press Ctrl Solenoid D

P2714 Press Ctrl Solenoid D Perf or Stuck Off

P2715 Press Ctrl Solenoid D Stuck On

P2716 Press Ctrl Solenoid D Electrical

P2717 Press Ctrl Solenoid D Interm

P2718 Press Ctrl Solenoid D Ctrl Circ / Open

P2719 Press Ctrl Solenoid D Ctrl Circ Range/Perf

P2720 Press Ctrl Solenoid D Ctrl Circ Low

P2721 Press Ctrl Solenoid D Ctrl Circ High

P2722 Press Ctrl Solenoid E

P2723 Press Ctrl Solenoid E Perf or Stuck Off

P2724 Press Ctrl Solenoid E Stuck On

Code and Meaning

P2725 Press Ctrl Solenoid E Electrical

P2726 Press Ctrl Solenoid E Interm

P2727 Press Ctrl Solenoid E Ctrl Circ / Open

P2728 Press Ctrl Solenoid E Ctrl Circ Range/Perf

P2729 Press Ctrl Solenoid E Ctrl Circ Low

P2730 Press Ctrl Solenoid E Ctrl Circ High

P2731 Press Ctrl Solenoid F

P2732 Press Ctrl Solenoid F Perf or Stuck Off

P2733 Press Ctrl Solenoid F Stuck On

P2734 Press Ctrl Solenoid F Electrical

P2735 Press Ctrl Solenoid F Interm

P2736 Press Ctrl Solenoid F Ctrl Circ/Open

P2737 Press Ctrl Solenoid F Ctrl Circ Range/Perf

P2738 Press Ctrl Solenoid F Ctrl Circ Low

P2739 Press Ctrl Solenoid F Ctrl Circ High

Code and Meaning

P2740 Trans Fluid Temp SensorB Circ

P2741 Trans Fluid Temp SensorB Circ Range Perf

P2742 Trans Fluid Temp SensorB Circ Low

P2743 Trans Fluid Temp SensorB Circ High

P2744 Trans Fluid Temp SensorB Circ Interm

P2745 Intermediate Shaft Speed SensorB Circ

P2746 Intermediate Shaft Speed SensorB Circ Range/Perf

P2747 Intermediate Shaft Speed SensorB Circ No Signal

P2748 Intermediate Shaft Speed SensorB Circ Interm

P2749 Intermediate Shaft Speed Sensor C Circ

P2750 Intermediate Shaft Speed Sensor C Circ Range/Perf

P2751 Intermediate Shaft Speed Sensor C Circ No Signal

P2752 Intermediate Shaft Speed Sensor C Circ Interm

P2753 Trans Fluid Cooler Ctrl Circ/Open

P2754 Trans Fluid Cooler Ctrl Circ Low

Code and Meaning

P2755 Trans Fluid Cooler Ctrl Circ High

P2756 Torq Conv Clutch Press Ctrl Solenoid

P2757 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Perf or Stuck Off

P2758 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Stuck On

P2759 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Electrical

P2760 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Intern

P2761 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ/Open

P2762 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Range/Perf

P2763 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ High

P2764 Torq Conv Clutch Press Ctrl Solenoid Ctrl Circ Low

P2765 Input/Turbine Speed SensorB Circ

P2766 Input/Turbine Speed SensorB Circ Range/Perf

P2767 Input/Turbine Speed SensorB Circ No Signal

P2768 Input/Turbine Speed SensorB Circ Intern

P2769 Torq Conv Clutch Circ Low

Code and Meaning

P2770 Torq Conv Clutch Circ High

P2771 4WD Low Switch Circ

P2772 4WD Low Switch Circ Range/Perf

P2773 4WD Low Switch Circ Low

P2774 4WD Low Switch Circ High

P2775 Upshift Switch Circ Range/Perf

P2776 Upshift Switch Circ Low

P2777 Upshift Switch Circ High

P2778 Upshift Switch Circ Interm/Erratic

P2779 Downshift Switch Circ Range/Perf

P2780 Downshift Switch Circ Low

P2781 Downshift Switch Circ High

P2782 Downshift Switch Circ Interm/Erratic

P2783 Torq Conv Temp Too High

P2784 Input/Turbine Speed SensorA/B Correlation

Code and Meaning

P2785 Clutch Actuator Temp Too High

P2786 Gear Shift Actuator Temp Too High

P2787 Clutch Temp Too High

P2788 Auto Shift Manual Adaptive Learning at Limit

P2789 Clutch Adaptive Learning at Limit

P2790 Gate Select Direction Circ

P2791 Gate Select Direction Circ Low

P2792 Gate Select Direction Circ High

P2793 Gear Shift Direction Circ

P2794 Gear Shift Direction Circ Low

P2795 Gear Shift Direction Circ High

P2A00 O2 Sensor Circ Range/Perf Bank1 Sensor 1

P2A01 O2 Sensor Circ Range/Perf Bank1 Sensor 2

P2A02 O2 Sensor Circ Range/Perf Bank1 Sensor 3

P2A03 O2 Sensor Circ Range/Perf Bank2 Sensor 1

Code and Meaning

P2A04 O2 Sensor Circ Range/Perf Bank2 Sensor 2

P2A05 O2 Sensor Circ Range/Perf Bank2 Sensor 3

P3xxx Generic Powertrain Diagnostic Codes DTC

P3400 Cylinder Deactivation Sys Bank1

P3401 Cyl1 Deactivation/Intake Valve Ctrl Circ/Open

P3402 Cyl1 Deactivation/Intake Valve Ctrl Perf

P3403 Cyl1 Deactivation/Intake Valve Ctrl Circ Low

P3404 Cyl1 Deactivation/Intake Valve Ctrl Circ High

P3405 Cyl1 Exhaust Valve Ctrl Circ/Open

P3406 Cyl1 Exhaust Valve Ctrl Perf

P3407 Cyl1 Exhaust Valve Ctrl Circ Low

P3408 Cyl1 Exhaust Valve Ctrl Circ High

P3409 Cyl2 Deactivation/Intake Valve Ctrl Circ/Open

P3410 Cyl2 Deactivation/Intake Valve Ctrl Perf

P3411 Cyl2 Deactivation/Intake Valve Ctrl Circ Low

Code and Meaning

P3412 Cyl2 Deactivation/Intake Valve Ctrl Circ High

P3413 Cyl2 Exhaust Valve Ctrl Circ/Open

P3414 Cyl2 Exhaust Valve Ctrl Perf

P3415 Cyl2 Exhaust Valve Ctrl Circ Low

P3416 Cyl2 Exhaust Valve Ctrl Circ High

P3417 Cyl3 Deactivation/Intake Valve Ctrl Circ/Open

P3418 Cyl3 Deactivation/Intake Valve Ctrl Perf

P3419 Cyl3 Deactivation/Intake Valve Ctrl Circ Low

P3420 Cyl3 Deactivation/Intake Valve Ctrl Circ High

P3421 Cyl3 Exhaust Valve Ctrl Circ/Open

P3422 Cyl3 Exhaust Valve Ctrl Perf

P3423 Cyl3 Exhaust Valve Ctrl Circ Low

P3424 Cyl3 Exhaust Valve Ctrl Circ High

P3425 Cyl4 Deactivation/Intake Valve Ctrl Circ/Open

P3426 Cyl4 Deactivation/Intake Valve Ctrl Perf

Code and Meaning

P3427 Cyl4 Deactivation/Intake Valve Ctrl Circ Low

P3428 Cyl4 Deactivation/Intake Valve Ctrl Circ High

P3429 Cyl4 Exhaust Valve Ctrl Circ/Open

P3430 Cyl4 Exhaust Valve Ctrl Perf

P3431 Cyl4 Exhaust Valve Ctrl Circ Low

P3432 Cyl4 Exhaust Valve Ctrl Circ High

P3433 Cyl5 Deactivation/Intake Valve Ctrl Circ/Open

P3434 Cyl5 Deactivation/Intake Valve Ctrl Perf

P3435 Cyl5 Deactivation/Intake Valve Ctrl Circ Low

P3436 Cyl5 Deactivation/Intake Valve Ctrl Circ High

P3437 Cyl5 Exhaust Valve Ctrl Circ/Open

P3438 Cyl5 Exhaust Valve Ctrl Perf

P3439 Cyl5 Exhaust Valve Ctrl Circ Low

P3440 Cyl5 Exhaust Valve Ctrl Circ High

P3441 Cyl6 Deactivation/Intake Valve Ctrl Circ/Open

Code and Meaning

P3442 Cyl6 Deactivation/Intake Valve Ctrl Perf

P3443 Cyl6 Deactivation/Intake Valve Ctrl Circ Low

P3444 Cyl6 Deactivation/Intake Valve Ctrl Circ High

P3445 Cyl6 Exhaust Valve Ctrl Circ/Open

P3446 Cyl6 Exhaust Valve Ctrl Perf

P3447 Cyl6 Exhaust Valve Ctrl Circ Low

P3448 Cyl6 Exhaust Valve Ctrl Circ High

P3449 Cyl7 Deactivation/Intake Valve Ctrl Circ/Open

P3450 Cyl7 Deactivation/Intake Valve Ctrl Perf

P3451 Cyl7 Deactivation/Intake Valve Ctrl Circ Low

P3452 Cyl7 Deactivation/Intake Valve Ctrl Circ High

P3453 Cyl7 Exhaust Valve Ctrl Circ/Open

P3454 Cyl7 Exhaust Valve Ctrl Perf

P3455 Cyl7 Exhaust Valve Ctrl Circ Low

P3456 Cyl7 Exhaust Valve Ctrl Circ High

Code and Meaning

P3457 Cyl8 Deactivation/Intake Valve Ctrl Circ/Open

P3458 Cyl8 Deactivation/Intake Valve Ctrl Perf

P3459 Cyl8 Deactivation/Intake Valve Ctrl Circ Low

P3460 Cyl8 Deactivation/Intake Valve Ctrl Circ High

P3461 Cyl8 Exhaust Valve Ctrl Circ/Open

P3462 Cyl8 Exhaust Valve Ctrl Perf

P3463 Cyl8 Exhaust Valve Ctrl Circ Low

P3464 Cyl8 Exhaust Valve Ctrl Circ High

P3465 Cyl9 Deactivation/Intake Valve Ctrl Circ/Open

P3466 Cyl9 Deactivation/Intake Valve Ctrl Perf

P3467 Cyl9 Deactivation/Intake Valve Ctrl Circ Low

P3468 Cyl9 Deactivation/Intake Valve Ctrl Circ High

P3469 Cyl9 Exhaust Valve Ctrl Circ/Open

P3470 Cyl9 Exhaust Valve Ctrl Perf

P3471 Cyl9 Exhaust Valve Ctrl Circ Low

Code and Meaning

P3472 Cyl9 Exhaust Valve Ctrl Circ High

P3473 Cyl10 Deactivation/Intake Valve Ctrl Circ/Open

P3474 Cyl10 Deactivation/Intake Valve Ctrl Perf

P3475 Cyl10 Deactivation/Intake Valve Ctrl Circ Low

P3476 Cyl10 Deactivation/Intake Valve Ctrl Circ High

P3477 Cyl10 Exhaust Valve Ctrl Circ/Open

P3478 Cyl10 Exhaust Valve Ctrl Perf

P3479 Cyl10 Exhaust Valve Ctrl Circ Low

P3480 Cyl10 Exhaust Valve Ctrl Circ High

P3481 Cyl11 Deactivation/Intake Valve Ctrl Circ/Open

P3482 Cyl11 Deactivation/Intake Valve Ctrl Perf

P3483 Cyl11 Deactivation/Intake Valve Ctrl Circ Low

P3484 Cyl11 Deactivation/Intake Valve Ctrl Circ High

P3485 Cyl11 Exhaust Valve Ctrl Circ/Open

P3486 Cyl11 Exhaust Valve Ctrl Perf

Code and Meaning

P3487 Cyl11 Exhaust Valve Ctrl Circ Low

P3488 Cyl11 Exhaust Valve Ctrl Circ High

P3489 Cyl12 Deactivation/Intake Valve Ctrl Circ/Open

P3490 Cyl12 Deactivation/Intake Valve Ctrl Perf

P3491 Cyl12 Deactivation/Intake Valve Ctrl Circ Low

P3492 Cyl12 Deactivation/Intake Valve Ctrl Circ High

P3493 Cyl12 Exhaust Valve Ctrl Circ/Open

Fuel Pressure Compensation

Minimum oil pressure protection

Minimum oil pressure after start

Rev limiters

Hard cuts

Fuel cut

Spark cut

Both cut

Soft limiting

ETB soft limit

Basic Features

Basic Features

Cranking control

4 items

Idle control

6 items

Bench Test Commands

Boost Control

Before you start tuning the boost control, it is essential the make sure that you have a safe boost cut pressure set under Base Engine > Limits and Fa...

Cylinder Bank Selection

Data logging settings

Basic Data logging settings

Fan Controllers

Fuel Pump Control

General Purpose PWM (GPPMW)

 **Main Relay Control**

Cranking control

Cranking control

Cranking fuel

3 items

Advanced Cranking Features

Cranking Idle Air Control

Cranking RPM Limit

Cranking fuel

Cranking fuel

 **Cranking Duration Fuel Multiplier**

 **Cranking Fuel Coolant Multiplier**

 **Fuel priming pulse**

Cranking Duration Fuel Multiplier

Cranking Fuel Coolant Multiplier

Fuel priming pulse

Advanced Cranking Features

Cranking Idle Air Control

Cranking RPM Limit

Idle control

Idle control

Advanced Idle Control Features

Idle tables for cranking taper

Idle Control Hardware

Solenoids

Idle Specific Ignition Table

The idle ignition table acts much like the open loop idle control in the regard that it is another open loop system contributing to the idle of the vehicle...

Idle settings

The idle settings menu can look daunting at first but this guide will help to decode the mystery of all the various idle settings.

Idle Tuning

One of the most challenging aspects of achieving optimal engine performance is idle tuning. Unlike fueling, which can be quantified with instrumenta...

Idle Specific VE Table

image

Advanced Idle Control Features

Idle tables for cranking taper

Coasting Idle tables

Idle Control Hardware

Solenoids

Single wire

Dual wire

PWM frequency

Stepper Motors

Dedicated stepper hardware

Step pin, direction, mode, enable etc

Dual H bridge

Direction 1/2, disable etc

PushPull outputs

Stepper a+,b+,a-,b- etc

Idle Specific Ignition Table

The idle ignition table acts much like the open loop idle control in the regard that it is another open loop system contributing to the idle of the vehicle. Adjusting the engine ignition timing at idle changes the engine torque output where an increase in timing produces more torque and a reduction reduces the torque. This change in torque can be used to adjust the engine speed and achieve a stable idle by reducing the timing above the idle RPM target and increasing it below the target.

Before tuning the ignition table, make sure to have your base open loop idle position set.

To tune the ignition table, start by setting the maximum and minimum values about 500RPM above and below your target idle speed. At your target idle speed, put in your desired timing angle. 10 degrees is a good starting point but a higher timing angle such as 14 degrees will give the engine a bit more torque at idle which helps the engine to quickly rev up from idle. Start by making a linear curve between the maximum and minimum RPM values in the table with values in the range of 20 to 5 degrees. As all engines respond differently, you may want to use different starting values but these are good generalizations. Run the car with your values and see how well it maintains idle. Start to adjust the timing values so that the timing pushes and pulls the engine RPM to the target. You may need to change the shape of the curve so that only small timing adjustments are made near target and large corrections are made if the RPM significantly deviates.

Idle settings

The idle settings menu can look daunting at first but this guide will help to decode the mystery of all the various idle settings.

Idle target RPM

TPS threshold

RPM upper limit

RPM deadzone

Max Vehicle speed for idle

Idle Tuning

One of the most challenging aspects of achieving optimal engine performance is idle tuning. Unlike fueling, which can be quantified with instrumentation like an AFR gauge, idle tuning involves tweaking a range of options to achieve a specific RPM. However, the choices made in the tuning process have a significant impact on the stability and robustness of the engine's idle.

Idle can be compared to a see-saw with three main factors affecting it: fuel, ignition, and air. These elements determine the amount of torque produced by the engine, which in turn affects idle stability. To maintain a steady idle, the torque output must also remain relatively constant. Essentially, idle represents a state of balance, where the motor's load (caused by internal friction, accessories like the alternator, AC, torque converter/trans pump, or supercharger) is counterbalanced by the amount of torque generated by the engine. When load and torque are equal, there is no net acceleration, and the RPM remains constant. In essence, this is the overall concept to grasp.

Prerequisites to a Stable Idle

The foundation for a stable idle is reliant on a motor that already runs well. Before tuning the idle, there are several features which must be tuned relatively well first.

Battery Voltage

Battery voltage tends to be lowest at idle because the alternator is spinning at a slower speed. As a result, voltage can fluctuate frequently, especially when electrical loads such as blower motors and headlights are turned on or off. It is essential to fine-tune the battery and alternator control settings to prevent sudden AFR swings due to voltage changes. This can be challenging to tune, but intentionally creating electrical loads by turning on the headlights, AC or blower fans is a good way of changing the alternator load so it can be tuned to output a near constant voltage under all conditions.

Idle Detection Thresholds

Within the idle settings, the first set of parameters to configure are the idle detection thresholds. These are a set of conditions which must be met for the ECU to establish that the car is idling. The first is the *TPS Threshold (%)* and is the maximum throttle position for idle to be enabled. After calibrating your TPS through *Tools > Calibrate TPS*, 1-2% is a good range to set this to. The *RPM upper limit* is the maximum RPM above the idle target that will still be considered idle. Typically 300-500 RPM is a good range so that the car won't move out of idle if the AC or another load requiring an RPM increase is enabled. *RPM deadzone* is the range around target in which the closed loop controllers will be disabled to prevent oscillations. 50-100 RPM is a good range here but this is discussed later. The *Max vehicle speed* dictates the maximum vehicle speed which can be considered idling. Setting this to 20-40 Kph prevents a scenario where the car is slowing down, still in gear, and the car goes into idle which tries to

drag the RPM down and can lead to an idle droop when the clutch is pressed in.

Idle AFR

The quality of the fuel and ignition tuning around and inside the idle region can significantly impact idle stability. It is crucial to tune the fueling in and around the idle region to maintain a consistent AFR, as any changes in AFR due to load or RPM can also affect the torque output. It is recommended to enable the *Idle VE Table* so that the fuelling in the idle region can be more finely tuned. Like tuning the battery voltage, you want to intentionally create more loads on the engine to tune the idle VE values for different loading conditions. You can get this relatively dialled in however, it is likely that this table will need tweaking during the idle tuning process to maintain stable AFRs in idle. It is also important to merge the edges of the idle VE table with your normal VE table so that the fuelling transitions coming off idle are constant.

Idle Air Control Valve Offsets

Load can vary during idle and AC is the most significant factor that can significantly impact the engine load at idle. For engines equipped with an automatic transmission, the load in park/neutral is significantly different from that in drive. It is usually necessary to add IAC duty cycle/air to compensate for the torque required to spin the AC compressor. Again, it is crucial to ensure that AFRs don't swing excessively when moving between different idle operational areas. In the idle settings, start with about 10-15% for the *AC adder (%)* parameter. As the AC increases the alternator load, the engine torque also needs to increase when the AC is

enabled so it is recommended to do this by increasing the engine RPM by 100-200 with the *AC target adder (RPM)*. The cooling fans also have associated adders (*Fan #x adder(%)*) although these don't usually need to be increased unless you notice a significant drop in RPM when the fans come on.

Open Loop Idle

Tuning the open loop idle is the first step in achieving a stable idle. In some cases, an open loop idle may be good enough for your purposes although it is highly recommended to set up a closed loop idle after perfecting the open loop. To start with, you must decide on what RPM the engine should idle at. To determine this, you must consider various factors such as flywheel and rotating inertia, driven accessories via belt or gear, noise level, personal preference, among others. It may involve an iterative process of selecting a target RPM, attempting to achieve it, and revising expectations. Generally, higher RPM idling is more manageable because the engine produces more torque. Although it is not used in the open loop idle configuration, open the *Target RPM* table in the idle settings and put in the target RPM you decided on. In the table, it is recommended to taper the idle RPM from about 200 RPM higher than target when the coolant temp is at about 20C to the actual RPM target at 60C approximately. This is to compensate for the extra drag on the engine as it heats up and the tolerances become looser.

Idle Airflow

The first step of tuning the idle RPM is to set up the open loop idle airflow. Suppose you aim to set the engine to idle at 800 RPM (minimum), the

airflow must be tuned to make the engine idle 50-150RPM higher than the 800 RPM target. This can be done by adjusting the *Open loop base position (%)* parameter, the idle adjustment screw, or the throttle end stop. It is recommended to tune these adjustments so the *Open loop base position (%)* parameter (which is the base duty cycle of the IACV) is at about 30% when the engine is idling 50-150RPM above target. This gives some room for the closed loop controller to adjust the duty cycle. It's essential to ensure that AFRs remain stable as you adjust the airflow. Before enabling idle control, a stable foundation is necessary. In this example, we will say that the engine idles at 950 RPM (150 RPM above target) with 10 degrees of timing, 1.0 lambda and 30% IACV duty cycle.

Idle Ignition Table

The idle ignition table acts much like the *open loop base position* in the regard that it is another open loop system contributing to the idle of the vehicle. Adjusting the engine ignition timing at idle changes the engine torque output where an increase in timing produces more torque and a reduction reduces the torque. This change in torque can be used to adjust the engine speed and achieve a stable idle by reducing the timing above the idle RPM target and increasing it below the target.

To tune the ignition table, start by setting the maximum and minimum values about 500RPM above and below your target idle speed and interpolate the values between these. At your target idle speed in the table, put in your desired timing angle. 10 degrees is a good starting point but a higher timing angle such as 15 degrees will give the engine a bit more torque at idle which helps the engine to quickly rev up from idle. The idle timing angle will vary from engine to engine so it is always worth researching what others have used on your specific engine.

The next step is to fill in the remaining cells of the idle timing table. At the minimum RPM, a value of 20 degrees is recommended as this is roughly where maximum brake torque (MBT) is. To fill in the gaps between the minimum and target RPM, use the interpolation button. For the maximum engine RPM value, a value in the range of 0-10 degrees less than the target is recommended (do not go below 0 degrees of timing). Once again, interpolate the values between the maximum RPM and target. For the RPM values above idle target, if you have AC, it can actually be beneficial to leave the spark angles as the same as the idle target. This allows the engine to idle up and increase the torque to compensate when the AC is enabled. If the timing reduces above target, the idle air valve (when tuned for closed loop) may need to compensate more for the extra load on the engine.

Run the car with your values and see how well it maintains idle. Give it a few throttle blips to see how the idle settles. Start to adjust the timing values so that the timing pushes and pulls the engine RPM to the target and stabilizes within 50 RPM. You may need to change the shape of the idle timing curve so that only small timing adjustments are made near target and large corrections are made if the RPM significantly deviates. The trick is to essentially make a table of accurate guesses for what the timing will need to be in order to kick the engine RPM back to the target. The better your guesses are, the less work the closed loop timing controller will need to do when you implement it.

Closed Loop Idle

Closed loop idle control uses a combination of closed loop timing adjustments and idle air control valve adjustments to achieve a stable

idle. Achieving a stable idle can be difficult as it requires tuning two separate controllers which operate in parallel to control the engine RPM. The best way to achieve a good idle is to use the closed loop idle timing for the larger and quicker corrections with the idle air controller acting to compensate for slower changes.

Before tuning the closed loop idle, you need to have properly tuned the idle VE, idle ignition table and open loop idle control. To tune the closed loop controllers, you also need some understanding of a closed loop controller called a PID controller. [This video by RC Model Reviews](#) perfectly explains PID controllers in basic terms.

Closed Loop Timing

It is now time to turn on closed loop idle timing. It's important to note that closed loop idle should not make significant changes all the time for a stable idle. However, closed loop idle timing adjustment is crucial for long-term stability, and it's necessary to keep the engine idling when changes occur such as AC, headlights, fans, etc. Closed loop idle timing relies heavily on the proportional gain with little to no derivative gain to act as a damper. A good place to start is with a proportional gain of 0.1 and a derivative gain of 0.05. For every engine, these values will need to be varied until the idle remains stable within 50 RPM of the target. To ensure the closed loop idle doesn't cause issues such as knocking, it's recommended to set boundaries on timing with an overall minimum and maximum adjustment from the open loop table values. A good starting point is a -5 degree minimum and +5 degree maximum but these can be increased up to 10 degrees if you need more aggressive control.

Closed Loop Idle Air

Closed loop idle air control is a powerful tool, but one that requires extreme caution as it can dramatically impact the engine RPM. Even small changes in airflow can have a significant impact, and this is compounded because the speed which an electronic throttle body or idle valves operate is much slower than spark control. To effectively use closed loop air control, a deadband of about 50-100RPM must be established around the target to allow for minor corrections to work.

In the *Closed Loop Idle* box in the idle settings, the controller should be set up with a very small proportional gain and a sufficiently larger integral gain. This ensures that the idle air controller reacts slowly and only to relatively large disturbances which the closed loop timing cannot compensate for itself. You may need a very small derivative gain however the controller should react slowly enough that it might not be necessary.


One of the things to be wary of here is that an integral dominated controller can suffer from a phenomenon known as windup where the integral gain becomes very large if the RPM stays high or low for a long period of time. This causes the RPM to massively overshoots the target. To mitigate this, you can clamp the amount which the integral term can increase or decrease the IACV duty cycle by. A safe recommendation is to set the *iTerm Min* & *iTerm Max* to $-/+10$ respectively but anywhere up to $-/+20$ should be reasonably safe.

To assist in the overall effectiveness of the controller, the minimum and maximum duty cycle variation of the entire idle air controller can be clamped. This effectively limits how fast and with how much force the idle

controller is allowed to increase or decrease the RPM. A safe range for the *Min* and *Max* is -10 and 20 respectively however these values can be changes around if the controller is responding more or less than you desire. For example, sometimes it is worth putting the maximum to a value such as 50 so that the controller has the authority to bring up the RPM if it gets sufficiently low.

Another setting of interest that should be used sparingly is the *PID Extra for low RPM(%)*. This effectively gives the controller a kick if the RPM gets too low and needs to take dramatic action. This parameter can be used to compensate for the recommended small proportional gain which is usually responsible for kicking the RPM up if it deviates too far from target. Realistically a well tuned idle controller shouldn't need this but the world isn't perfect so this serves as a band-aid for scenarios where the controller is struggling to increase RPM and is at risk of stalling. Normally, set this to 0% but if you absolutely can't fix an idle drooping problem, experiment with values up to 100% gradually increasing the percentage until the idle is kicked up to around target. Be sparing with this as a high percentage can kick the RPM way above target causing an unstable idle.

Idle Specific VE Table



The screenshot shows a software window titled "Idle VE" with a menu bar containing "File" and "View". Below the menu bar, there is a "3D View" checkbox which is currently unchecked. A toolbar with various icons is visible above the table. The table itself is a 4x4 grid with the following values:

60	68.3	68.3	68.3	68.3
50	68.3	68.3	68.3	68.3
40	45.0	49.9	54.9	68.3
35	45.0	48.6	52.3	55.0
↩	900	950	1000	1100

Below the table, the text "RPMValue" is centered.

The idle specific VE table is a smaller 4x4 table referenced only when the engine is operating in the idle condition. As the engine is under very little load during idle, changes in engine load can have a significant effect on the AFR. These loads can be from the air conditioning compressor engaging or from the alternator duty cycle increasing from extra electrical loads such as cooling fans, headlights or even electric windows. By adjusting the idle VE table to encapsulate the finite idle RPM and load ranges, you can tune the idle to operate close to the AFR target regardless of the engine load.

To tune the idle VE, make sure *closed loop fuel correction* under *Fuel* is disabled. Proceed to warm the car up and switch off all cooling fans, headlights and air conditioning. Tune the corresponding idle VE table cells until the AFR target is reached. Now turn on the accessories one by one, tuning the corresponding cells the idle VE table. Next repeat this process

with multiple accessories on at once such as the air conditioning and headlights. Once the cells have been tuned, interpolate to fill any unused cells and smooth the cells together. In the circumstance that engaging the accessories has a large effect on the AFR, you may not be able to smooth the table much.

Bench Test Commands

Boost Control

Before you start tuning the boost control, it is essential to make sure that you have a safe boost cut pressure set under *Base Engine > Limits and Fallbacks*. Within this menu, it is also recommended to set only fuel to be cut on the RPM limit as cutting fuel and spark can lead to excess fuel igniting inside the turbine housing causing excess wear to the turbo.

Electronic boost control (EBC) is a method of controlling a vehicle's boost from an ECU or boost controller. EBC allows for more precise control of boost resulting in the ability to reduce spool up time, set the boost to an exact figure or tune the boost to flatten a torque curve.

Boost Control Options

Three Port Boost Control Solenoid

A three port boost control solenoid works by quickly alternating between diverting boost pressure to atmosphere and to the wastegate. By adjusting the duty cycle or time spent diverting air to atmosphere, the solenoid effectively changes the boost pressure that the wastegate sees allowing it to stay closed for up to three times the wastegate spring pressure.

For most vehicles, this is the most common method of electronic boost control as it is cheap, can be easily plumbed into most turbos and for the most part does a good job of controlling the boost.

A three-port boost solenoid has three ports: an inlet port, an outlet port, and a control port. The inlet port is connected to the turbocharger outlet, the outlet port is connected to the wastegate actuator, and the control port is connected to the ECU. The ECU sends a signal to the control port to regulate the amount of boost pressure produced by the turbocharger.

Four Port Boost Control Solenoid

A four-port boost solenoid has an additional port, known as a reference port. The reference port is connected to the intake manifold or the atmosphere, and it provides a reference pressure to the boost solenoid. The boost solenoid uses this reference pressure to regulate the boost pressure produced by the turbocharger. The four-port design allows for more precise control over the boost pressure to a three port solenoid because it takes into account the reference pressure in addition to the control signal from the ECU. By bleeding off excess pressure when needed, the four-port boost solenoid can maintain a consistent and accurate boost pressure, resulting in better performance and reliability for the turbocharged engine.


Electric Wastegate Actuator

An electric wastegate actuator replaces a conventional spring based wastegate with an electric actuator to regulate the boost pressure.

Open Loop Boost Control

Open loop boost control is the simplest form of electronic boost control where the boost control solenoid is assigned a specific duty cycle based

on the engine RPM and throttle pedal position. With open loop control, you need to guess what duty cycle will correspond with your desired boost pressure and work from there. An example of an open loop boost control table is shown below.



Tuning Open Loop Boost Control

Before you start tuning the boost, consider what you are looking for the boost controller to do. Do you want the fastest possible spool up? Do you

want the boost to come on all at once or progressively build up? Do you want to accelerate as fast as possible right on the limit of grip or to spin the tyres?

1. Decide what the minimum boost pressure you want to run will be and install the corresponding wastegate spring.
2. Disconnect any boost control solenoids and connect the wastegate directly to a source of boost pressure.
3. Verify that the boost cut works by setting it to a low value such as 100kPa. Once verified that it works, move it 10-20kPa above your desired boost pressure.
4. Take the car for a drive doing a range of pulls and take notice of how the boost responds. In first and second gear, when does the car move into boost and when does it stabilize? In higher gears, when does the car move into boost and when does it stabilize? Once the boost stabilizes, does the boost curve increase, decrease or stay flat? As an example, say that you have a turbo Miata running at sea level (100kPa atmospheric pressure) and the turbo moves into positive boost at 2000RPM and stabilizes at 3500RPM where it stays at 150kPa (50kPa or ~7PSI of boost) until redline.
5. The safest way of determining the ideal duty cycle for your boost goals is to start at the minimum and work up from there. Start by setting every cell on the open loop table to 20% duty cycle and do several full throttle pulls in 2nd-4th gear noting the boost it reaches. 20% is generally the minimum duty cycle the solenoid needs to run and this can be tested by turning the key to *On* and with the engine off, push the throttle listening for the solenoid clicking. Gradually

increase the duty cycle in steps of up to 5% until the car reaches your desired boost pressure at full throttle.

6. Once the desired boost pressure is reached, look at how the boost curve moves once it stabilizes. If it continues to rise past target pressure, progressively raise the duty cycle in the table as the RPM increases. If the boost drops, do the opposite and raise the duty cycle as the RPM increases. Continue to adjust the duty cycles until the stable boost stays within 5-10kPA of target.
7. In your boost control table, decide on the minimum throttle position where you would like the boost control to activate. 40-50% is generally a good starting point. Below the starting point, set every cell to zero. At the starting throttle position row, set the duty cycle to the minimum duty cycle required to operate the boost solenoid which is usually 20%. Now interpolate vertically between the minimum boost throttle position row to the 100% throttle position row so that at in a given RPM column, the duty cycle will increase as the throttle is pushed more.
8. Optionally for a fast spool up time, recall what RPM the boost reached target in 3rd or 4th gear. Now rescale the table by so that the new lowest or second lowest RPM column is 1000RPM below the boost target and the second or third RPM column corresponds to the RPM when the boost target is reached. Set the columns below target boost to 100% and test it out with some pulls in different gears. Progressively raise the RPM of the 100% duty cycle columns as much as you can before the boost goes above the target pressure and leave them there. It is recommended to back off the 100% duty cycle RPM slightly from the absolute highest it can be as a factor of safety. To

make transition to boost smoother, the 100% duty cycle columns can also be vertically interpolated between 100% and a lower duty cycle such as 50% at the minimum boost RPM.

Closed Loop Boost Control

Closed loop boost control builds on the open loop boost controller and actively adjusts the solenoid duty cycle to reach the specified target pressure. The controller starts at the specified duty cycle in a given cell in the open loop table and adds or subtracts to that value until the target pressure is reached. The closed loop boost controller uses a PID controller to adjust the duty cycle. A PID controller works by measuring the error between the measured boost and the desired boost and calculating values for the P, I and D terms based off of the error. These terms are then added together to form the calculated duty cycle which the controller will measure the boost pressure response to and will continually adjust its calculated duty cycle until the target pressure is achieved.

The P-term multiplies the duty cycle per kPa of error. For example, if P is set to 0.2 and there is a 20kPa error, it will add a value of $0.2 * 20 = 4\%$ to the duty cycle.

The I-term multiplies the duty cycle by the kPa of error and the seconds that there is error. For example, if I is 0.1 and there is 10kPa of error for 2 seconds, it will add a value of $0.1 * 10 * 2 = 2\%$ to the duty cycle.

The D-term multiplies the duty cycle by the kPa of error per second (or rate of change of kPa). For example, if D is 0.2 and the boost is rising at 10kPa per second, a value of $0.2 * 10 = 5\%$ would be subtracted to the

duty cycle to slow the rate of approach to the target.

Cylinder Bank Selection

Data logging settings

Basic Data logging settings

SD card logging

**Diagnostic and High speed
logger**

Fan Controllers

Fuel Pump Control

General Purpose PWM (GPPMW)

Main Relay Control

Advanced Features

Information on all sensor inputs and data outputs

ETB

6 items

VVT

3 items

CAN

What is CAN and CANBUS?

Cylinder Angle Offset Configuration

Manual configuration of the cylinder bank angles for oddfire and difficult engines.

Debug Mode

Debug mode is planned to be obsoleted.

Fuel-Related

5 items

GDI

1 items

Knock Control

LUA Scripting

For a basic introductions see this wiki section.

 **Launch Control**

Or how to break your gearbox and engine

 **MAP Sampling Angle** **Multi Dimension Mapping**

Basic outline

 **Override VE. Ignition and AFR table axis** **Rotary**

1 items



Smart Alternator Control



Spark-Related

1 items

ETB

Electronic Throttle Body

Electronic Throttle Bias Table

ETB feed forward setup

Idle control using ETB

All features needed to do ETB idle control discussed here, needs to cover the way ETB changes some of the basic idle settings to function differently ...

ETB PID and Autotune

ETB pedal target mapping

Electronic Throttle Settings

ETB enable/disable

Redundant Sensors for ETB Position

Reason for redundancy in ETB position sensing

Electronic Throttle Bias Table

ETB feed forward setup

Idle control using ETB

All features needed to do ETB idle control discussed here, needs to cover the way ETB changes some of the basic idle settings to function differently when ETB idle is operational.

ETB PID and Autotune

ETB pedal target mapping

Electronic Throttle Settings

ETB enable/disable

H-bridge function

PWM frequency

**ETB idle - See Idle control using
ETB page**

ETB PID - See ETB PID page

Redundant Sensors for ETB Position

Reason for redundancy in ETB position sensing

Basic redundant sensors

Things like 0.5-4.5v with inverted or half value signal for the secondary

Ford Redundant TPS Mode

Ford Pedal and ETB with the weird cut off on the secondary signal

VVT

Variable Cam Timing

 **On/Off VVT Control**

 **VVT PID Control**

 **VVT Target Tables**

On/Off VVT Control

VVT PID Control

VVT Target Tables

CAN

What is CAN and CANBUS?

CAN (Controller Area Network) is a robust vehicle bus standard designed to facilitate communication among various components without a host computer. It is used in many modern cars, and is a great way to get data from the car to the **ECU**. It is also a great way to get data from the **ECU** to other devices, such as a dash, or a data logger.

CANBUS / CAN bus, or Controller Area Network Bus, refers to the physical medium (wires and connections) through which the CAN protocol operates. It's the network of interconnected CAN devices within a vehicle or industrial setup.

DBC

A **DBC** (Database Container) file is a standard file format used in the context of Controller Area Network (CAN) networks. It contains information about messages and signals that can be transmitted over a CAN network.

In a **DBC** file:

- Messages represent specific packets of data sent over the CAN network, each identified by a unique ID.
- Signals are individual pieces of data within messages, specifying the data's name, start bit, length, endianness, and other attributes. Signals

can represent information such as vehicle speed, engine RPM, or sensor readings.

FOME's DBC file

🚫 SOURCE

[FOME-Tech/fome-fw/blob/master/firmware/controllers/can/FOME_CAN_verbose.dbc](#)

Loading...

Cylinder Angle Offset Configuration

Manual configuration of the cylinder bank angles for oddfire and difficult engines.

Debug Mode

Debug mode is planned to be obsoleted.

Replacement are log channels.

Debug mode is an advanced troubleshooting feature allowing one to monitor the internal state of some FOME subsystems.

In TunerStudio, select "Base Engine Settings -> Debug Mode" and use the gauges from "Debug" category.

Barometric-Pressure- Compensation

Charge Temperature Estimation

Closed Loop Fuel Correction

Injection Phase Settings

Injector Testing Mode

Not sure if we keep this?

High Pressure Fuel Pump Settings

Knock Control

LUA Scripting

For a basic introductions see [this wiki section](#).

For examples see [files in example directory](#).

Launch Control

**Or how to break your gearbox
and engine**

MAP Sampling Angle

Multi Dimension Mapping

Basic outline

Multiplier and Bias tables

VE multiplier

Ignition Adder

What can be done with them

Flex-Fuel or Dual Fuel

ITB TPS blending

Something Wacky

Override VE. Ignition and AFR table axis

Rotary engine specific settings

Smart Alternator Control

Multispark

Fuel

Fuel

Fuel algorithms

3 items

Fuel settings

10 items

Acceleration

2 items

Fuel algorithms

Fuel algorithms



AlphaN fuel



MAF based fuel control

Current Status



Speed Density Based fuel control

AlphaN fuel

MAF based fuel control

Current Status

The MAF based fueling of FOME is still undergoing development, the current status has the fueling functioning correctly but presents a few tuning challenges due to TunerStudio integration and the Spark Table still being reliant on the old engine load math.

This is an evolving situation at present and thus MAF fueling is still considered experimental.

Please only use for development work at your own risk.

MAF fuel theory - The detail

The implementation of the MAF in FOME is intended to replicate the functionality of OEM systems and as such is more complex than some other systems.

The foundation of the MAF system is the Mass Air Flow sensor itself, this is a device using a hot wire, hot film or vane to directly measure the flow of air into the engine. Obviously this sensor does not give out an airflow value, it gives us a voltage, current or PWM signal that represents the flow. FOME can interpret a voltage or current MAF at this time via a transfer function table.

The Transfer function table is used to convert the raw MAF sensor reading into a Kg/h (Kilogram Per Hour) airflow.

This Kg/h value is then processed into a required fuel quantity by the following calculations:

$$\text{g/s} = \text{Kg/h} * 1000 / 3600$$

$$\text{n/s} = \text{rpm} / 60$$

$$\text{airPerRevolution} = \text{g/s} / \text{n/s}$$

$$\text{cylinder Airmass} = \text{airPerRevolution} / \text{half Cylinder number}$$

In FOME we use a correction factor table to modify this measured air mass to allow correction of any errors in the measurement due to dynamic air flow effects. To do this we need to have a "load" value that allows us to have a Load Vs Speed fuel table.

$$\text{StandardAirCharge} = \text{engine displacement} / \text{number of cylinders} * 1.2929$$

This produces the air mass for cylinder filling at 100% VE under standard SAE conditions. Using this we can relate our cylinder air mass back to a standardised 100% cylinder filling and thus we have a "load" value to use when tuning.

$$\text{airChargeLoad} = 100 * \text{cylinder Airmass} / \text{Standard AirCharge}$$

The required fuel is now simply corrected by adjusting the measured air by the value in the VE table, this value is simply a %.

$$\text{corrected Cylinder Airmass} = \text{cylinder Airmass} * (\text{VE map value} / 100)$$

$\text{fuelMassGram} = \text{corrected Cylinder Airmass} / \text{desired AFR}$

$\text{pulse Width} = \text{fuelMass} / \text{injector flow (in g/s)}$

Using this method FOME is able to directly measure the air flow into an engine and calculate the required fuel with minimal tuning.

MAF fuel tuning - The quick version

To tune FOME using the MAF is probably the quickest and easiest method provided you have a working MAF sensor and the correct information to input in the Transfer Function Table.

The first thing to do is input the voltage (or current) to Kg/h information into the Transfer Function Table in TunerStudio.

Secondly you will need to decide what Air/Fuel ratio you would like your engine to run at and input this into the AFR table in TunerStudio. For a first start a value of 14 is perfectly acceptable for gasoline. This table is the primary source of the desired fuel mixture, it will be this table that is tuned to decide the engines target AFR. A future update will make this fueling table dynamic so that an input % of ethanol in the main fueling dialog will change the fuel density and thus the required fuel mass injected. The result of this will be that users can leave this table tuned as though it were for pure gasoline (14.7:1 stoichiometric) and the % ethanol input will make sure the fuelling stays at the same Lambda value. This has the advantage of working well with aftermarket wideband controllers that generally work in AFR using pure gasoline as the standard.

Before starting the engine for the first time it is wise to ensure the Fuel Table is filled with values of "100", a value of 100 means that the fuel calculation uses 100% of its measured air mass to decide on the fuel injection pulse.

Tuning this table will adjust for dynamic airflow effects that happen in the inlet of an engine and will allow small (or large but hopefully not) corrections to the fuel injection which may be required to have the engine meet it's desired air/fuel target.

This table should only be tuned if the engine is not meeting the desired air/fuel target under relatively steady state conditions (i.e. without any acceleration enrichment or overrun fuel cut). If a different air/fuel ratio is desired at a specific load or RPM then the AFR Table is the correct table to adjust instead.

Some useful MAF sensor maths in [this link](#)

Speed Density Based fuel control

Fuel settings

Fuel settings

 **Air Fuel Ratio Setting**

 **Coolant Temperature Multiplier**

 **Individual Cylinder Trim**

 **Deceleration fuel cutoff**

 **How flex fuel works in FOME**

Place to cover the flex fuel, how it works and how it is related to the multidimensional mapping.

 **Fuel injection Mode**

Place to cover the simultaneous, batch and sequential fuel injection

 **TPS fuel multiplier** **Intake Air Temperature Fuel Multiplier** **Fuel injector dead time settings** **Small Pulse Width correction**

Polynomial

Air Fuel Ratio Setting

Coolant Temperature Multiplier

Individual Cylinder Trim

Deceleration fuel cutoff

How flex fuel works in **FOME**

Place to cover the flex fuel, how it works and how it is related to the multidimensional mapping.

Fuel injection Mode

Place to cover the simultaneous, batch and sequential fuel injection

TPS fuel multiplier

Intake Air

Temperature Fuel

Multiplier

Fuel injector dead time settings

Small Pulse Width correction

Polynomial

2 slope/Ford method

Acceleration

Acceleration

 **TPS Based Acceleration Correction**

 **Wall Wetting Based Acceleration Compensation**

TPS Based Acceleration Correction

Wall Wetting Based Acceleration Compensation

Hardware

Hardware

Flashing Software Notes

Some boards, notably those with processors utilizing certain dual bank memory layout, like the STM32F7, suffer from an

Hardware-Circuits

8 items

Hardware-Details

6 items

Flashing Software Notes

NOTE

Some boards, notably those with processors utilizing certain dual bank memory layout, like the STM32F7, suffer from an issue such that flashing does not succeed correctly, due to an error with the erasure mechanism. For these situations, manually erase the flash memory before flashing; i.e. perform a full/mass erase procedure first.

While the FOME console is the recommended and officially supported way to update FOME firmware on supported boards, other mechanisms exist to flash firmware to board supporting FOME. These tools are also useful in odd situations, like the event of a firmware update/flash failure, or some other firmware corruption issue, such that FOME console nor TunerStudio recognize the ECU when connected.

For the ECU, you will need to access buttons or pins on the main board to force the processor into bootloader/DFU mode. Some boards use a momentary button, likely near to the reset button, to force this mode during power-up. Others might use a set of pins or pads that need shorted to force this mode during power-up. Press the button or short the pins with the ECU disconnected from the computer, then simultaneously connect the ECU into the computer. Once connected, the button can be released or the short removed.

STM32CubeProgrammer

STM32CubeProgrammer is an officially STMicroelectronics supported tool to flash STM32 processors. Information about and how to download and install the tool can be found on [the STM wiki](#).

In STM32CubeProgrammer, select the *USB* tab on the right and refresh the port in the right side menu until a DFU is detected. Click *Connect* to connect the ECU to the programmer. Click the *Read* button to read the device memory and to validate that the ECU is connected.

Once validated, choose the *Open File* button and load the file marked *fome.bin* within the firmware bundle downloaded earlier. This is a binary file containing the ECU firmware. Now choose the *Download* button to write this firmware to the ECU. Give it up to several minutes to download and once the status console confirms successful download, disconnect from the programmer then unplug the ECU and plug it back in. The ECU should now connect to the computer and TS normally again.

dfu-util

dfu-util is a free software tool to flash Device Firmware Upgrade (DFU) compatible devices, including STM32 processors. It supports most popular operating systems, including MacOS and Linux. Information about dfu-util can be found on [the dfu-util website](#).

Updating with dfu-util is as straight-forward as invoking it like so:

```
dfu-util -v -d 0483:df11 -a 0 -D fome.dfu -s :leave
```

Note that the `:leave` option does not always work, which would otherwise automatically instruct the processor to leave DFU mode and load the firmware; the board must be manually reset to load the flashed firmware.

To erase a device, use the following invocation:

```
dfu-util -v -d 0483:df11 -a 0 -s :mass-erase:force
```

Discrete-VR

High-Low Driver Circuits

Highside Driver Circuits

Lowside Driver Circuits

PT2001 Low-Z driver

12v, 5v and 3.3v regulation circuits

STM32 Compatibility with FOME

What to write in this section

Details on our various generic driver layouts, what they are and the basics of how they work.

Base Boards

Brain Boards

BeerMoneyMotorsports CAN gauge

A page to outline the hardware and wiring of the BMM KaN Multi Fit CAN gauge.

[BMM: KaN Pinout and Wiring](#)

FOME low-z injector driver

Details on the low impedance injector driver board, its wiring and function

Power steering controller

Wide Band Lambda Module

Ignition

Ignition

Ignition-Hardware

3 items

Ignition-Settings

7 items

Ignition-Types

4 items

Ignition Modules

place for listing known good ignition modules

Ignition coils

Place for listing known good ignition coils

Smart and Dumb Coils

Dwell settings

How to correctly configure the firing order and ignition pins

Place to describe the correct settings of firing order with regard to the pin config.

Intake Air

Temperature Ignition

Adder

Ignition advance table

Ignition coolant correction

Ignition Cylinder Trim

Ignition Mode

See Ignition Types Section?

Individual coils

Something to explain individual coils can be set up in either wasted or sequential

Sequential ignition mode

Single coil or distributor ignition

Wasted spark ignition mode

Vehicle Specific

Vehicle Specific

 **Mazda-MX5-Miata**

5 items

Miata MX5 Quick Start Guide

So, you've just got yourself a shiny new BMM MX5 Miata ECU for your NA or NB, nice! If you're wondering how to install and get it running, you've come to the right place. This guide will cover how to install the ECU to the car with a Bosch LSU 4.9 wideband oxygen sensor and a mass air pressure (MAP) line. Installation of additional sensors or peripherals is covered in the advanced guides.

NOTE: Before commencing the ECU installation, it is recommended to jack up the car or drive it onto ramps in the case when the oxygen sensor location is under the vehicle.

Required Tools and Components

- BMM Miata ECU
- BMM wideband adapter harness
- BMM options port pigtail
- Genuine Bosch LSU 4.9 oxygen sensor
- 3 metres of silicone vacuum hose 5/32" or 4mm internal diameter
- 4mm straight barb joiner
- 22mm wrench or 22mm oxygen sensor socket
- Timing light
- USB cable (included with ECU)

- Windows, Mac or Linux laptop with an installed copy of [EFI Analytics TunerStudio](#)
- Spanner and socket set

Removing Original ECU

The stock ECU location for a Miata will be in one of three spots depending on the driving side and year:

Left Hand Drive NB

The ECU can be found above the pedals, next to the steering column.



90-93 Left Hand Drive NA and Right Hand Drive NA/NB

The ECU can be found under the carpet in the passenger side footwell. To access this, the carpet needs to be unhooked from the vertical trim piece on the edge closest to the passenger door. Removing this trim piece can also simplify access. The ECU kick plate will also need to be removed after

taking off the five 10mm nuts and bolts holding it in place.



94-97 Right Hand Drive NA

The ECU can be found behind the passenger's seat, under the carpet. Move the seat forwards all the way. Next, the passenger door sill needs to be removed with a philips head screwdriver so that the carpet towards the

back of the seat can be pulled back to reveal the ECU.

Once the ECU has been located on your Miata, disconnect the car battery then remove all electrical plugs to the ECU. Un-bolt any remaining ECU mounting brackets from the car with a 10mm socket and the ECU should now be free from the car. The last step is to use a philips head to remove the factory ECU mounting brackets from the stock ECU case for these will be needed to mount the BMM ECU.



Connecting Wideband Oxygen Sensor

NOTE: It is imperative that you use a genuine Bosch LSU 4.9 sensor rather than a cloned product. A fake LSU 4.9 will not provide accurate readings and can cause a lot of headaches down the track. The best way of avoiding a fake sensor is to buy directly from a reputable supplier of vehicle parts rather than generic large online re-sellers. Typical part numbers for this Bosch sensor include: 17025, 17212, 17123 and 17217. The notable difference between these part numbers is the cable length so it is recommended to measure what length you need ahead of time.

Find the factory oxygen sensor on the exhaust and unplug it from the wiring harness. In the case that the car has multiple oxygen sensors, the one to remove is the closest sensor to the engine block before any catalytic converters. Next, unscrew the sensor and replace it with a Bosch LSU 4.9 wide-band sensor. Connect the sensor to the BMM wideband adaptor harness. The trailing end of the harness will need to be fed through the firewall into the cabin. The easiest way of doing this, as shown in the image below, is to cut a hole in the nearest firewall bung to the stock ECU location, and feed the cable through that. Cable tie the wiring away from any hot areas of the engine bay. Inside the cabin, connect the wideband adaptor harness plug to the options port pigtail and plug it into the ECU.




Using an External Wideband Controller

In the case you wish to use an external wideband controller such as an *AEM X-Series Wideband UEGO AFR Sensor Controller Gauge*, the wideband sensor should be plugged into the wideband controller instead of directly into the ECU. The best way to wire in the controller is directly to the old narrow band oxygen sensor plug on the car based off the diagram below. In this diagram, pin 1 goes to the controller analogue output, pin 2 to the signal ground, pin 3 to the controller 12V input and pin 4 to the other controller ground (if applicable). Make sure to double check the voltages on the pins before connecting the controller to them. The external controller also requires additional setup in Tuner Studio which will be covered later.

MAZDA 4-WIRE

1

OE: Signal (Black)
Universal: Signal
Type B (Blue)



OE: Heater (White)
Universal: Heater
Type B (Black)

3

2

OE: Ground (Gray)
Universal: Ground
Type B (White)

OE: Heater (White)
Universal: Heater
Type B (Black)

4


Note: View From Front Of Connector

Connecting MAP Line

Look around the intake manifold for any spare vacuum ports that lie after the throttle body and connect the vacuum line. If there are no spare ports, pick one and attach the vacuum line to it using a tee piece. It is recommended but not required to cable tie the vacuum line to the tee. In the image below, there was a free vacuum port on the back of the intake manifold which has been tee'ed off into the MAP line and the blow off valve line (only applicable on turbo charged vehicles).



Like the oxygen sensor, feed the line through the bung in the firewall to the ECU. If you have a 4mm barb joiner, connect the vacuum line to the vacuum line protruding from the BMM ECU case. If you do not have a barb joiner, open up the BMM ECU case with a philips head and feed the vacuum line through the case. Mock up the position of the case in the car before cutting the vacuum line to length. Pull the vacuum line onto the MAP sensor on the ECU (the sensor with the nipple on it pictured below) and optionally fasten it with a small cable tie. The ECU can now be put back into its case.



Using the MAP line combined with an intake air temperature (IAT) sensor, the BMM ECU can run the car using what is known as speed-density air metering. This means that you can unplug the mass air flow (MAF) sensor or the air flow meter (AFM) for the NA 1.6L vehicles. Removing these sensors and replacing them with a pod filter directly to the intake can even result in a fractional power increase from the reduction in intake restriction.

Additional Steps for NA6 Vehicles

The NA6 1.6L vehicles which use an AFM instead of a MAF require a few additional modifications to run with a BMM ECU. A manual NA6 do not have a variable throttle position sensor (TPS) like the automatic NA6, later model NAs and all NBs. An NA6 also needs an external intake air temperature (IAT) sensor wired in as the AFM which has one inside is

typically removed. They also require a jumper for the ECU to control the fuel pump which was previously the job of the air flow meter. Additionally, it is recommended to ground the sensors to the ECU rather than the chassis as detailed in the [NA6 ECU Grounding Guide](#).

The first step is to disconnect the factory TPS sensor. **This is very important or it will cause a short circuit later.** The TPS sensor location is shown in the image below.




The BMM ECUs for this vehicle include a KIA TPS and adapter. The KIA TPS will plug straight to the OEM TPS plug without any additional wiring. If using another variable TPS that requires re-wiring, the NA6 TPS connector pinout is as follows:

Function	Cable Colour
Signal	Green/White

Function	Cable Colour
Ground	Black/Green
5V Reference	Red

The next step is to wire up the IAT sensor and to add a jumper wire to the AFM connector as per the wiring diagram below. Any IAT sensor with two wires can be used although a GM IAT sensor is recommended as FOME already has a configuration for it. As the IAT is a resistance-based sensor, the orientation of the wires does not matter.




Connecting the ECU

Now that the MAP line and wideband are connected to the ECU, the remaining wiring harness plugs from the OEM wiring loom can be plugged into the ECU. Take the factory ECU mounts and attach them to the BMM ECU case. The ECU can now be re-installed into the factory location. The car battery can now be re-connected.

Tuner Studio Setup

Make sure that you have downloaded the latest version of TunerStudio (TS) from [here](#). Although the base version of the software is free, it is strongly recommended to buy a license for the additional features including auto-tuning and the ability to customize the default dashboard.

Begin the setup by plugging the ECU into the laptop and opening TS. Create a new project and click *detect* under firmware. Select the COM port corresponding to the FOME ECU in the device list. If the COM port cannot be found or the firmware cannot be automatically detected, click *Other/Browse* and load the .ini file for the ECU which can either be downloaded or found within the ZIP file on the USB device which appears when the ECU is plugged into the computer.



In the next dialog choose between lambda or air fuel ratio (AFR) as your display units. lambda is recommended as it is easier to comprehend and tune with. For example, the ideal or stoichiometric AFR for regular petrol is 14.7 (14.7 parts air to 1 part fuel) which corresponds with a lambda of 1. Lambda represents the percentage of air in the combustion chamber compared to the amount needed for ideal or stoichiometric combustion to

occur. If a car is running 10% lean, the AFR would be 16.17 and lambda would be 1.1. If the car is 10% rich, AFR would be 13.36 and lambda would be 0.9. Looking at lambda, it is instantly obvious what percentage rich or lean the engine is running but with AFR, it requires more effort.

The only time AFR should be selected here is if you are using an external wideband controller.

In the third dialog box, configure it as shown in the image below but select the com port which corresponds to your ECU. If unsure, go to the device manager on your computer and it should list the COM port number next to the name of the ECU. Click *Test Port* and if successful, move to the next dialog.

Create New Project X

New TunerStudio Project

Communication Settings

Driver: Standard Protocols Driver (Default) ▼

Connection Type

RS232 Serial Interface ▼

Connection Settings

Com Port: COM3 ▼ ?

Baud Rate: 115200 ▼ ?

Bluetooth Port ?


Not tested Test Port

< Back Next >

In the final dialog box, select the default gauge layout (you can change this later as you wish) and click *finish*. The last step before cranking the engine is to click the *Ignition* button to open the ignition settings and change the timing mode from *dynamic* to *fixed* and the fixed timing setting to 10 degrees. This will lock the engine to operate at 10 degrees of timing so that you can set the base timing.

Additional Tuner Studio Steps for an External Wideband Controller

To set up the external wideband controller there are several additional steps in Tuner Studio. First, your display units should be set to AFR for this as already stated. If you forgot to do this earlier, press *CTRL + P* to open the vehicle properties. Now, open the *Aux Sensors* dialog under *Sensors* and the *Full Pinout 3/3* dialog under *Controllers*. As per the diagram below, set the *AFR ADC Input* and *ADC Input* to the pin corresponding with *O2S* (pin 2C for the example). For the values in the *Aux Linear Sensor #1* box you need to reference the manual of your wideband controller for what voltages correspond to its AFR outputs. In the example below, 0V corresponds to an AFR of 10.0 and 4.99V corresponds to an AFR of 19.98. Once these are set, click *Burn*. If TS does not exactly correspond to the readings on your wideband, you can adjust with the correction value.



After completing all of the setup steps, you can go ahead and turn the car key two clicks to *ON* and listed for the fuel pump priming. Once the fuel pump has primed, go ahead and start the engine. Let it run for a few seconds and turn it off again. **Do not drive the vehicle yet, there are still several steps to complete before the car is ready for a drive.**

Set Base Timing


The car should start on the base map although once it is running, the base timing needs to be set up. This syncs the timing between the ECU and the car so that they are both reading the same values. Typically, the base timing will be a few degrees out from the base map as it varies slightly from car to car.

To set the base timing, connect the timing light power to a spare 12V


battery and the inductive clamp onto the cylinder 1 spark plug lead (the closest spark plug to the front of the engine bay). Ensure that the arrow on the inductive clamp is pointing along the wire towards the spark plug, not towards the coil pack.




In TS, under *Ignition > Ignition Settings*, set the timing mode to *fixed* and *10* degrees then burn the configuration.



Now start the car and hold the timing gun trigger, shining the light onto the bottom harmonic damper pulley on the front of the engine. This pulley has two timing marks on it and a labelled cover above it. When the timing is spot on, these marks on the rotating pulley will line up with the *10* and *T* marks on the cover as shown below.



If your timing marks do not line up like in the image above, you will need to change the base timing. Count how many marks the timing is off by and turn the car engine off. In TS, go to *Base Engine > Trigger* and increase/decrease the *Trigger Advance Angle* by the amount of marks the timing was off by then burn the configuration. Repeat this process until the timing marks line up then change the timing mode back from *fixed* to *dynamic*.



First Drive and Tuning the VE Table

Everything is now ready to take your Miata for its first drive. You can't go and thrash it straight away though as the VE table which determines the fuelling needs to be tuned for your vehicle. Before you take the car for a drive, make sure your laptop is charged.

Start the car and plug the laptop in. Within 30 seconds, the lambda gauge should wake up and start displaying a value. For now, you want that value to be around 1 meaning that the exact amount of fuel is being supplied to the engine for perfect combustion to occur. To change the lambda value, you need to modify the VE Table under *Fuel > VE*. VE stands for volumetric efficiency which is the efficiency that the engine can move the fuel and air mix into and out of the cylinders. An example of a VE table is shown below (do not copy this table as it is off a highly modified vehicle). The table adjusts the VE percentage (represented by the numbers on the grid) based on the engine speed (represented as revolutions per minute - RPM) and engine load (represented as the MAP). With the engine running, blip the throttle and see how the indicator moves around the different table cells as the engine state changes.

VE

File View Tools Help


VE Table 3D View

v	240	72.6	72.6	72.6	72.6	75.1	77.4	76.4	75.5	76.8	84.8	87.0	83.2	82.4	73.0	73.9	74.7
e	220	72.6	72.6	72.6	72.6	75.1	77.4	76.4	75.5	76.8	84.8	87.0	83.2	82.4	73.0	73.9	74.7
T	200	72.6	72.6	72.6	72.6	75.1	77.4	76.4	75.5	76.8	84.8	87.0	83.2	82.4	73.0	73.9	74.7
a	180	72.7	72.7	72.7	72.7	72.7	73.2	74.7	76.9	77.0	89.9	89.0	85.7	84.7	73.6	74.6	75.6
b	160	72.7	72.7	72.7	72.7	72.7	85.0	83.9	79.3	77.0	89.3	84.6	86.7	80.2	66.8	68.2	69.6
l	140	72.7	72.7	72.7	72.7	75.2	85.6	81.4	75.3	77.4	79.9	85.3	85.1	80.7	74.7	70.2	76.5
e	130	73.7	72.7	72.7	72.7	78.4	81.1	81.4	80.5	84.4	94.4	96.9	87.2	86.5	76.7	75.0	76.5
Y	110	72.7	72.7	76.6	80.4	77.8	79.9	79.8	78.3	82.7	97.2	95.5	95.7	87.2	75.9	73.6	76.5
A	100	67.2	75.9	81.2	87.9	83.6	83.1	82.0	82.0	83.7	94.1	90.5	82.7	79.0	74.1	68.9	76.5
x	85	61.8	80.6	74.7	83.8	80.7	82.3	81.1	78.4	85.0	94.9	100.0	85.4	73.5	78.3	78.5	80.8
i	75	69.3	79.3	79.8	79.9	78.5	77.3	76.5	74.7	85.9	97.8	100.0	83.5	87.2	87.6	78.7	80.4
s	65	59.4	76.2	74.4	73.9	74.7	75.5	74.7	69.2	80.0	91.4	100.0	89.5	88.0	83.4	73.0	74.6
	55	59.4	71.7	70.5	67.2	67.9	70.8	68.8	64.8	75.9	90.1	93.2	98.9	89.3	68.2	66.2	71.9
	40	55.0	47.2	61.5	56.4	54.7	58.2	56.5	52.6	59.5	82.8	81.7	93.5	76.9	51.8	55.3	59.7
k	30	52.9	43.8	48.1	32.6	31.6	36.3	35.2	37.0	45.0	61.6	66.5	63.8	62.4	41.3	45.2	54.4
P	20	45.0	45.0	45.0	25.2	25.0	25.0	25.0	25.0	26.3	38.1	44.0	36.8	33.7	34.6	46.9	46.6
a		500	700	1200	1500	1800	2300	2900	3400	3900	4300	4800	5300	5800	6300	6800	7300


RPMValue

Burn Close


The general way to tune the VE table is to go through all the cells which the engine will operate within and to adjust the VE percentage until the lambda gauge matches the value in the *Target Lambda Table* shown below and in TS found under *Fuel > Target Lambda*. For example, if the lambda gauge shows 1.1 and the target lambda for that engine state is 1.0, the corresponding VE cell needs to be increased by 10%. The target lambda table supplied with the Miata base map should be sufficient to start with but you can modify it later to make the engine run richer or leaner under certain conditions such as boost or highway cruising respectively.



There are three ways of tuning the VE table. The first way is to drive the car around smoothly as a mate in the passenger seat goes through and changes the VE values until the lambda gauge matches the target lambda. The second and easier way is to use the TS autotuner which is only available in the full version of TS but absolutely worth it. To tune this way, you first need to disable some parameters. Under *Fuel*, open *Closed loop fuel correction* and *Deceleration fuel cut off (DFCO)*, set them both to false and click *burn* with the engine off. The third and easiest (yet most expensive option) is to take the car to a dyno for tuning where they will do either the first or second option themselves. The advantage of a dyno is that they can set it to bring the engine into any state they wish to perfectly configure the VE table.



Next, click the tab labelled *Tune Analyze Live! - Tune For You* to bring up the autotuner. Click to the *Advanced Settings* tab and configure it as shown in the image below. These configuration settings are deliberately quite loose so that TS can quickly tune the general shape of the VE table. On the left side of the *VE Table Control Panel*, you also need to check the box marked *Update Controller* which ensures that the VE table is updated on the ECU as the autotune corrects itself.



Now that the autotuner is set up, start the car and click *Start Auto Tune* on the autotuner. Let the car idle in park whilst it gets up to the minimum temperature. While this happens, you can attempt to change the idle cells in the VE table to get them to a lambda of 1. Once the car has warmed up, **smoothly** drive it around going through the gears and all the way through the rev range. A mix of flat, uphill and downhill driving in different gears is optimal to tune the majority of the engine's operating range. After you are sufficiently happy, click *Stop Auto Tune*, turn the engine off and click *Save on ECU*. You will want to repeat this process several more times, every time dropping the *Cell Change Resistance* and *Authority Limits* to slowly refine your VE table.


When you are satisfied with your VE table, turn closed loop fuel correction and *Deceleration fuel cut off (DFCO)* back to true. You don't actually need DFCO to be enabled although it will save fuel by turning the injectors off when the car is rolling in gear. Your Miata should now be relatively safe to drive but this is only the start of the tuning journey. As you read through the more advanced guides in this wiki, you will learn about all of the different ways the ECU can be configured to improve the drivability and squeeze every drop of performance out of your Miata.

Miata 36T Trigger Wheel Installation

A trigger wheel with more teeth on the crankshaft provides a finer resolution of the crankshaft position signal. This finer resolution enhances timing control, reduces signal noise and vibration, and improves performance, especially at high RPM. Overall, it contributes to better engine stability and drivability, making it particularly beneficial in high-performance or racing scenarios.

For Miatas, there are a range of upgraded trigger wheels available, most with 35 or 34 teeth referred to as a 36-1T or 36-2T trigger wheel. The triggers nominally have 36 teeth and either one or two teeth are removed so the crank position sensor will receive a signal when the crank has completed a full rotation.

The trigger wheel recommended for BMM ECUs is the 1999-2001 Mazda Protege 36-1 Trigger Wheel (part # ZM0111408). This trigger wheel is compatible with the stock crankshaft pulley and a Fluiddampr crankshaft pulley. If using an ATI damper, you must purchase a compatible trigger wheel.



Installation

Before completing this installation it is recommended to have the car running on a BMM ECU with the stock trigger wheel. This way, only a few parameters in the tune need to be changed to get the car working with this part.

Disconnect the Battery

Ensure the engine is off and disconnect the battery for safety.

Remove Engine Belts

Remove the engine belts obstructing access to the crankshaft pulley. Typically, there are two belts: the accessory belt which drives the power steering and A/C and the alternator belt which also drives the water pump. The belt tensioners are respectively located on the power steering pump (top right on the engine from the front) and the alternator (bottom left). With the belts removed, you should have clear access to the crankshaft pulley.

Rotate Engine to Top Dead Center (TDC)

Using a 21mm socket on the bolt in the centre of the crank pulley, rotate the engine clockwise until the marks on the crank pulley line up with the timing marks on the timing belt cover.



Remove the Crankshaft Pulley

Remove the crankshaft pulley by undoing the four 10mm bolts on the front. The large centre bolt doesn't need to be removed if using the stock or a Fluiddampr pulley. An ATI damper will require removal of the crankshaft bolt to install so consult their installation manual if required. Behind the pulley should be the OEM trigger wheel. Go ahead and remove it, put it in the bin or use it as a beer coaster.


Install the New Trigger Wheel

The new trigger wheel can go on to the engine in two orientations, correctly and backwards. To radially align the trigger wheel, there is a dowel pin on the crank which slots into a hole in the trigger wheel. At TDC, the dowel pin should be vertical or at the 12 o'clock position. The correct orientation is to put the trigger wheel on, as per the diagrams below, with the centre recessed part of the trigger pointing towards the crank, the white dot facing outwards and the missing tooth at approximately the 7 o'clock position when the engine is at TDC and the dowel pin is vertical. The trigger wheel is the wrong way around if the teeth are further forwards of the engine than the centre recess, the white dot is facing towards the engine, or the missing tooth is at the 5 o'clock position at engine TDC.

This side towards engine



This side away from engine



If installing an ATI damper and trigger wheel or a Fluiddampr, consult the manual as the installation has several additional steps which include

bolting the trigger wheel to the aftermarket crankshaft pulley damper. In the case of a Fluiddampr, the orientation of the Mazda 323 trigger wheel will be identical to installation onto a stock pulley.

Re-Install Crank Pulley and Adjust Crank Sensor

Re-install the crank pulley and the four 10mm bolts (109-151 inch/lbs 13-17 Nm). Check the clearance between the crank sensor and the tip of a tooth on the timing wheel, there should be a 0.5-1.5 mm or 0.020-0.059 inch gap between the tooth and the sensor. If you later come up with trigger errors, this gap may need to be reduced. To reduce the gap, loosen the 10mm bolt holding the crank sensor and wiggle it to the desired position.

Re-Install Belts and Connect Battery

Re-install the accessory and alternator belts checking they are suitably tight. Now connect the battery back to the car. The mechanical installation is now complete and it's time to boot up the computer.


TunerStudio Settings

In the "Trigger" menu under the Base Engine tab, change the trigger type to 36/1 and the trigger angle advance to 75 degrees.

If using a 36-2 trigger wheel instead, the first setting would be 36/2 and the advance will likely be different so check with the manufacturer. In the case of a 36-2T trigger wheel for an ATI damper, the advance angle

should be around 148 degrees.

These settings will likely get the car started with the Mazda 323 timing wheel however the trigger angle advance may need to be iterated to perfectly match the timing on your car. To check or set the base timing, set the timing to fixed in TunerStudio and use a timing light on the crank to measure the timing. If the timing is not 10 degrees BTDC, iterate the trigger angle advance in TS until it is spot on. This is covered in "Set Base Timing" within the [Miata Quick Start Guide](#).



Now after ensuring your timing is reverted back to dynamic in TS, the installation should now be complete!

Miata Coil On Plug Conversion

Converting your Miata to run a coil on plug (COP) ignition setup is a great engine upgrade for those with forced induction or high-performance engines. Offering a stronger spark and improved reliability, coil-on-plug technology outperforms the coil packs of the 1990s and early 2000s Miatas. It also eliminates the need for ignition wire replacements and reduces electrical interference, making it a more robust and appealing option in automotive applications.

This guide will discuss the steps to convert your stock NA or NB Miata ignition system to COP.

Parts Required

Ignition Coils and Connectors

Toyota and Audi/VW ignition coils are the most common. For Toyota coils, ones off a 1ZZ engine will work as well as many other variants. Some part numbers for Toyota coils are: 90080-19015, 90919-02239, 90080-19023, 90919-02234. The part number for the coil connector is: 90980-11885.

For Audi coils, the ones used are referred to as R8 coils as they are used on the Audi R8 (as well as most other Audi's and some VWs). The most common part number is: 06E905115G however there are also many

variants that will work depending which brand of "R8 coil" you want and how much you want to spend. The part number for the R8 coil connector is: 1J0973724.

Both of these ignition coils work and both have their distinct advantages. The R8 coils securely clip onto the spark plugs however they protrude further from the spark plug holes than stock so usually require a form of spacer to keep them from wiggling around. The Toyota ones sit flusher however they also require a bracket for their mounting bolt to secure them in place. For the NA6 and earlier NA8 cars, the tachometer takes a signal from the ignition coils, only the Toyota coils have this pin. You can run R8 coils on these cars however your tachometer will not work unless you wire it directly to the ECU.

Car Wiring Harness Connectors

If you wish to solder directly to the harness, you can ignore this however those wishing for a more elegant solution prefer to clip their COP harness onto the existing vehicle harness.

For a 1.6L, this is more difficult and it is either recommended to buy a spare igniter to take apart or simply wire directly into the harness. For the other NA and NB Miatas utilizing a coil pack on the back of the valve cover, a compatible connector part number is: 6098-0144.


Other Components

- 10,000uF capacitor to be installed between the 12V and GND which helps to filter electrical noise however this is not strictly necessary.
- 18-22 AWG wire to help reduce the internal resistance and carry the


power to drive the coils.

- Wiring harness or electrical tape to wrap over the harness
- Crimping tool
- Soldering equipment
- Heat shrink
- Wire strippers
- Wiring
- The wiring diagrams for each model NA/NB is shown below.


NA6 (1.6L)



NA8 94-95 (1.8L)



NA8 95+ /NB1 (1.8L)



Toyota Coil Pinout

From left to right on the coil is the ground, ECU signal, tachometer signal, and 12V. For later NA8 and NB1 Miatas, the tachometer signal does not need to be wired up.



1. Ground
2. Trigger
3. Tach
4. 12V

R8 Coil Pinout

From left to right on the coil is the ground, ECU signal, ground, and 12V. The two grounds can be connected together. Note that the R8 coils have

no tachometer signal meaning that on NA6 and early NA8 cars, the tachometer will need to get its signal from the ECU. Later NA8s and NB1s do not have this issue.



COP Harness

To make the neatest harness, cut the wires to length with the coils installed in the car in their desired orientations. Leave a small amount of excess so there is no tension on the wiring harness and room in case a wire needs to be re-stripped. Make sure to cover each exposed solder joint with electrical tape or heat shrink then go over the entire harness with

tape to protect it. It is recommended to check your harness wiring several times for shorts or mistakes before powering on the car.

Coil Mounts

For both coils, there are a range of third-party suppliers selling mounting brackets. If you wish to DIY a mount, they can be made relatively inexpensively using aluminum or 3D printed spacers (ABS or other high temperature plastics are recommended).

ECU Dwell Time Setup

The dwell times need to be modified in TunerStudio before starting the car with the new COPs. Recommended safe dwell settings are shown below for both Toyota and R8 COPs. Note that dwell times can vary significantly between different ignition coils and it is recommended to do some additional research on your specific coil. The longer the dwell time, the longer the coil charges for and the stronger the spark. Too little dwell will result in a weak spark and too much dwell can draw an excessive amount of current, possibly melting the coil.

Cranking Settings

File View

Cranking Settings

- Cranking RPM limit(RPM)

Fuel

- Injection mode: Simultaneous
- Fuel Source For Cranking: Fixed
- Base fuel mass(mg): 27.0

Ignition

- Timing Advance mode: Fixed (auto taper)
- Fixed cranking advance(deg): 10
- Fixed Cranking Dwell(ms): 4.0**

Idle air valve

- Cranking base IAC position(percent): 60
- After cranking IAC taper duration(cycles): 50
- Override cranking IAC CLT multiplier: true

Advanced

- Enable flood clear: true
- Enable faster engine spin-up: true
- Use Advance Corrections for cranking: false
- Use Flex Fuel cranking table: false

This sets the RPM limit below which the ECU will use cranking fuel and ignition logic, typically this is around 350-450rpm.

Burn Close

No warnings	No Check Engine	Trigger OK
No clutch down	No braking	AC Switch off
IAT OK	No SD card	No SD logging

Dwell

File View

Dwell time base

RPM	Dwell
500	2.50
1200	2.40
2000	2.30
3000	2.20
4000	2.10
5000	2.10
6000	2.00
7500	1.90

Dwell voltage correction

Battery ...	Multiplier
8.0	2.28
10.0	1.62
12.0	1.26
14.0	1.00
16.0	0.84
18.0	0.70
19.0	0.70
20.0	0.70

Miata VVT Setup and Tuning

Tuning the NB2 BP-Z3/BP-VE VVT motor can be a daunting task. This guide will detail the process for configuring and tuning the VVT for an NB2 VVT motor using a BMM ECU.

Required Equipment

- Vehicle running an NB2 VVT motor.
- Access to a dyno or a safe location to tune the vehicle using Virtual Dyno. An actual dyno is preferable to virtual dyno due to the accuracy of readings and ability to safely vary the operating point of the engine.
- Laptop with TunerStudio, MegaLog Viewer and optionally Virtual Dyno installed.

Initial TunerStudio Configuration


Open TunerStudio and open the "VVT Configuration and PID" menu under the advanced tab. Going down the settings in this menu first is the activation delay. This is the initial delay when the car is started before the VVT is enabled. A setting of 1000-5000ms (1-5s) should be suitable here to give the engine enough time to build oil pressure before enabling the VVT.

The "Do not control below RPM" setting or activation RPM disables VVT until the engine RPM exceeds this value. Ideally set it about at 100-200 RPM or so above your idle RPM to keep it disabled during idle. This will simplify the idle tuning as the engine torque from the VVT changing can lead to a fluctuating idle.

For the VVT solenoid banks, an NB2 motor only has VVT on the intake so select the pin labelled as "VVT" for the "VVT solenoid bank 1 intake" setting.


On the right side of the menu are the PID control options. If you are new to PID tuning, plenty of guides exist detailing how it works. [This video by RCModelReviews](#) details how PIDs work on a basic level.

Pictured below are some reasonable default settings however it is still recommended to configure the settings yourself as settings can vary from car to car.



VVT Offset Setting

Before configuring the VVT PID, the basic VVT angle offset needs to be configured. This is to calibrate what the ECU thinks is 0 degrees VVT angle to the actual VVT angle on the car, similar to setting the base timing. **This is different to the offset in the PID control menu.** Open the "Trigger" menu under the "Base Engine" tab and locate the "VVT offset bank 1 intake(value)" setting. In the engine bay, unplug the VVT solenoid highlighted in the image below:



Right click one of the gauges on the background of TunerStudio and under VVT, change it to "VVT bank 1 intake vvtPositionB1IGauge". This will show a live reading of the detected VVT position on the car.

Start the car with the solenoid unplugged and read the VVT position on the gauge. Change the "VVT offset bank 1 intake(value)" setting until the VVT position reads 0. The VVT angle is now calibrated and you can shut off the car and plug the solenoid back in. Your offset should be similar to that shown below:

Advanced Trigger

<https://rusefi.com/s/vvt>

? Cam mode (intake cams)	Miata NB2
? Cam mode (exhaust cams)	Inactive
? Cam for engine sync resolution	Intake First Bank


Set offset so VVT indicates 0 degrees in default position

? VVT offset bank 1 intake(value)	101.5
? VVT offset bank 1 exhaust(value)	0.0
? VVT offset bank 2 intake(value)	0.0
? VVT offset bank 2 exhaust(value)	0.0
? Require cam/VVT sync for ignition	false
? Maximum cam/VVT sync RPM(rpm)	0
? Print verbose VVT sync details to console	false
? Print verbose trigger sync to console	false
? Display logic signals	true
? Do not print messages in case of sync error	true
Focus on inputs in engine sniffer	false
Enable noise filtering	false
? Trigger Edge Filter	with filter

PID Tuning VVT Settings

Under the PID settings the offset is the VVT solenoid duty cycle offset. Basically, the solenoid will only activate if it is pulsed above a threshold duty cycle and the PID controller needs to know what duty cycle this occurs. PID tuning can be a tedious process and it is recommended to outsource it to a professional if you are not confident.

To tune the offset, open the "VVT Closed Loop Target" table and set every cell to a constant value such as 10 degrees. Set the P gain to 1. Right click one of the gauges on the background of TS and under VVT, change it to "VVT bank 1 intake - vvtPositionB1IGauge". This will show a live reading of the detected VVT position on the car.




Start with an offset value of e.g. 10. Start the car and hold the engine RPM

at a constant value above the threshold RPM and observe the VVT position gauge. If the gauge does not change, increase the offset by 5-10 and repeat until you find the minimum offset required for the gauge to change VVT position. Note that the actual VVT position won't be correct yet as the PID controller still needs to be set up. A value in the range of 30-40 is expected.

Next is the PID tuning. This step can take a while and is important to do thoroughly to ensure that the VVT can reach its target angles quickly and without overshooting significantly. The PID tuning is best done on a dyno or with a mate to drive the car whilst you tune it. Alternatively you can take a driving datalog, analyze it in MegaLogViewer, revise the PID settings and take another driving log. This method would be very time consuming and the first two are recommended.

To tune the P, I, and D settings you can either start from scratch or work from other users values to refine them. Below are some PID values you can work from if you wish. The process of tuning the PIDs is to put various angle targets in the VVT intake target table at different engine loads and RPM and to move the engine around between them. As the VVT target changes, the PID loop will activate to attempt to reach the new target. By watching the response of how quickly and with how much overshoot the controller reaches the target, the PID controller can be tuned.

An example on the dyno this might look like having all VVT target cells below 1500 RPM at 0 and above that at 20 degrees. In the "diagnostics and high speed loggers" tab you can set one graph to be the VVT position and the other as the VVT target as shown below:



Next, rev and hold the engine up to e.g. 2000 RPM and watch how quickly the VVT position rises to match the VVT target. If the position overshoots, decrease P or increase D, vice versa if it undershoots. If the position slowly drifts from 20 degrees, you would increase the I gain. The PID settings would be varied until the VVT position quickly rises or falls to and VVT target changes without much over or undershoot. To properly optimize the PID tune, it is recommended to repeat a similar tuning process with lots of VVT angles.

Once the VVT is PID tuned, the VVT target table can be tuned.

VVT Target Angle Tuning


Tuning the VVT angle is where the power gains are made. At this point the VVT should be fully set up and PID tuned to quickly reach the target position. If you cannot be bothered tuning the VVT angle, copying another users settings may yield decent results provided they have done the proper tuning however there will always be slight variances from car to car. A reasonable target table example is shown below:

f u e l i n g : .	100	8	15	25	35	35	15	0	0
	75	8	15	25	30	30	15	0	0
	60	8	15	20	25	25	15	0	0
	40	8	12	18	20	20	10	0	0
	25	8	12	18	20	20	10	0	0
	10	0	0	15	20	20	10	0	0
	5	0	0	10	10	10	10	0	0
	0	0	0	0	0	0	0	0	0
		↕	800	1500	2500	3500	4250	5000	6000
		RPMValue							

The target angle is tuned in two sections, ramp run tuning and steady state tuning. Ramp runs are used to tune the VVT at maximum throttle and steady state tuning is used to tune the angles for partial throttle applications when the engine isn't fully loaded. This tuning is best done on a dyno for the best accuracy.

To tune the ramp run, set the entire VVT target table to 0 and perform a run. Save this run and do another, this time incrementing the whole VVT target table angle by 5-10 degrees depending how many dyno pulls you want to do. Repeat this process until the maximum VVT angle of 44

degrees is reached. Now load up all of the dyno runs and overlay them on top of each other. There will be points across these graphs where the torque from one VVT angle rises above the others. Power can be used as well but it is easier to do the tuning using the torque plots. For a given RPM range, take the VVT angle with the highest torque and put that into the maximum load section of the VVT target table. Repeat this for every RPM range where a different VVT angle yields a higher engine torque until the maximum load row of the table is populated. An example ramp run dyno graph is shown below where there are several "dyno runs" at different VVT angles. The yellow lines indicate the crossover points where a certain VVT angle has the most torque. Simply set the highest torque producing VVT angle in the chart for a given RPM range to that in the target table.



If you have some way of maintaining a constant throttle position below 100% such as a chock under the pedal (**on the dyno only!!!**) or limiting the maximum throttle body travel, ramp runs can be used to efficiently populate the whole VVT table for conditions where the engine isn't fully

loaded.

To steady state tune on a dyno, the dyno will hold the engine at a specific RPM and load so you can vary the VVT angle in real time to see which angle has the highest torque. You then move to another cell and repeat this to tune the lower engine load sections of the VVT target table. To save time, it is possible go along a row tuning every second cell then interpolating between them. The downsides to steady state tuning is the higher load and RPM will quickly heat up the engine so it is crucial to monitor the temperature. This method also takes quite a lot of time but will yield precise results as the angle can be varied in small increments as the torque is measured instantaneously.

Road tuning with steady state is not possible as there is no way to measure the torque of the engine as the car sits at a specific load and RPM.

NA6 Miata ECU Grounding

When installing a standalone ECU on an NA6, there is one step that is often overlooked and not well-documented. This step is to ensure that the car sensors are grounded to the ECU instead of the chassis.

Grounding sensors directly to the ECU rather than the chassis provides numerous benefits including reduced electrical noise, improved signal integrity, and better sensor performance. Eliminating factory ECU ground connections to the chassis becomes particularly important when swapping to a standalone ECU with additional sensors, as it ensures a centralized grounding system and avoids potential conflicts in sensor readings.

Instructions

There is a stud coming off the intake manifold below the fuel rail, holding a P clamp for the wire harness with a connector to the Cam Angle Sensor. This is where a pair of grounds meet on a round ring terminal: one being a chassis ground (black), the other being an ECU ground (black and green). The black and green wire must be cut from this ring terminal and isolated. The location of this wire is shown in the images below:



INTAKE MANIFOLD, NEAR REAR OF MOTOR



BLACK AND GREEN GROUND WIRE



Note: If your car's ground is different due to modifications, follow the harness from the passenger side firewall to the cam angle sensor, and the pair of grounds may have been relocated to another location. See the NA6 wiring diagram at the end of this guide for further information.

Benefits

Sensor grounds play a critical role in ensuring accurate readings and proper functionality of various vehicle sensors. It is preferable to have sensor grounds connected to the ECU rather than the chassis. Eliminating a factory ECU ground connected to the chassis is important for several reasons:

- **Noise and Interference Reduction:** Grounding sensors directly to the ECU helps minimize electrical noise and interference that can affect sensor signals. The ECU acts as a central point for grounding, providing a cleaner and more stable electrical reference for sensor operation.
- **Signal Integrity:** Grounding sensors to the ECU ensures consistent and reliable signal integrity. By eliminating ground loops and potential differences between sensor grounds and the ECU ground, accuracy and precision in sensor readings are maintained, leading to more reliable engine management and diagnostics.
- **Improved Sensor Performance:** Sensors rely on stable ground connections to function optimally. By grounding sensors to the ECU, they benefit from a more controlled electrical environment, resulting in improved sensor performance, responsiveness, and accuracy.
- **Preventing Ground Offset Issues:** When sensors are grounded to the chassis, there can be voltage potential differences between the sensor ground and the ECU ground. This can lead to ground offset issues, where sensor readings are skewed or erratic due to voltage differentials. By grounding sensors directly to the ECU, these issues

are minimized or eliminated. Maintaining Factory ECU Grounding: Factory ECU ground connections to the chassis should be eliminated if aftermarket modifications are made to the vehicle's electrical system. This ensures that sensor grounds are centralized and routed through the ECU, maintaining a consistent electrical reference and preventing potential conflicts or inconsistencies in sensor readings.


NA6 Wiring

If you are having difficulties tracing the correct wires to isolate, the wiring diagram below highlights the black and green ground wire and where it connects to on the car. By cutting the black and green wire from the engine block, you can see that the crank angle sensor is only wired to the ground on the ECU.

GROUND LOCATIONS TABLE

AA

Component	Figure No. (Location)
GROUND A: (NEAR BATTERY)	1 (A 2)
GROUND B: (LEFT SIDE OF ENGINE COMPARTMENT, JC-01)	1 (E 3)
GROUND C: (RIGHT SIDE OF UNDERDASH NEAR BLOWER)	1 (E 3)
GROUND D: (RIGHT REAR COMPARTMENT ON ENGINE BLOCK)	3 (E 9-10)
GROUND E: (RIGHT REAR ENGINE COMPARTMENT ON ENGINE BLOCK)	2 (E 4)
GROUND F: (RIGHT SIDE OF UNDERDASH, ABOVE BLOWER)	5 (B 17)
GROUND G: (LEFT SIDE OF UNDERDASH, ABOVE FUSE BLOCK, JC-04)	5 (B 17)
GROUND H: (FAR RIGHT SIDE OF UNDERDASH)	5 (E 17)
GROUND I: (FAR LEFT SIDE OF UNDERDASH)	5 (E 17)
GROUND J: (REAR OF TRUNK, BETWEEN LICENSE LIGHTS)	6 (E 22)
GROUND K: (RIGHR REAR TRUNK)	6 (C 22)



How to add, change and test a page in the wiki

Prerequisites

- A free login in GitHub


Simplest approach to make a small change

- go to end of page and click on "Edit this page" link
- follow GitHub's instructions for "[Editing files in another user's repository](#)".

Best way to edit or add a larger number of pages


Get this: [Github Desktop](#)


Clone the wiki repo [Wiki Repo](#)



Get VSCode: [VSCode](#)

Open Wiki in VSCode from github desktop





Start to edit the docs

Pages are created with a right click and named ##-xxxx.md, they will show up as pages in the wiki.

Folders are creatable with a right click, they will show up like this in the

wiki **Fuel-Algorithms** >

To control ordering of topics in sidebar navigation the so called "numbered prefix" concept is used. This concept is further explained in [linked section of Docusaurus user manual](#)

To make images work the images need to be in the same folder as the .md, image names are also case sensitive so check capitals.

This markdown cheat sheet will tell you everything you need to format pages

<https://github.com/adam-p/markdown-here/wiki/Markdown-Cheatsheet>

Save your work and proceed to testing of change.

How to test your changes

Prerequisites for local test

- [Node.js](#) version 18 or above:
 - When installing Node.js, you are recommended to check all checkboxes related to dependencies.

run Docusaurus locally

Change directory:

```
cd wiki
```

Install NodeJS dependencies:

```
npm install
```

Run the development server:

```
npm start
```

The `cd` command changes the directory you're working with. In order to work with your newly created Docusaurus site, you'll need to navigate the terminal there.

The `npm install` installs all the dependencies for your site. You'll need to run this command once when you first download the project, and again only if you `package-lock.json` file changes.


The `npm start` command builds your website locally and serves it through a development server, ready for you to view at <http://localhost:3000>.

Open `docs/13-How-to-edit-wiki.md` (this page) and edit some lines: the site **reloads automatically** and displays your changes.


How to publish your change to wiki

in VScode and go to github desktop

It will ask you for a title, description and to commit the changes (see bottom left of picture)



Once that is done you can push your changes and they will get automatically updated to the wiki



How to structure

- Stuff!
- More stuff!
- Stuff that looks like stuff but isn't!

Subtitle 1

Subtitle 2

Subtitle 3

This kind of subtitle

You can also use like **this link**

Additional Information

Some lists and links to useful information

Trusted Suppliers of parts

This page contains information on suppliers that users of FOME have purchased items from and had good results.

Trusted Suppliers of parts

This page contains information on suppliers that users of FOME have purchased items from and had good results.

Deutsch connectors - [aliexpress Jorch](#)

Wiring (TXL, etc.) - [Prowireusa](#)

Wiring - [4RCustomsWire](#)

Brand & Marketing Resources

Here, you can find assets related to our project's branding, trademarks, and marketing materials. While our project is open source and inclusive, we encourage users to respect our brand identity.

Assets

Logo



[Download LogoFiles.zip](#)

Font

[Download Comfortaa.zip](#)